High-throughput Phenotyping Assay Andersen laboratory - updated August 2018 BCR

Amplifying your populations:

- For each generation picked, use plates from the same batch of NGMA and OP50.
- If picking for a GWA assay, make sure there will be enough 6 cm plates for each generation.
- Pull out plates to room temperature several hours (or the night) before picking to ensure you will not be picking to "wet" plates.
- It is necessary monitor your strains through this whole process. If they are growing slowly you can leave the worms at room temperature the day/night before you pick them. Start monitoring at the first generation to make subsequent picking as easy as possible. Be careful of temperature sensitive strains or mutants, as they are most affected by shifting temperatures.
- These steps ensure that trans-generational effects of starvation and high levels of crowding are minimized.
- 1. Using sterile, autoclaved spatulas, chunk a starved plate onto a fresh OP50-spotted plate. This step is usually done on Wednesday/Thursday for normal sorter assays (see schedule at the end of this protocol). If the plates you are chunking from are several months old, you should chunk a larger area of agar to the new plate to ensure that enough worms come off of the chunk. Store your plates in the 20° room between generations, unless worms are growing slowly, in which case store your worms at room temperature on your bench.
- 2. After 48 hours, pipette 15 μ L bleach solution away from the lawn of a new plate. Pick ten to fifteen gravid worms into the bleach. Do this for each strain. This will help prevent the spread of contamination from the chunk plate.
- 3. After 24 hours, pick 10-15 L1s to a new plate for each strain. If for some reason the L1s didn't survive the bleach, make a note of it and pick from the chunk plate for generation one.
- 4. After 48 hours, pick five late-stage L4s to one 6 cm plate from each strain. This pick is generation one. **NOTE:** Worms may have grown into young adults by this time. Pick the youngest worms you can find.
- 5. Three days later, pick five late-stage L4s to a fresh plate for each strain. This pick is generation two.
- 6. Three days later, pick five late-stage L4s to fresh plates for each strain. Make sure all of the plates are from the same batch of NGMA and same OP50. This pick is generation three.
 - Dose responses pick to four plates.
 - · Heritability/other high replication assays (NILs, allele swaps) pick to two or three plates.
 - Mappings pick to one plate.
- 7. Four days later, pick five L4s of each strain to two plates for every well that will be setup in the high-throughput assay. This is generation four. Pay attention to the timing for each strain. Some strains grow more slowly. It is best to group strains together with similar growth speeds. We've found that it is often good practice to note the time and date that the plate is setup. In that way, you can see how long it takes to get to a plate of gravid worms without starvation. If strains are growing slowly or have a low population number, pick six or seven worms per strain. Try to pick as fast as possible. You don't want one strain to be four hours older than the last strain.

- **Dose responses** you will have five wells for each of four strains in quadruplicate. Therefore, you will have 20 wells and require a total of 40 plates from each strain. Write down the order that you picked each strain from one to 40. In that way, you can mix older plates with newer plates to even out the age of the worms picked. If you will be running less than ten 96 well plates in your assay, you can reduce the number to 14-20 plates/strain.
- Heritability assays you will have seven wells for each of 12 strains. Therefore, you will need 14 plates from every strain.
- **Mappings** you will have one well for each strain. Therefore, you will only need to pick two plates of every strain.

96-well Bleaching and Synchronization:

- 8. In the afternoon, four days before bleaching (~84-90 hours, the same day as your gen. 4 pick), make 200mL of fresh bleach solution (see recipes page). Store at 4°C until needed.
- 9. Make 500 mL batches of fresh K Medium (see recipes page) a few days in advance of preparing assay plates so you can check it for contamination. This can be made the same day as the bleach. When making K medium, add all water and salts, then filter with Thermo Filter Unit (Cat #566-0020). After filtering, add cholesterol that has been filtered (Cat. # PN 4192, Pall Life Sciences). Decrease any opportunities for the filtered K medium to become contaminated. If your K medium is contaminated, make new.
- 10. If you are doing a 96 well bleach, check that there are enough autoclaved deep 96 well plates and autoclaved pasteur pipettes before your bleach day. They must be cleaned at least a day in advance so they have time to dry before autoclaving. Check deep 96 well plates for any white residue at the bottom of the wells, as these may contaminate your assay.
- 11. Pay close attention to your strains as they grow during this last generation. On the day of the bleach, you want to have a healthy robust population of gravid animals. Check the plates two and three days after picking to make sure that they will be staged for the bleach and staged close to each other. Usually, we take out a few plates (or the entire batch) for 12 to 24 hours to speed up slow strains.
- 12. Four days after picking generation four, check the strains to ensure your worms are staged properly for your bleach. We want a plate with many gravid animals but not a huge population size and no starvation.
- 13. Type up how you would like your strains to be organized in each 96 well plate (see plate setup examples at the end of this protocol). You will later use this information to make a CSV file used in data analysis. Once your worms are staged properly, sterilize your bench with bleach and ethanol, then lay out your fourth generation plates in the same order you will have them arranged in your 96 well plates. NOTE: if your assay has 12 or fewer strains, you may choose to perform a conical bleach instead of the 96 well bleach. Follow the separate protocol attached.
- 14. Take your bleach solution out of the 4° fridge before you start washing your plates into the deep 96 well plate (or 30-45 minutes before you will finish filling the wells of the deep-well plate). This allows the bleach to warm up a little bit, allowing for more effective bleaching.

- 15. Working with a partner, use M9 to wash worms off from plates and add to the appropriate well. Add two mLs of M9 to the first plate using a filler dispenser pipette. Gently shake the M9 back and forth in the plate, dump the M9 onto the next plate and shake the M9 back and forth. Continue this for each plate needed for one well (normally two plates per well). After the final plate, have your partner transfer the worms using a Pasteur pipette to the corresponding well of a deep 96-well plate (Arctic White, AWLS-X10005). You can use a piece of foil wrapped around the deep-well plate to help keep your place. It is important to make sure this step goes efficiently and quickly. The longer the adults and embryos stay in the hypoxic condition, the more a stress response might be triggered.
 - It is necessary to add the same volume to each well so that the 96-well aspirator functions
 properly. This is why you should only add M9 to a set of plates directly before you wash the
 worms from those plates into a well. If liquid remains on the plates for too long, it will absorb into
 the plate, giving different final volumes.
- 16. Carefully remove the Pasteur pipette bulb and leave the pipette into the well to mark the well that has been filled.
- 17. After washing all worm strains into the deep-well plate, remove all Pasteur pipettes. Be careful to avoid cross contamination, by slowly removing them one at a time and allowing excess liquid to drain into the well. You can again use aluminum foil to help keep wells covered once the pipettes are removed. Put the pipettes into 50% bleach solution until the setup is complete.
- 18. Make sure all wells, including the blanks have an equal volume of liquid. It is easier to fill them and make even now, then when you are adding bleach to mostly empty wells. This step is crucial to allow the 96-well aspirator to remove liquid from each well evenly. Add ~1.4 mL to wash wells with the dH₂O squirt bottle to ensure that they are not problematic during aspiration. Securely place the sealing mat on the deep-well plate. Check to make sure the sealing mat is flat across the whole plate.
- 19. Set up the 96-well aspirator following the Setup 96-well Aspirator protocol (i.e. clean the aspirator with ethanol if required). Empty the vacuum flask attached to the 96-well aspirator. It works more reliably and reproducibly when empty.
- 20. Also add ~1.4 mL to every well in the balance plate by the centrifuge labeled "Step One". Tare your deep well plate on the scale and make sure the balance plate is within +/- 10 grams of that weight. Take the other balance plate (labeled "Step two") by the centrifuge and make sure it is filled with 700 μL of water per well.
- 21. Centrifuge the deep well plate at 1100 rpm for one minute using the 5810R clinical centrifuge at room temperature with the first balance plate. The volume of the liquid per well should not exceed 1.7 mL to prevent contamination during centrifugation
- 22. Take off the sealing mat, and remove the M9 using the 96-well aspirator (VP 177A-1, V&P Scientific). Check to make sure that every well has been aspirated. If not, then remove the M9 by hand.
 - When using the aspirator be aware that the aspirator may leak after aspiration! After you finish any aspirating, gently push or slide the plate out of the manifold base. Once the plate is clear of the aspirator, hold a paper towel gently against the aspirator pins and tilt the aspirator towards the side with the tubing to clear any liquid remaining in the manifold. Gently blot the pins to remove any remaining moisture.

- Be careful not to disturb the worm pellet. To avoid disturbing the pellet, it is best to aspirate the M9
 as soon after the centrifuge finishes as possible.
- 23. Add 700 μ l of bleach solution by manually using the 12-channel 300 μ L pipette. Pipetting 233 μ L three times down the plate works fine. Seal with the sealing mat after all bleach has been added.
 - Use the fresh bleach solution that you have already pulled out to room temperature a half hour prior to bleaching. Bleach solution should have been prepared four days ahead of the bleaching process.
- 24. Take the sealed plate over to the balance and tare for that weight. Hurry! Wasted time leads to over bleaching.
- 25. Shake on the microplate vortex at 1450 rpm for 2 minutes then rotate the plate 180° and shake for 2 more minutes. Use rubber bands to hold the deep-well plate onto the vortex.
 - Much of the variability in the number of L1s and survival of L1s comes from this step. If you note
 that all adults are dissolved after four minutes, then add 50% more embryos per well when titering.
 Survival is compromised whenever the animals are over-bleached.
 - You want the adult worms to be 90% dissolved by the bleach but not completely dissolved. In other
 words, there should be occasional adult carcasses floating around. However, when the options are
 to have more carcasses and more healthy embryos, or fewer carcasses and fewer healthy
 embryos, it is better to err on the side of the former.
- 26. While the plate is shaking, put M9 into a disposable reagent trough. Get new tips on the 12-channel pipette to prevent putting any extra bleach into the deep-well plate.
- 27. Also while the plate is shaking, check that the other balance deep-well plate is within 10 g of the tared bleach plate weight. This should be fine if you've added 700 μL to each well. Use a dH₂O squirt bottle to even it out if necessary. Put this balance in the centrifuge.
- 28. After four minutes total shake time, spin down the worms at 1100 rpm for one minute using the 5810R clinical centrifuge. Always make sure to remove the sealing mat carefully after the spin to avoid cross contamination.
- 29. Aspirate out the bleach solution using the 96-well plate aspirator. Move quickly!
- 30. Use 12-channel 300 µL pipette to add 700 µl of M9 to every well and shake on the microplate vortex for 15 seconds. Move quickly!
- 31. Spin down the worms at 1100 rpm for one min. using the 5810R clinical centrifuge.
- 32. Remove the M9 using the 96-well aspirator. Move quickly!
- 33. Repeat steps 30-32 two more times for a total of three M9 washes. Move quickly! After the bleach, the wells look yellowish. After washing, the wells should look much less yellow. You can vortex for the washes longer if you have lots of worms and need extra bleach time. If you are over-bleaching (by accident) or have very few worms, then perform the bleach step for 15-30 seconds less in each two-minute shake.

- 34. During your last spin, fill a disposable reagent trough with K medium (see recipes) and change out the pipette tips.
- 35. Using the 12-channel 300 μ L pipette, add 400 μ L of K medium to all wells. If you are concerned that your titers will be too low (due to over bleaching or poorly grown animals), resuspend in a final volume of 300 μ L K medium.
- 36. Calculate the titer of embryos by resuspending the embryos using the Eppendorf Xplorer 12-channel repeat pipetter. Use the mix function to mix 100 μ l x5 three times. Then pipette 10 μ l onto the bottom of a 96-well plate to count the number of embryos.
 - For dose responses, count the embryos from each strain (N2, CB4856, DL238, JU258) twice.
 - For heritabilities, count the embryos from one row of the plate that is not row H (the wash row).
 - For GWAS or RIAILs mappings, count the embryos from two or three rows.
- 37. After calculating the titer, dilute so that there are approximately 20-60 embryos per 10 μ l. There will certainly be variation across the strains. Try to maximize the number that will fall in the ideal range while minimizing the number that would fall outside of that range. Use the mix function again to check your titers before pipetting into your assay plates.
- 38. Pipette the amount of embryo solution to get to about 25-50 animals from each well of the deep-well plate into the number of tissue-culture treated 96-well flat-bottom plates that are needed for your assay. Usually, 10 μ L of embryo solution works well. Use the Eppendorf Xplorer 12-channel repeat pipetter to speed up the process and decrease repetitive strain. Remember to mix each row three times before aspirating and dispensing to tissue-culture plates. Use the 12-channel pipet set to 100 μ L to mix.
 - Transfer the embryos from the well of the deep 96-well plate to the corresponding well of the flatbottom 96-well plate (e.g. embryos from well A1 of the deep-well plate should only be pipetted into well A1 of the flat-bottom plates)
 - Use a piece of foil across the deep-well plate to keep track of where you have pipetted. Remove distractions to limit losing your place and to decrease confusion.
- 39. Add K medium to bring the volume of each well up to 50 µL.
- 40. Seal all 96-well plates with Rayon gas permeable strip (Fisher cat #14-222-043). Try to avoid wrinkles in the Rayon strip.
- 41. Shake overnight at 180 rpm at 20°C on the Excella E24R shaker in a freshly made humidity chamber.
 - To make a humidity chamber, place damp paper towels in a clean (bleached and rinsed) plastic box, close the box, and seal all around the top lid edge with parafilm.
- 42. The deep-well plates can be reused. After completing the entire bleach process/aliquoting the embryos, dump liquid down sink, add some 50% Clorox bleach to each well of the deep well plate, shake on the microplane vortex for 2-3 minutes, then wash 3-5 times with water. Dry them overnight, then wrap with tin foil and autoclave. We reuse them 5 times, so put a tick mark on the side after each use. The sealing mats can also be reused. Wash them simultaneously with the deep-well plates. Mark with a tick. Wrap in tin foil and autoclave. The mats can be reused five times.

- The deep well plates MUST be dumped down the sink immediately after aliquoting embryos.
 We have found that otherwise the embryos stick to the bottom of the plate and become impossible to clean out.
- 43. Also after completing the aliquoting process, rinse the Pasteur pipettes 3-5 times with water, blot on a paper towel and let them dry before autoclaving again for reuse.
- 44. At the end of the day, remember to: (1) charge the automatic pipette dispenser, (2) wash out the deep-well plate and sealing mat as described above, (3) check that the deep-well plate and sealing mat are still within five uses and throw them out if old, (4) clean out the 96-well aspirator by aspirating a tip box lid filled with distilled water two times and 95% ethanol one time, (5) and make sure the vacuum line is off, (6) clean out the pasteur pipettes as described above, and (7) aliquot using an autoclaved spatula 100 mg of powdered lysate to as many autoclaved microfuge tubes as you will need for the entire feeding of L1s and set up of drug plates. Typical assays require 10-20 tubes of 100 mg of aliquoted lysate (see recipe to calculate exactly how much you will need). Please wear gloves and be very careful with the lysate in the stock bottle. Contamination affects everyone!

Feeding

- We feed plates one day after bleaching, as long as the L1 larvae hatched.
- We feed each plate at the same time of day we plan on sorting the worms 48 hours later. If your sorting will start early in the morning Thursday/Friday, you must feed early on Tuesday/ Wednesday.
- 45. The next morning after bleaching, check one or two plates that were aliquoted the previous day. Check for successful hatching of L1 larvae. If there was successful hatching, continue with protocol. If not, contact Erik.
- 46. Make food from bacterial lysate (final concentration 50 mg/mL). The recipe is located at the bottom of this protocol. You must feed worms around the same time you will run the plates on the sorter two days later. If you're running many plates, start making food early in the morning.
- 47. Start with one or two plates. Add 5 μ L of lysate food to every well that has worms in it. Make sure to resuspend the bacteria before you add it to the plates! Feed a plate every 25 minutes through the day. Use a timer to make sure you don't forget and lose time. If your day is busy, you can feed two plates every fifty minutes.
 - Ensure that the bacterial food is mixed into each well. Every well should look cloudy. It is easiest to see when you look at the wells above a black background. To ensure the food droplet fully gets into the well, spin in the clinical centrifuge (use a blank balance) for two seconds using a short spin.
- 48. Seal with Rayon gas permeable strip, and label the plate top with the plate number and time that you added the food solution. Put the plates back in the humidity chamber once they are fed. When done for the day, make sure your paper towels are still damp and parafilm the box shut.
- 49. Shake for 48 hours at 180 rpm at 20°C on the Excella E24R shaker.

Sorting/Scoring

- To prevent contamination, change pipette tips often when setting up plates.
- Turn on the HEPA air filter across the bay from the bench where you set up your plates
- 50. You must sterilize the sorter before use. This is usually done the Wednesday before sorting. Follow the separate sterilization protocol in the red binder by the sorter starting at step four.
- 51. Two days after feeding you will sort your worms. Before making target plates, clean the bench to reduce contamination of wells. Wear a lab coat and start by spraying 10% bleach across the bench. Wipe away the bleach in one direction and then toss the towels. Use the cheap paper towels by the sink for these cleaning steps.
- 52. Next, spray the pipets you will use with 70% ethanol on the bench and wipe them down.
- 53. Then, spray the entire bench with 70% ethanol and wipe away ethanol with paper towels in one direction.
- 54. Repeat these steps on the sorter bench area too.
- 55. Make up 10 mg/mL bacterial lysate (as described in RECIPES) in a 50 mL or 150 mL conical, depending on how much you need.
- 56. Add kanamycin to the 10 mg/mL bacterial lysate mix. Kanamycin final concentration should be 50 μ M. That is a 1:1600 dilution of our 80 mM stock or 6.25 μ L per 10 mL of solution.
- 57. Get fresh ddH₂O and/or DMSO for standardizing solvent conditions. Use double distilled water fresh from the distiller in the Lamb autoclave room. Decant into a 2 mL tube. Pipet from the DMSO stock bottle into a new 2 mL tube. Label the tubes for the solvent inside.
- 58. Organize the area. Get 96-well plates from the consumables bench for the assay. Get troughs for pipetting solution to the wells. Make sure you have M9 with 0.1 mg/mL FUdR for wash wells. Take out tubes of drugs from -20°C or 4°C storage (cold room by Morimoto lab).
- 59. Look at the drug preparation sheets to figure out what volume conical or tube you need to set up the plates for the assay. For mappings, NIL tests, heritabilities, etc., we use a single drug for an entire plate. 15 mL conicals are good for this volume. For dose responses, you will use 1.7 mL posi-click tubes, one per concentration/five tubes per plate.
- 60. Pipet the 10 mg/mL lysate into the 15 mL conical or 1.7 mL tubes, as dictated by the set up sheet.
- 61. Add DMSO or water solvent, as dictated by the set up sheet.
- 62. Add drug, as dictated by the set up sheet.
- 63. Cap conical and vortex for five seconds to mix.

- 64. Decant into a one-time-use trough (USA Scientific, #1346-1010). For dose responses, pipette 600 μ L into 12-channel reservoirs. Each tube should be pipetted into two separate troughs.
- 65. Using a 12-channel pipet, pipet 50 μ L of drug solution into each well of the 96-well plate needed for the assay.
- 66. Pipet 50 μ L of wash solution (M9 with 0.1 mg/mL FUdR) into each wash well. For dose responses, pipette 600 μ L FUdR into the wash well channel of the reservoir before setting up plates.
- 67. Label the plate with the plate number, drug name, and solvent name.
- 68. Put the plate into a temporary humidity chamber box. Temporary humidity chambers are plastic shoe boxes bleached and ethanol cleaned before use. Add about 10 paper towels from near the sink to the box and put in distilled water from the tap until they are very damp.
- 69. Throughout the day of using the sorter, make sure that the Whirpool Whispure 510 HEPA air filter is running. This cleaning prevents contamination of the plates by the sorter.
- 70. Before sorting add M9 (no azide!!!) to bring the final volume up to 250 μ L. Typical assays have 50 μ L of L4 worms, lysate, and K medium, so add 200 μ L of M9 before sorting. If you forget, the sorter will fill with bubbles and won't sort accurately. In which case. Run two full rows of 300 μ L water in each well.
- 71. Once all target plates are setup, turn on the sorter (follow other document on sorter use, found on Dropbox, called Andersen Sorter Protocols). Use program USE_for_L4 dispense.csv (or other appropriate .csv file) on the sorter to sort three L4s per well from each setup plate to each assay plate for scoring dose responses or mappings. Use the program USE_for_L4 dispense_columns.csv on the sorter to sort L4s from each setup plate to one assay plate for columnar formats. I recommend starting up the sorter while you are cleaning the bench and preparing the target plates. With practice, they can be done at the same time.
 - •NOTE: You have to make a new save file for each plate sorting/scored. Please read the naming convention rules at the end of this document.
- 72. Throughout the day of using the sorter, keep a close eye on the level of the sheath fluid in the sheath bottle. Do not allow it to use up more than 10% of the total volume. This means that every 3-4 plates you need to depressurize the sheath bottle, remove the top, add in the amount of M9 that was used, put the top back on, and re-pressurize the bottle. Do this continually throughout the day to maintain a constant pressure within the sheath bottle, leading to constant flow rate through the flow cell.
- 73. Also throughout the day of using the sorter, count the number of sorted animals using a flashlight and write on the plate lid the number sorted. After that plate is completed, count the number of L4 animals in the well to confirm that the sorter is working correctly.
- 74. After counting L4s for each strain, seal the target plate with gas-permeable Rayon strip (Axygen, cat#14-222-043 from Fisher). Make sure the edges are sealed and press hard onto all wells.
- 75. Put the finished and sealed plates in a long-term humidity chamber. Long-term humidity chambers are plastic shoe boxes bleached and ethanol cleaned before use. Add about eight C-fold paper towels

from near the sorter to the box and put in distilled water from the tap. Make sure this box is very damp. Label the box with the assay name and score date.

- 76. After the last plate of the day, wrap the long-term humidity chamber with parafilm. Take care to wrap no more than 10 cm on the top of the box. Most of the parafilm should be on the bottom part of the box.
- 77. Shake for 96 hours at 180 rpm at 20°C on the Excella E24R shaker in a humidity chamber. Make sure that during these four days, the boxes are completely sealed with parafilm and the paper towels inside are very damp. This will prevent excessive evaporation. Evaporation will decrease the volume in the wells of the plates, which can create problems with the sorter. Check the boxes during the four days if necessary.
- 78. When scoring plates, use program USE_for_analysis.csv (or other appropriate CSV file) on the sorter and without bubble trap. Be sure that the plate format is correct, depending on what assay you are running and the orientation of the strains.
- 79. If you are testing pharyngeal pumping, before scoring, be sure to make a solution of bacterial lysate and red fluorescent microspheres. This solution is 1 mg/mL lysate, and a 1:50 dilution of 0.5 μ M microspheres (Polysciences, cat. # 19507-5). The beads are stored in the undercounter refrigerator. Add 5 μ L of this solution to each well that has worms on the plate to be scored, and incubate while shaking at 20°C, 180 rpm, for five minutes. After five minutes, add 200 μ L of M9 with 50 mM sodium azide to stop feeding and straighten the worms. M9 with 50mM sodium azide can be made by adding 3.25 grams of sodium azide per liter of M9.
- 80. If you are not testing pharyngeal pumping, just add 200 μ L of M9 with 50 mM sodium azide to each well before scoring.
- 81. Make sure that any M9 used in the wells for sorting, scoring, or put in the sheath bottle have been made, filtered (Thermo Filter Unit, Cat #166-0045), autoclaved, and cooled to room temperature before using ahead of time.
- 82. Throughout the day of using the sorter, keep a close eye on the level of the sheath fluid in the sheath bottle. Do not allow it to use up more than 10% of the total volume. This means that every 3-4 plates you need to depressurize the sheath bottle, remove the top, add in the amount of M9 that was used, put the top back on, and pressurize the bottle. Do this continually throughout the day to maintain a constant pressure within the sheath bottle, leading to constant flow rate through the flow cell.

NOTE: When using the sorter, either for sorting or scoring, you MUST keep a close eye on it. It is a temperamental machine, and frequently has various problems. If you have to go to the bathroom, check email, go to lunch, etc., please find someone else to watch it. It CAN NOT be left alone. Read the documents the lab has in the Protocols folder in the AndersenLab DropBox about the sorter (AndersenSorterProtocols, SorterBestPractices) to familiarize yourself with the sorter, and its problems, and how to deal with them. Before taking on the sorter yourself, watch Erik or Robyn work with it to see how it works.

RECIPES

K medium:

Per 500 mL: 51 mM NaCl (**5.1 mL of 5 M NaCl**) 32 mM KCl (**16 mL of 1 M KCl**) 3 mM CaCl₂ (**1.5 mL of 1 M CaCl2**) 3 mM MgSO₄ (**1.5 mL of 1 M MgSO4**)

We keep a separate set of salts to only use for sorter experiments. Pour yourself as much as you need of into 50 mL conicals, then pipette into a graduated cylinder. Mix the four salts with increasing water, then fill to 500 mL of dH₂O.

Filter sterilize with Thermo Filter Unit (Cat #566-0020)

Add 1.25 µg/mL unfiltered cholesterol (125 µL of 5 mg/mL cholesterol) after filtering

Mix, label, and store for up to two weeks. Be sure to check the K medium prior to use for any floating particulate, which is a sign of contamination. If K medium is contaminated, pour it down the drain and make new K medium. Record which batch you used of each reagent (date/initials) in your lab notebook; this way we can quickly figure out if a batch of something has gone bad.

Bacterial Lysate:

- 1. Wearing gloves, weigh out 100 mg bacterial lysate into autoclaved tubes using a clean spatula (wipe with ethanol before use). For feeding L1 larvae, each tube will make ~2 mLs lysate solution. For setting up assay plates, each tube will make ~10 mLs of lysate solution.
- 2. Shortly vortex tubes of 100 mg bacterial lysate and add 650 µL of K medium to each tube
- 3. Vortex for 60 seconds, making sure that all lysate goes into suspension. If it doesn't go in easily, try running the microfuge tube along the length of a tube rack a few times and vortexing more. If you have many tubes to prepare, put the completed tubes shaking on the plate vortexer.
- 4. Add 300 μL K medium.
- 5. Vortex 30 seconds. Like above, if you have many tubes to prepare, put the completed tubes shaking on the plate vortexer.
- 6. Spin down in the microfuge for 30 seconds at 5000 rpm.
- 7. Pipette \sim 980 μ L of the lysate solution into a 15 mL conical or 150 mL conical, depending on whether you are setting up feeds or assays. Be careful not to disturb the lysate pellet. Chunks of lysate will cause more lysate clumping.
- 8. For every tube of lysate used initially, add 1 mL of K medium (to get to a 50 mg/mL concentration) for days with feeding L1 larvae. For assay set up, you will add 9 mL K medium for every 1 mL of 100 mg/mL lysate. The final concentration is 10 mg/mL lysate.
- 9. Add kanamycin. For feed days add 62.5 μ L of 80 mM kan per 10 mLs of solution. For assay setup days, add 6.25 μ L of 80 mM kan per 10 mLs of solution.
- 10. Vortex to resuspend before pipetting into wells.
- 11. Record which bottle of lysate you used, as well as which batch of Kanamycin in your lab notebook.

Bleach Solution:

Per 200 mL:

40 mL NaOCI (in the cold room, from Fisher, cat #SS290-1), add \sim 100 mL ddH₂O 10 mL of freshly made 10 M NaOH (add 4g NaOH pellets to 10 mL of ddH₂O), add some ddH₂O Add ddH₂O up to 200 mL

Mix well, store at 4°C (undercounter fridge #1) until needed. This bleach should be made four days before use. If you make is earlier or later, you much adjust the bleaching time for stronger or weaker bleach, respectively. Throw out old bottles of bleach in the fridge as necessary.

Sorter File Naming Conventions:

There are four components to naming a file on the sorter for the current data analysis pipeline. The general outline looks like: **pXX strains condition control**

pXX corresponds to the plate number. Plate 1 should be p01. Plate 21 should be p21. **strains** corresponds to the strains that you set up in the deep-well plate (and subsequent 96-well plates). This area will be titled whatever this assay is called. Example: McGrathRILs1a, NILsTest4b, etc. **condition** corresponds to the condition in each individual plate. abamectin, DMSO, copper, and tunicmycin would all be examples of conditions.

control is the appropriate control for the condition. DMSO, None, water, and DMSO (respectively) are the associated controls for the conditions listed above.

Standard Sorter Assay Calendar

Sunday	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	
			A - chunk strains	B - chunk strains	A - clean strains	A - pick L1s B - clean strains	
B - pick L1s	A - pick G1	B - pick G1		A - pick G2	B - pick G2		
A - pick G3	B - pick G3			A - pick G4 - make bleach	B - pick G4 - make bleach A/B - make K media		
A - move strains to room temp	A - bleach B - move strains to room temp	B - bleach A - feed	A/B - sterilize the sorter B - feed	A - sort L4s	B - sort L4s		
	A - score	B - score					

Conical Bleaching and Synchronization:

- 1. Four days after picking your generation four worms, check to see that they are staged properly for bleaching. You want there to be maximal number of gravid adults without starvation.
- 2. Sterilize your bench top with bleach and ethanol. Take your bleach solution made four days prior out of the fridge about a half hour before use.
- 3. Wash worms off plates into a 15 ml conical tube. You can squirt M9 onto one plate of Strain A, transfer the liquid to another plate of strain A, etc. Wash all plates from a single strain into one 15 ml conical tube. It is easy to pour from the final 6 cm plate into the 15 mL conical with a little bit of practice. We typically pour two mLs of M9 onto one plate, and transfer the same solution to four other plates before pouring it into the conical. Repeat for all strains.
- 4. Spin down worms at 1100 rpm for 1 minute using the table-top clinical centrifuge.
- 5. Aspirate off the M9, being careful to not suck up any of your worms.
- 6. Add 7 mL of bleaching solution to each 15 mL conical. The freshness of the bleach solution matters. Ineffective bleaching solution (kept at 4°C longer than one month or kept at room temp for longer than eight hours) will require more time to bleach worms and will not dissolve the worms uniformly. Shake the tubes manually, use a nutator, or use the plate vortex if you have many strains. You can bleach multiple strains at the same time, but depending on experience you may want to start with only doing 4-5 at once.
- 7. After four minutes of shaking, check to see if the adult worms are dissolved every minute until complete. Be very careful not to over bleach the worms. Once you see that the carcasses are nearly dissolved, move to the next step. If there are only embryos left, then you have gone too long.
- 8. Once there are just a few adults remaining, **move quickly** to spin down the embryos at 1100 rpm for 30 seconds. It is best to have the reagents next to the sink and prepared for the next few steps. Some table-top centrifuges do not have an option of 30 seconds, so you must stop the centrifuge manually after 30 seconds. If you feel you have under-bleached your worms, you may let them spin down for a full minute.
- 9. **Immediately** decant off the bleach into the sink or aspirate it out carefully and quickly without disturbing the worm pellet.
- 10. Add 10 ml of M9 using a sterile glass pipette or pouring from a 50 mL conical to each 15 mL conical tube.
- 11. Invert three times as you walk back to the clinical centrifuge.
- 12. Spin down the embryos at 1100 rpm for 30 seconds.
- 13. Decant off the M9 into the sink or aspirate carefully and quickly without disturbing the worm pellet.

- 14. Repeat steps 10-13 two more times.
- 15. After the third M9 wash, resuspend the embryos in 2 mL of K medium.
- 16. Determine the titer of the embryos by counting the number of embryos in 5 μ l. Adjust the resuspension liquid to obtain the desired concentration (*e.g.* 0.5 1 embryo per μ l).
- 17. Return to step 38 in the HTA protocol. Vortex each 15 mL conical of embryos for at least five seconds before pouring into single channel reservoir. Either pipette immediately or use the mix function before pipetting into assay plates.

Plate setup: Dose responses



Where each column is a different, increasing concentration in each six-column block. One drug per plate, wash between each strain. Strains are rotated to decrease plate effect. (Each letter denotes a different strain, each color denotes a different treatment, with increasing font size corresponding to concentration)

Heritability

Α	В	С	D	Е	F	G	Н	1	J	K	L
Α	В	С	D	Е	F	G	Н	1	J	K	L
Α	В	С	D	Е	F	G	Н	I	J	K	L
Α	В	С	D	Е	F	G	Н	I	J	K	L
Α	В	С	D	Е	F	G	Н	I	J	K	L
Α	В	С	D	Е	F	G	Н	1	J	K	L
Α	В	С	D	Е	F	G	Н	I	J	K	L
Wash											

Where each column is a different strain, and the whole plate has the same concentration of a single drug.

Mapping

A	Wash										
A	Wash	A	Wash	A	Wash	A	Wash	Α	Wash	A	Wash
В	Wash										
В	Wash										
С	Wash										
С	Wash										
D	Wash										
D	Wash										

Where every two rows is a separate strain and each position in every two row block contains a different drug. (Each letter denotes a different strain, each color denotes a different treatment)