#### **Table of Contents**

1.	What is the NMEA 0183 Standard? pa	age 1
2.	Electrical Interface	2
3.	General Sentence Format	2
	Talker Identifiers	
5.	Sentence Identifiers and Sentence Formats	4
	Some Proprietary Sentences	
	Manufacturer Codes	
	References	

The material presented in this document has been compiled from various inofficial sources. It is neither a complete nor error-free description of the NMEA 0183 standard. In particular, it does not cover the new sentences and the high-speed interface defined in version 3.x.

Klaus Betke, May 2000. Revised August 2001.

# 1. What is the NMEA 0183 Standard?

The National Marine Electronics Association (NMEA) is a non-profit association of manufacturers, distributors, dealers, educational institutions, and others interested in peripheral marine electronics occupations. The NMEA 0183 standard defines an electrical interface and data protocol for communications between marine instrumentation.

NMEA 0183 is a voluntary industry standard, first released in March of 1983. It has been updated from time to time; the latest release, currently (August 2001) Version 3.0, July 2001, is available from the NMEA office (Warning: the price for non-members is 250 US\$).

P O Box 3435 New Bern NC 28564-3435 USA www.nmea.org

NMEA has also established a working group to develop a new standard for data communications among shipboard electronic devices. The new standard, NMEA 2000, is a bi-directional, multi-transmitter, multi-receiver serial data network. It is multi-master and self-configuring, and there is no central controller. The NMEA began a beta testing period in January 2000 with eleven manufacturers. A release version of NMEA 2000 is expected in 2001.

#### 2. Electrical Interface

NMEA 0183 devices are designated as either *talkers* or *listeners* (with some devices being both), employing an asynchronous serial interface with the following parameters:

Baud rate: 4800

Number of data bits: 8 (bit 7 is 0)
Stop bits: 1 (or more)
Parity: none
Handshake: none

NMEA 0183 allows a single talker and several listeners on one circuit. The recommended interconnect wiring is a shielded twisted pair, with the shield grounded only at the talker. The standard dos not specify the use of a particular connector. Note: The new 0183-HS standard (HS = high speed) introduced in version 3.0 uses a 3-wire interface and a baud rate of 38400. This type of interface is not discussed here.

Its is recommended that the talker output comply with EIA RS-422, a differential system with two signal lines, "A" and "B". Differential drive signals have no reference to ground and are more immune to noise. However, a single-ended line at TTL level is accepted as well. The voltages on the A line correspond to those on the TTL single wire, while the B voltages are inverted (when output A is at +5 V, output B is at 0 V, and vice versa. This is the unipolar RS-422 operation. In bipolar mode ±5 V are used).

In either case, the recommended receive circuit uses an opto-isolator with suitable protection circuitry. The input should be isolated from the receiver's ground. In practice, the single wire, or the RS-422 "A" wire may be directly connected to a computer's RS-232 input. In fact even many of the latest products, like hand-held GPS receivers, do not have a RS-422 differential output, but just a single line with TTL or 5 V CMOS compatible signal level.

#### 3. General Sentence Format

All data is transmitted in the form of *sentences*. Only printable ASCII characters are allowed, plus CR (carriage return) and LF (line feed). Each sentence starts with a "\$" sign and ends with <CR><LF>. There are three basic kinds of sentences: *talker sentences*, *proprietary sentences* and *query sentences*.

Talker Sentences. The general format for a talker sentence is:

```
$ttsss,d1,d2,....<CR><LF>
```

The first two letters following the "\$" are the *talker identifier*. The next three characters (sss) are the *sentence identifier*, followed by a number of *data fields* separated by commas, followed by an optional *checksum*, and terminated by carriage return/line feed. The data fields are uniquely defined for each sentence type. An example talker sentence is:

```
$HCHDM, 238, M<CR><LF>
```

where "HC" specifies the talker as being a magnetic compass, the "HDM" specifies the magnetic heading message follows. The "238" is the heading value, and "M" designates the heading value as magnetic.

A sentence may contain up to 80 characters plus "\$" and CR/LF. If data for a field is not available, the field is omitted, but the delimiting commas are still sent, with no space between them. The checksum field consists of a "\*" and two hex digits representing the exclusive OR of all characters between, but not including, the "\$" and "\*".

**Proprietary Sentences.** The standard allows individual manufacturers to define *proprietary sentence formats*. These sentences start with "\$P", then a 3 letter manufacturer ID, followed by whatever data the manufacturer wishes, following the general format of the standard sentences. Some proprietary sentences, mainly from Garmin, Inc., are listed in chapter 6.

**Query sentences.** A query sentence is a means for a listener to request a particular sentence from a talker. The general format is:

```
$ttllQ,sss,[CR][LF]
```

The first two characters of the address field are the talker identifier of the requester and the next two characters are the talker identifier of the device being queried (listener). The fifth character is always a "Q" defining the message as a query. The next field (sss) contains the three letter mnemonic of the sentence being requested. An example query sentence is:

```
$CCGPQ,GGA<CR><LF>
```

where the "CC" device (computer) is requesting from the "GP" device (a GPS unit) the "GGA" sentence. The GPS will then transmit this sentence once per second until a different query is requested.

#### 4. Talker Identifiers

ZQ

ΖV

Timekeeper – Quartz

AG Autopilot - General AΡ Autopilot - Magnetic CD Communications – Digital Selective Calling (DSC) Communications - Receiver / Beacon Receiver CR CS Communications - Satellite CT Communications – Radio-Telephone (MF/HF) CV Communications - Radio-Telephone (VHF) CX Communications - Scanning Receiver DF Direction Finder EC Electronic Chart Display & Information System (ECDIS) ΕP Emergency Position Indicating Beacon (EPIRB) ER **Engine Room Monitoring Systems** GP Global Positioning System (GPS) HC Heading - Magnetic Compass HE Heading - North Seeking Gyro HN Heading - Non North Seeking Gyro Ш Integrated Instrumentation IN Integrated Navigation LC Loran C Р Proprietary Code RA RADAR and/or ARPA SD Sounder, Depth SN Electronic Positioning System, other/general SS Sounder, Scanning ΤI Turn Rate Indicator Velocity Sensor, Doppler, other/general VD DM Velocity Sensor, Speed Log, Water, Magnetic VW Velocity Sensor, Speed Log, Water, Mechanical WI Weather Instruments ΥX Transducer ZΑ Timekeeper – Atomic Clock Timekeeper – Chronometer ZC

Timekeeper - Radio Update, WWV or WWVH

# 5. Sentence Identifiers and Formats

### **AAM** Waypoint Arrival Alarm


1 2 3 4 5 6 | | | | | | | \$--AAM,A,A,x.x,N,c--c\*hh

- 1) Status, BOOLEAN, A = Arrival circle entered
- 2) Status, BOOLEAN, A = perpendicular passed at waypoint
- 3) Arrival circle radius
- 4) Units of radius, nautical miles
- 5) Waypoint ID
- 6) Checksum

#### ALM GPS Almanac Data

- 1) Total number of messages
- 2) Message Number
- 3) Satellite PRN number (01 to 32)
- 4) GPS Week Number: Date and time in GPS is computed as number of weeks from 6 January 1980 plus number of seconds into the week.
- 5) SV health, bits 17-24 of each almanac page
- 6) Eccentricity
- 7) Almanac Reference Time
- 8) Inclination Angle
- 9) Rate of Right Ascension
- 10) Root of semi-major axis
- 11) Argument of perigee
- 12) Longitude of ascension node
- 13) Mean anomaly
- 14) FO Clock Parameter
- 15) F1 Clock Parameter
- 16) Checksum

## APA Autopilot Sentence "A"



- 1) Status
  - V = LORAN-C Blink or SNR warning
  - ${\tt A} = {\tt general}$  warning flag or other navigation systems when a reliable fix is not available
- 2) Status
  - V = Loran-C Cycle Lock warning flag
  - A = OK or not used
- 3) Cross Track Error Magnitude
- 4) Direction to steer, L or R
- 5) Cross Track Units (Nautic miles or kilometres)
- 6) Status
  - A = Arrival Circle Entered
- 7) Status
  - A = Perpendicular passed at waypoint
- 8) Bearing origin to destination
- 9) M = Magnetic, T = True
- 10) Destination Waypoint ID
- 11) checksum

#### APB Autopilot Sentence "B"

1) Status

V = LORAN-C Blink or SNR warning

A = general warning flag or other navigation systems when a reliable fix is not available

2) Status

V = Loran-C Cycle Lock warning flag

A = OK or not used

- 3) Cross Track Error Magnitude
- 4) Direction to steer, L or R
- 5) Cross Track Units, N = Nautical Miles
- 6) Status


A = Arrival Circle Entered

- 7) Status
  - A = Perpendicular passed at waypoint
- 8) Bearing origin to destination
- 9) M = Magnetic, T = True
- 10) Destination Waypoint ID
- 11) Bearing, present position to Destination
- 12) M = Magnetic, T = True
- 13) Heading to steer to destination waypoint
- 14) M = Magnetic, T = True
- 15) Checksum

#### ASD Autopilot System Data

Format unknown

## BEC Bearing & Distance to Waypoint - Dead Reckoning



- 1) Time (UTC)
- 2) Waypoint Latitude
- 3) N = North, S = South
- 4) Waypoint Longitude
- 5) E = East, W = West
- 6) Bearing, True
- 7) T = True
- 8) Bearing, Magnetic
- 9) M = Magnetic
- 10) Nautical Miles
- 11) N = Nautical Miles
- 12) Waypoint ID
- 13) Checksum

#### **BOD Bearing – Waypoint to Waypoint**

2 3 4 5 6 \$--BOD,x.x,T,x.x,M,c--c,c--c\*hh

- 1) Bearing Degrees, TRUE
- 2) T = True
- 3) Bearing Degrees, Magnetic
- 4) M = Magnetic
- 5) TO Waypoint
- 6) FROM Waypoint
- 7) Checksum

#### **BWC** Bearing and Distance to Waypoint - Latitude, N/S, Longitude, E/W, UTC, Status

```
7 8
      1
               2
                      3 4
                                5 6
                                           9 10 | 12
                                                       13
                                    İ
                      \$--BWC, hhmmss.ss, \verb|lll.ll,a,yyyyy.yy,a,x.x,T,x.x,M,x.x,N,c--c*hh|
```


- 1) Time (UTC)
- 2) Waypoint Latitude
- 3) N = North, S = South
- 4) Waypoint Longitude
- 5) E = East, W = West
- 6) Bearing, True
- 7) T = True
- 8) Bearing, Magnetic
- 9) M = Magnetic
- 10) Nautical Miles
- 11) N = Nautical Miles
- 12) Waypoint ID
- 13) Checksum

#### Bearing and Distance to Waypoint - Rhumb Line Latitude, N/S, Longitude, E/W, **BWR UTC, Status**

```
11
                     3 4
                              5 6
                                   7 8
                                        9 10 | 12
                                                   13
                     \$--BWR, hhmmss.ss, \verb|lll.ll,a,yyyyy.yy,a,x.x,T,x.x,M,x.x,N,c--c*hh|
```

- 1) Time (UTC)
- 2) Waypoint Latitude
- 3) N = North, S = South
- 4) Waypoint Longitude
- 5) E = East, W = West
- 6) Bearing, True
- 7) T = True
- 8) Bearing, Magnetic
- 9) M = Magnetic
- 10) Nautical Miles
- 11) N = Nautical Miles
- 12) Waypoint ID
- 13) Checksum

# **BWW** Bearing – Waypoint to Waypoint



- 1) Bearing Degrees, TRUE
- 2) T = True
- 3) Bearing Degrees, Magnetic
- 4) M = Magnetic
- 5) TO Waypoint
- 6) FROM Waypoint
- 7) Checksum

# **DBK** Depth Below Keel

- 1) Depth, feet
- 2) f = feet
- 3) Depth, meters
- 4) M = meters
- 5) Depth, Fathoms
- 6) F = Fathoms
- 7) Checksum

# **DBS** Depth Below Surface

- 1) Depth, feet
- 2) f = feet
- 3) Depth, meters
- 4) M = meters
- 5) Depth, Fathoms
- 6) F = Fathoms
- 7) Checksum


# **DBT** Depth Below Transducer

- 1) Depth, feet
- 2) f = feet
- 3) Depth, meters
- 4) M = meters
- 5) Depth, Fathoms
- 6) F = Fathoms
- 7) Checksum

# **DCN** Decca Position

obsolete

# **DPT** Heading – Deviation & Variation



- 1) Depth, meters
- 2) Offset from transducer; positive means distance from transducer to water line, negative means distance from transducer to keel
- 3) Checksum

# **DSC** Digital Selective Calling Information

Format unknown

#### DSE Extended DSC

Format unknown

#### **DSI DSC** Transponder Initiate

Format unknown

# **DSR** DSC Transponder Response

Format unknown

#### **DTM** Datum Reference

Format unknown

# FSI Frequency Set Information

- 1) Transmitting Frequency
- 2) Receiving Frequency
- 3) Communications Mode (NMEA Syntax 2)
- 4) Power Level
- 5) Checksum

# GBS GPS Satellite Fault Detection

Format unknown


# GGA Global Positioning System Fix Data. Time, Position and fix related data for a GPS receiver

- 1) Time (UTC)
- 2) Latitude
- 3) N or S (North or South)
- 4) Longitude
- 5) E or W (East or West)
- 6) GPS Quality Indicator,
  - 0 fix not available,
  - 1 GPS fix,
  - 2 Differential GPS fix
- 7) Number of satellites in view, 00 12
- 8) Horizontal Dilution of precision
- 9) Antenna Altitude above/below mean-sea-level (geoid)
- 10) Units of antenna altitude, meters
- 11) Geoidal separation, the difference between the WGS-84 earth ellipsoid and mean-sea-level (geoid), "-" means mean-sea-level below ellipsoid
- 12) Units of geoidal separation, meters
- 13) Age of differential GPS data, time in seconds since last SC104 type 1 or 9 update, null field when DGPS is not used
- 14) Differential reference station ID, 0000-1023
- 15) Checksum

# GLC Geographic Position, Loran-C

- 1) GRI Microseconds/10
- 2) Master TOA Microseconds
- 3) Master TOA Signal Status
- 4) Time Difference 1 Microseconds
- 5) Time Difference 1 Signal Status
- 6) Time Difference 2 Microseconds
- 7) Time Difference 2 Signal Status
- 8) Time Difference 3 Microseconds
- 9) Time Difference 3 Signal Status
- 10) Time Difference 4 Microseconds
- 11) Time Difference 4 Signal Status
- 12) Time Difference 5 Microseconds
- 13) Time Difference 5 Signal Status
- 14) Checksum

#### **GLL** Geographic Position – Latitude/Longitude



- 1) Latitude
- 2) N or S (North or South)
- 3) Longitude
- 4) E or W (East or West)
- 5) Time (UTC)
- 6) Status A Data Valid, V Data Invalid
- 7) Checksum

# GRS GPS Range Residuals

Format unknown

#### **GST** GPS Pseudorange Noise Statistics

Format unknown

#### GSA GPS DOP and active satellites

- 1) Selection mode
- 2) Mode
- 3) ID of 1st satellite used for fix
- 4) ID of 2nd satellite used for fix

. . .

- 14) ID of 12th satellite used for fix
- 15) PDOP in meters
- 16) HDOP in meters
- 17) VDOP in meters
- 18) Checksum

#### GSV Satellites in view

- 1) total number of messages
- 2) message number
- 3) satellites in view
- 4) satellite number
- 5) elevation in degrees
- 6) azimuth in degrees to true
- 7) SNR in dB

more satellite infos like 4)-7)

n) Checksum

# GTD Geographic Location in Time Differences

- 1) time difference
- 2) time difference
- 3) time difference
- 4) time difference
- 5) time difference
- n) Checksum

# GXA TRANSIT Position – Latitude/Longitude, Location and Time of TRANSIT Fix at Waypoint

obsolete

# **HDG** Heading – Deviation & Variation

- 1) Magnetic Sensor heading in degrees
- 2) Magnetic Deviation, degrees
- 3) Magnetic Deviation direction, E = Easterly, W = Westerly
- 4) Magnetic Variation degrees
- 5) Magnetic Variation direction, E = Easterly, W = Westerly
- 6) Checksum

# **HDM** Heading – Magnetic

- 1) Heading Degrees, magnetic
- 2) M = magnetic
- 3) Checksum

# **HDT** Heading – True

- 1) Heading Degrees, true
- 2) T = True
- 3) Checksum

#### **HSC** Heading Steering Command

- 1) Heading Degrees, True
- 2) T = True
- 3) Heading Degrees, Magnetic
- 4) M = Magnetic
- 5) Checksum

#### **Loran-C Signal Data** LCD

5 6 7 8 9 10 11 12 13 14 

- 1) GRI Microseconds/10
- 2) Master Relative SNR
- 3) Master Relative ECD
- 4) Time Difference 1 Microseconds
- 5) Time Difference 1 Signal Status
- 6) Time Difference 2 Microseconds
- 7) Time Difference 2 Signal Status
- 8) Time Difference 3 Microseconds
- 9) Time Difference 3 Signal Status
- 10) Time Difference 4 Microseconds
- 11) Time Difference 4 Signal Status 12) Time Difference 5 Microseconds
- 13) Time Difference 5 Signal Status
- 14) Checksum

#### MSK MSK Receiver Interface (for DGPS Beacon Receivers)

1 2 3 4 5 6 

\$GPMSK,xxx.x,xx,xxx,xx,N\*hh

- 1) Frequency in kHz (283.5 to 325.0)
- 2) Frequency Selection

M1 = Manual

A1 = Automatic (field 1 empty)

- 3) MSK bit rate (100 or 200)
- 4) Bit Rate Selection

M2 = Manual

A2 = Automatic (field 3 empty)

- 5) Period of output of performance status message, 0 to 100 seconds (\$CRMSS)
- 6) Checksum


#### **MSK Receiver Signal Status MSS**

Format unknown

### MWD Wind Direction & Speed

Format unknown

#### **MTW** Water Temperature



- 1) Degrees
- 2) Unit of Measurement, Celcius
- 3) Checksum

# **MWV** Wind Speed and Angle

- 1) Wind Angle, 0 to 360 degrees
- 2) Reference, R = Relative, T = True
- 3) Wind Speed
- 4) Wind Speed Units,  ${\rm K}/{\rm M}/{\rm N}$
- 5) Status, A = Data Valid
- 6) Checksum


#### **OLN** Omega Lane Numbers

obsolete

# OSD Own Ship Data


- 1) Heading, degrees true
- 2) Status, A = Data Valid
- 3) Vessel Course, degrees True
- 4) Course Reference
- 5) Vessel Speed
- 6) Speed Reference
- 7) Vessel Set, degrees True
- 8) Vessel drift (speed)
- 9) Speed Units
- 10) Checksum

#### **ROO** Waypoints in Active Route



- 1) waypoint ID
- . . .
- n) checksum

# **RMA** Recommended Minimum Navigation Information



- 1) Blink Warning
- 2) Latitude
- 3) N or S
- 4) Longitude
- 5) E or W
- 6) Time Difference A, µS
- 7) Time Difference B, µS
- 8) Speed Over Ground, Knots
- 9) Track Made Good, degrees true
- 10) Magnetic Variation, degrees
- 11) E or W
- 12) Checksum


# **RMB** Recommended Minimum Navigation Information

- 1) Status, V = Navigation receiver warning
- 2) Cross Track error nautical miles
- 3) Direction to Steer, Left or Right
- 4) TO Waypoint ID
- 5) FROM Waypoint ID
- 6) Destination Waypoint Latitude
- 7) N or S
- 8) Destination Waypoint Longitude
- 9) E or W
- 10) Range to destination in nautical miles
- 11) Bearing to destination in degrees True
- 12) Destination closing velocity in knots
- 13) Arrival Status, A = Arrival Circle Entered
- 14) Checksum

# **RMC** Recommended Minimum Navigation Information


- 1) Time (UTC)
- 2) Status, V = Navigation receiver warning
- 3) Latitude
- 4) N or S
- 5) Longitude
- 6) E or W
- 7) Speed over ground, knots
- 8) Track made good, degrees true
- 9) Date, ddmmyy
- 10) Magnetic Variation, degrees
- 11) E or W
- 12) Checksum

# **ROT** Rate Of Turn



- 1) Rate Of Turn, degrees per minute, "-" means bow turns to port
- 2) Status, A means data is valid
- 3) Checksum

# **RPM** Revolutions




- Source; S = Shaft, E = Engine
- 2) Engine or shaft number
- 3) Speed, Revolutions per minute
- 4) Propeller pitch, % of maximum, "-" means astern
- 5) Status, A means data is valid
- 6) Checksum

# **RSA** Rudder Sensor Angle

- 1) Starboard (or single) rudder sensor, "-" means Turn To Port
- 2) Status, A means data is valid
- 3) Port rudder sensor
- 4) Status, A means data is valid
- 5) Checksum

## **RSD** RADAR System Data



- 9) Cursor Range From Own Ship
- 10) Cursor Bearing Degrees Clockwise From Zero
- 11) Range Scale
- 12) Range Units
- 14) Checksum

#### RTE Routes


- 1) Total number of messages being transmitted
- 2) Message Number
- 3) Message mode

c = complete route, all waypoints

 $\ensuremath{\mathbf{w}}$  = working route, the waypoint you just left, the waypoint you're heading to, then all the rest

- 4) Waypoint ID
- x) More Waypoints
- n) Checksum

#### SFI Scanning Frequency Information



- 1) Total Number Of Messages
- 2) Message Number
- 3) Frequency 1
- 4) Mode 1
- n) Checksum

# STN Multiple Data ID

- 1) Talker ID Number
- 2) Checksum

#### TLL Target Latitude and Longitude

Format unknown

#### TRF TRANSIT Fix Data

obsolete

#### TTM Tracked Target Message

- 1) Target Number
- 2) Target Distance
- 3) Bearing from own ship
- 4) Bearing Units
- 5) Target speed
- 6) Target Course
- 7) Course Units
- 8) Distance of closest-point-of-approach
- 9) Time until closest-point-of-approach "-" means increasing
- 10) "-" means increasing
- 11) Target name
- 12) Target Status
- 13) Reference Target
- 14) Checksum

# VBW Dual Ground/Water Speed

- 1) Longitudinal water speed, "-" means astern
- 2) Transverse water speed, "-" means port
- 3) Status, A = data valid
- 4) Longitudinal ground speed, "-" means astern
- 5) Transverse ground speed, "-" means port
- 6) Status, A = data valid
- 7) Checksum

#### VDR Set and Drift

- 1) Degress True
- 2) T = True
- 3) Degrees Magnetic
- 4) M = Magnetic
- 5) Knots (speed of current)
- 6) N = Knots
- 7) Checksum

# **VHW** Water Speed and Heading

- 1) Degress True
- 2) T = True
- 3) Degrees Magnetic
- 4) M = Magnetic
- 5) Knots (speed of vessel relative to the water)
- 6) N = Knots
- 7) Kilometers (speed of vessel relative to the water)
- 8) K = Kilometres
- 9) Checksum

# **VLW** Distance Traveled through Water

- 1) Total cumulative distance
- 2) N = Nautical Miles
- 3) Distance since Reset
- 4) N = Nautical Miles
- 5) Checksum

#### **VPW** Speed – Measured Parallel to Wind

- 1) Speed, "-" means downwind
- 2) N = Knots
- 3) Speed, "-" means downwind
- 4) M = Meters per second
- 5) Checksum

#### VTG Track Made Good and Ground Speed

```
1 2 3 4 5 6 7 8 9

| | | | | | | | | | |

$--VTG,x.x,T,x.x,M,x.x,N,x.x,K*hh
```

- 1) Track Degrees
- 2) T = True
- 3) Track Degrees
- 4) M = Magnetic
- 5) Speed Knots
- 6) N = Knots
- 7) Speed Kilometers Per Hour
- 8) K = Kilometres Per Hour
- 9) Checksum

# **VWR** Relative Wind Speed and Angle

- 1) Wind direction magnitude in degrees
- 2) Wind direction Left/Right of bow
- 3) Speed
- 4) N = Knots
- 5) Speed
- 6) M = Meters Per Second
- 7) Speed
- 8) K = Kilometers Per Hour
- 9) Checksum

# **WCV** Waypoint Closure Velocity

- 1) Velocity
- 2) N = knots
- 3) Waypoint ID
- 4) Checksum

# WDC Distance to Waypoint - Great Circle

Format unknown

# WDR Distance to Waypoint - Rhumb Line

Format unknown

#### WNC Distance - Waypoint to Waypoint

- 1) Distance, Nautical Miles
- 2) N = Nautical Miles
- 3) Distance, Kilometers
- 4) K = Kilometers
- 5) TO Waypoint
- 6) FROM Waypoint
- 7) Checksum

# **WPL** Waypoint Location

- 1) Latitude
- 2) N or S (North or South)
- 3) Longitude
- 4) E or W (East or West)
- 5) Waypoint Name
- 6) Checksum

# XDR Cross Track Error – Dead Reckoning

- 1) Transducer type
- 2) Measurement data
- 3) Units of measurement
- 4) Name of transducer
- x) More of the same
- n) Checksum

# XTE Cross-Track Error - Measured

1) Status

V = LORAN-C blink or SNR warning

 ${\tt A}$  = general warning flag or other navigation systems when a reliable fix is not available

2) Status

V = Loran-C cycle lock warning flag

A = OK or not used

- 3) Cross track error magnitude
- 4) Direction to steer, L or R
- 5) Cross track units. N = Nautical Miles
- 6) Checksum

# XTR Cross Track Error – Dead Reckoning

- 1) Magnitude of cross track error
- 2) Direction to steer, L or R
- 3) Units, N = Nautical Miles
- 4) Checksum


# ZDA Time & Date - UTC, Day, Month, Year and Local Time Zone

- $\$--\mathtt{ZDA}\mathtt{,hhmmss.ss,xx,xx,xxx,xxx,xx*}$
- 1) Local zone minutes description, same sign as local hours
- 2) Local zone description, 00 to +/- 13 hours  $\,$
- 3) Year
- 4) Month, 01 to 12
- 5) Day, 01 to 31
- 6) Time (UTC)
- 7) Checksum

# **ZDL** Time and Distance to Variable Point


Format unknown

# **ZFO** UTC & Time from Origin Waypoint



- 1) Time (UTC)
- 2) Elapsed Time
- 3) Origin Waypoint ID
- 4) Checksum

# ZTG UTC & Time to Destination Waypoint




- 1) Time (UTC)
- 2) Time Remaining
- 3) Destination Waypoint ID
- 4) Checksum

# 6. Some Proprietary Sentences

#### **\$PGRMC** Sensor Configuration Information

Garmin proprietary sentence



- 1) Fix mode, A=automatic (only option)
- 2) Altitude above/below mean sea level, -1500.0 to 18000.0 meters
- 3) Earth datum index. If the user datum index (96) is specified, fields 5-8 must contain valid values. Otherwise, fields 4-8 must be null.
- 4) User earth datum semi-major axis, 6360000.0 to 6380000.0 meters (.001 meters resolution)
- 5) User earth datum inverse flattening factor, 285.0 to 310.0 (10-9 resolution)
- 6) User earth datum delta x earth centered coordinate, -5000.0 to 5000.0 meters (1 meter resolution)
- 7) User earth datum delta y earth centered coordinate, -5000.0 to 5000.0 meters (1 meter resolution)
- 8) User earth datum delta z earth centered coordinate, -5000.0 to 5000.0 meters (1 meter resolution)
- 9) Differential mode, A = automatic (output DGPS data when available, non-DGPs otherwise), D = differential exclusively (output only differential fixes)
- 10) NMEA Baud rate, 1 = 1200, 2 = 2400, 3 = 4800, 4 = 9600
- 11) Filter mode, 2 = no filtering (only option)
- 12) PPS mode, 1 = No PPS, 2 = 1 Hz
- 13) Checksum

#### **\$PGRME Estimated Position Error**

Garmin proprietary sentence

- 1) Estimated horizontal position error (HPE)
- 2) Unit, metres
- 3) Estimated vertical error (VPE)
- 4) Unit, metres
- 5) Overall spherical equivalent position error
- 6) Unit, metres
- 7) Checksum

# **\$PGRMF** Position Fix Sentence

Garmin proprietary sentence

10 12 15 1 2 3 5 6 7 8 9 | 11| 13 14 16 \$PGRMF,x.x,x.x,ddmmyy,hhmmss,x.x,ddmm.mmmm,c,dddmm.mmmm,c,c,c,c,x.x,x.x,c,c\*hh

- 1) GPS week number (0 1023)
- 2) GPS seconds (0 604799)
- 3) UTC date of position fix
- 4) UTC time of position fix
- 5) GPS leap second count
- 6) Latitude
- 7) N or S
- 8) Longitude
- 9) E or W
- 10) Mode

M = manual

A = automatic

11) Fix type

0 = no fix


1 = 2D fix

2 = 3D fix

- 12) Speed over ground, 0 to 999 kilometers/hour
- 13) Course over ground, 0 to 359 degrees, true
- 14) Position dilution of precision, 0 to 9 (rounded to nearest integer value)
- 15) Time dilution of precision, 0 to 9 (rounded to nearest integer value)
- 16) Checksum

#### **\$PGRMI** Sensor Initialisation Information


Garmin proprietary sentence



- 1) Latitude
- 2) N or S
- 3) Longitude
- 4) E or W
- 5) Current UTC date
- 6) Current UTC time
- 7) Checksum

#### **\$PGRMM** Map Datum

Garmin proprietary sentence



- 1) Currently active horizontal datum (WGS-84, NAD27 Canada, ED50, a.s.o)
- 2) Checksum

# **\$PGRMO Output Sentence Enable/Disable**

Garmin proprietary sentence

1 2 3 | | | | \$PGRMO,cccc,c\*hh

- 1) Target sentence description (e.g., PGRMT, GPGSV, etc.)
- 2) Target sentence mode
  - 0 = disable specified sentence
  - 1 = enable specified sentence
  - 2 = disable all
  - 3 = enable all output sentences (except GPALM)
- 3) Checksum

#### **\$PGRMT** Sensor Status Information


Garmin proprietary sentence

1 2 3 4 5 6 7 8 9 10 | | | | | | | | | | | \$PGRMT,c...c,c,c,c,c,c,x.x,c\*hh

- 1) Product, model and software version
  - e.g. "GPS25VEE] 1.10"
- 2) Rom checksum test
  - P = pass
  - F = fail
- 3) Receiver failure discrete
  - P = pass
  - F = fail
- 4) Stored data lost
  - R = retained
  - L = lost
- 5) Real time clock lost
  - R = retained
  - L = lost
- 6) Oscillator drift discrete
  - P = pass
  - F = excessive drift detected
- 7) Data collection discrete
  - C = collecting
  - null if not collecting
- 8) Board temperature in degrees  ${\tt C}$
- 9) Board configuration data
  - R = retained
  - L = lost
- 10) Checksum

# \$PGRMV 3D Velocity

Garmin proprietary sentence



- 1) True east velocity, -999.9 to 9999.9 meters/second
- 2) True north velocity, -999.9 to 9999.9 meters/second
- 3) Up velocity, -999.9 to 9999.9 meters/second
- 4) Checksum

# **\$PGRMZ** Altitude Information

Garmin proprietary sentence

1 2 3 4 | | | | \$PGRMZ,x.x,f,h\*hh

- 1) Altitude
- 2) Unit, feets
- 3) Position fix dimensions2 user altitude3 GPS altitude
- 4) Checksum

# **\$PSLIB** Differental GPS Beacon Receiver Control

Starlink, Inc. proprietary sentence, used by Garmin and others

- 1) Frequency
- 2) Bit rate
- 3) Request type
   J = status request
   K = configuration request
   blank = tuning message
- 4) Checksum

#### CME Cushman Electronics, Inc. 7. Manufacturer Codes CMP C-Map, s.r.l. CMS Coastal Marine Sales Company Note: This list is out-of-date, but perhaps still useful. CMV CourseMaster USA, Inc. CNV Coastal Navigator **AAR** Asian American Resources CNX Cynex Manufactoring Company **ACE Auto-Comm Engineering Corporation** CPL Computrol, Inc. **ACR** ACR Electronics, Inc. CPN Compunav **ACS** Arco Solar, Inc. CPS Columbus Positioning, Inc. **ACT** Advanced Control Technology CPT CPT, Inc. AGI Airguide Instrument Company CRE Crystal Electronics, Limited AHA Autohelm of America CRO The Caro Group AIP Aiphone Corporation **CRY** Crystek Crystals Corporation ALD Alden Electronics, Inc. CSI Communication Systems International, Inc. AMR **AMR Systems CSM** Comsat Maritime Services **AMT** Airmar Technology CST Cast. Inc. **ANS** Antenna Specialists CSV Combined Services ANX Analytyx Electronic Systems CTA **Current Alternatives** ANZ Anschutz of America CTB Cetec Benmar APC Apelco CTC Cell-tech Communications APN American Pioneer, Inc. CTE Castle Electronics APX Amperex, Inc. CTL C-Tech, Limited AQC Aqua-Chem, Inc. CNI Continental Instruments AQD Aquadynamics, Inc. CWD Cubic Western Data AQM Aqua Meter Instrument Company CWV Celwave R.F., Inc. ASP American Solar Power CYZ cYz, Inc. ATE Aetna Engineering DCC **Dolphin Components Corporation** Atlantic Marketing Company, Inc. ATM DEB Debeg GmbH ATR Airtron DFI Defender Industries, Inc. ATV Activation, Inc. DGC Digicourse, Inc. AVN Advanced Navigation, Inc. DME Digital Marine Electronics Corp. AWA Awa New Zealand, Limited DMI Datamarine International, Inc. BBL Industries, Inc. BBL DNS Dornier System GmbH **BBR** and Associates BBR DNT Del Norte Technology, Inc. **BDV** Brisson Development, Inc. **DPS** Danaplus, Inc. **BEC Boat Electric Company** DRL R.L. Drake Company **BGS** Barringer Geoservice DSC Dynascan Corporation **BGT** Brookes and Gatehouse, Inc. DYN Dynamote Corporation BHE **BH Electronics** DYT Dytek Laboratories, Inc. BHR Bahr Technologies, Inc. **EBC Emergency Beacon Corporation** BLB Bay Laboratories **ECT** Echotec, Inc. **BME Bartel Marine Electronics EEV** EEV, Inc. Neil Brown Instrument Systems BNI **EFC Efcom Communication Systems BNS Bowditch Navigation Systems** ELD Electronic Devices, Inc. BRM Mel Barr Company **EMC Electric Motion Company BRY** Byrd Industries **EMS** Electro Marine Systems, Inc. BTH Benthos, Inc. ENA Energy Analysts, Inc. BTK Baltek Corporation **ENC** Encron, Inc. **BTS** Boat Sentry, Inc. EPM **Epsco Marine** BXA Bendix-Avalex. Inc. EPT Eastprint, Inc. CAT Catel **ERC** The Ericsson Corporation CBN Cybernet Marine Products **ESA European Space Agency** CCA Copal Corporation of America FDN Fluiddyne CCC Coastal Communications Company FHE Fish Hawk Electronics CCL Coastal Climate Company FJN Jon Fluke Company CCM **Coastal Communications FMM** First Mate Marine Autopilots CDC Cordic Company FNT Franklin Net and Twine, Limited CEC Ceco Communications, Inc. **FRC** The Fredericks Company CHI Charles Industries, Limited FTG T.G. Faria Corporation CKM Cinkel Marine Electronics Industries FUJ Fujitsu Ten Corporation of America CMA Societe Nouvelle D'Equiment du Calvados

**FEC** 

CMC

Coe Manufacturing Company

Furuno Electric Company (??)

FUR	Furuno USA, Inc.	MDL	Medallion Instruments, Inc.
GAM	GRE America, Inc.	MEC	Marine Engine Center, Inc.
GCA	Gulf Cellular Associates	MEG	Maritec Engineering GmbH
GES	Geostar Corporation	MFR	Modern Products, Ltd
GFC	Graphic Controls Corporation	MFW	Frank W. Murphy Manufacturing
GIS	Galax Integrated Systems	MGN	Magellan Corporation
GPI	Global Positioning Instrument Corporation	MGS	MG Electronic Sales Corporation
GRM	Garmin Corporation	MIE	Mieco, Inc.
GSC	Gold Star Company, Limited	MIM	Marconi International Marine Company
GTO	Gro Electronics	MLE	Martha Lake Electronics
GVE	Guest Corporation	MLN	Matlin Company
GVT	Great Valley Technology	MLP	Marlin Products
HAL	HAL Communications Corporation	MLT	Miller Technologies
HAR	Harris Corporation	MMB	Marsh-McBirney, Inc.
HIG	Hy-Gain	MME	Marks Marine Engineering
HIT	Hi-Tec	MMP	Metal Marine Pilot, Inc.
HPK	Hewlett-Packard	MMS	Mars Marine Systems
HRC	Harco Manufacturing Company	MNI	Micro-Now Instrument Company
HRT	Hart Systems, Inc.	MNT	Marine Technology
HTI	Heart Interface, Inc.	MNX	Marinex
HUL	Hull Electronics Company	MOT	Motorola
HWM	Honeywell Marine Systems	MPN	Memphis Net and Twine Company, Inc.
ICO	Icom of America, Inc.	MQS	Marquis Industries, Inc.
IFD	International Fishing Devices	MRC	Marinecomp, Inc.
IFI	Instruments for Industry	MRE	Morad Electronics Corporation
IME	Imperial Marine Equipment	MRP	Mooring Products of New England
IMI	I.M.I.	MRR	Il Morrow, Inc.
IMM	ITT MacKay Marine	MRS	Marine Radio Service
IMP	Impulse Manufacturing, Inc.	MSB	Mitsubishi Electric Company, Ltd.
IMT	International Marketing and Trading, Inc.	MSE	Master Electronics
INM	Inmar Electronic and Sales, Inc.	MSM	Master Mariner, Inc.
INT	Intech, Inc.	MST	Mesotech Systems, Ltd. Marine Technical Associates
IRT IST	Intera Technologies, Ltd.	MTA MTG	
ITM	Innerspace Technology, Inc. Intermarine Electronics, Inc.	MTK	Narine Technical Assistance Group Martech, Inc.
ITR	Itera, Limited	MTR	Mitre Corporation, Inc.
JAN	Jan Crystals	MTS	Mets, Inc.
JFR	Ray Jefferson	MUR	Murata Erie North America
JMT	Japan Marine Telecommunications	MVX	Magnavox Advanced Products and
JRC	Japan Radio Company, Inc.	IVIVX	Systems Company
JRI	J-R Industries, Inc.	MXX	Maxxima Marine
JTC	J-Tech Associates, Inc.	MES	Marine Electronics Service, Inc.
JTR	Jotron Radiosearch, Ltd.	NAT	Nautech, Limited
KBE	KB Electronics, Ld.	NEF	New England Fishing Gear, Inc.
KBM	Kennebec Marine Company	NMR	Newmar
KLA	Klein Associates, Inc.	NGS	Navigation Sciences, Inc.
KMR	King Marine Radio Corporation	NOM	Nav-Com, Inc.
KNG	King Radio Corporation	NOV	NovAtel Communications, Ltd.
KOD	Koden Electronics Company, Ltd.	NSM	Northstar Marine
KRP	Krupp International, Inc.	NTK	Novatech Designs, Ltd.
KVH	KVH Company	NVC	Navico
KYI	Kyocera International, Inc.	NVS	Navstar
LAT	Latitude Corporation	NVO	Navionics, s.p.a.
LEC	Lorain Electronics Corporation	OAR	O.A.R. Corporation
LMM	Lamarche Manufacturing Company	ODE	Ocean Data Equipment Corporation
LRD	Lorad	ODN	Odin Electronics, Inc.
LSE	Littlemore Scientific Engineering	OIN	Ocean instruments, Inc.
LSP	Laser Plot, Inc.	OKI	Oki Electronic Industry Company
LTF	Littlefuse, Inc.	OLY	Navstar Limited (Polytechnic Electronics)
LWR	Lowrance Electronics Corportation	OMN	Omnetics
NACI	Misuslania lusa		Ossan Dassansk

ORE

Ocean Research

MCL

Micrologic, Inc.

THE NIVIE	A 0163 P1010C01		
OTK	Ocean Technology	SRS	Shipmate, Rauff & Sorensen, A/S
PCE	Pace	TBB	Thompson Brothers Boat Manufacturing
PDM	Prodelco Marine Systems	100	Company
PLA	Plath, C. Division of Litton	TCN	Trade Commission of Norway (THE)
PLI	Pilot Instruments	TDL	Tideland Signal
PMI	Pernicka Marine Products	THR	Thrane and Thrane A/A
		TLS	
PMP	Pacific Marine Products		Telesystems
PRK	Perko, Inc.	TMT	Tamtech, Ltd.
PSM	Pearce-Simpson	TNL	Trimble Navigation
PTC	Petro-Com	TRC	Tracor, Inc.
PTG	P.T.I./Guest	TSI	Techsonic Industries, Inc.
PTH	Pathcom, Inc.	TTK	Talon Technology Corporation
RAC	Racal Marine, Inc.	TTS	Transtector Systems
RAE	RCA Astro-Electronics	TWC	Transworld Communications, Inc.
RAY	Raytheon Marine Company	TXI	Texas Instruments, Inc.
RCA	RCA Service Company	UME	Umec
RCH	Roach Engineering	UNI	Uniden Corporation of America
RCI	Rochester Instruments, Inc.	UNP	Unipas, Inc.
RDI	Radar Devices	UNF	Uniforce Electronics Company
RDM	Ray-Dar Manufacturing Company	VAN	Vanner, Inc.
REC	Ross Engineering Company	VAR	Varian Eimac Associates
RFP	Rolfite Products, Inc.	VCM	Videocom
RGC	RCS Global Communications, Inc.	VEX	Vexillar
RGY	Regency Electronics, Inc.	VIS	Vessel Information Systems, Inc.
RMR	RCA Missile and Surface Radar	VMR	Vast Marketing Corporation
RSL	Ross Laboratories, Inc.	WAL	Walport USA
RSM	Robertson-Shipmate, USA	WBG	Westberg Manufacturing, Inc.
RWI	Rockwell International	WEC	Westinghouse Electric Corporation
RME	Racal Marine Electronics	WHA	W-H Autopilots
RTN	Robertson Tritech Nyaskaien A/S	WMM	Wait Manufacturing and Marine Sales
SAI	SAIT, Inc.	VVIVIIVI	Company
SBR	Sea-Bird electronics, Inc.	WMR	Wesmar Electronics
SCR	Signalcrafters, Inc.	WNG	Winegard Company
SEA	SEA	WSE	Wilson Electronics Corporation
SEC		WTC	Watercom
SEP	Sercel Electronics of Canada Steel and Engine Products, Inc.	WST	
	<u> </u>		West Electronics Ltd.
SFN	Seafarer Navigation International	YAS	Yaesu Electronics
SGC	SGC, Inc.		
SIG	Signet, Inc.		
SIM	Simrad,Inc		
SKA	Skantek Corporation		
SKP	Skipper Electronics A/S		
SLI	Starlink, Inc.		
SME	Shakespeare Marine Electronics		
SMF	Seattle Marine and Fishing Supply Co.		
SML	Simerl Instruments		
SMI	Sperry Marine, Inc.		
SNV	Starnav Corporation		
SOM	Sound Marine Electronics, Inc.		
SOV	Sell Overseas America		
SPL	Spelmar		
SPT	Sound Powered Telephone		
SRD	SRD Labs		
SRS	Scientific Radio Systems, Inc.		
SRT	Standard Radio and Telefon AB		
SSI	Sea Scout Industries		
STC	Standard Communications		
STI	Sea-Temp Instrument Corporation		
STM	Si-Toy Marino Floatronics		

Swoffer Marine Instruments, Inc.

Si-Tex Marine Electronics

Savoy Electronics

STM

SVY SWI

#### 8. References

- [1] National Marine Electronics Association: http://www.nmea.org
- [2] Torsten Baumbach's web site: http://pandora.inf.uni-jena.de/ttbb/
- [3] Peter Bennett's GPS and NMEA site: http://vancouver-webpages.com/pub/peter/index.html
- [4] Data Transmission Protocol Specification for Magellan Products. Revision 1.0. Magellan Corporation, Santa Clara 1999. Available at: http://magellangps.com
  - This document describes the protocol used by Magellan's consumer GPS units, including a number of NMEA 0183 proprietary sentences.
- [5] SBA-1 Interfacing Manual. Revision 0.0. Communications Systems International, Inc, Calgary, 1999. Available at: www.csi-dgps.com.
  - This manual explains the interfacing of the SBA-1 DGPS beacon receiver to numerous GPS units as well as the CSI proprietary sentences used.