

## **Advanced Count zone**

Used for:

**Purdue Coordination Diagram** 

Purdue Link Pivot Offset Optimization

Approach Volume

Approach Delay & Arrivals on Red

Approach Speed

Located: 350 to 600 ft behind the stop bar

Note: Place in advance of initial queue of vehicles during the red. Extra benefit if same as DZ detection. Priority #2

## UDOT Detection

Setup

53

52 55

38

54

39 36

**Small yellow & red actuation zone** 

Used for:


Yellow and Red Actuations

Located:

- On stopbar (if detector has a speed filter)
- Slightly advance of stopbar (if no speed filter)

Note: Placing detector at stop bar will provide a more accurate representation of when vehicle enter the intersection. Consider latency adjustments. Priority #5

12



Used for:

Purdue Split Failure

15' Presence zone w/ 3-sec delay in controller,

Used for: Not used for ATSPMs

Note: Priority #1



8

11 7

## **Small count zone**

Used for:

**Turning Movement Counts** 

4

3

Located: On or near the stop bar for each lane

Note: Priority #4. If CAV technology is deployed and needs space in the detector rack, CAV technology is priority #3