## **Bump Sensor**



## Resource - Sensing

Works by measuring the capacitance of twelve electrode points. When an object comes close to the electrode connector, the measured capacitance changes.

30  $\mu$ A, 3.3V; 7 USD bump\_sensor