5.1.7 Multiplexing

Multiplexing in wireless communication

- Multiplexing is a transmission technique that allows to send multiple different signals over the same channel.
- Allows parallel communication with multiple users, even without MIMO.
- Leveraged by MAC layer protocols for managing the multiple access.
 - Space division multiplexing (SDM)
 - Frequency division multiplexing (FDM)
 - Time division multiplexing (TDM)
 - Code division multiplexing (CDM)


Space Division Multiplexing (SDM)

SPD is achieved with MIMO technology.

towards different directions.


- The channels that are created between a receiver and a transmitter are physically separated, as antennas at the receiver and the transmitter are at a certain distance from each other and can be oriented

 Vertical Beamforming
 - Smart antennas, i.e., arrays of antennas connected with each other at the same node, can coordinate and adjust themselves and perform beamforming, to send and receive multiple signals in parallel.
- Not to be confused with spatial multiplexing



Frequency Division Multiplexing (FDM)


- Frequency division multiplexing (FDM) subdivides the frequency range into several non-overlapping frequency bands (mentioned it before).
- Different sub channels have their own frequency band.
- Senders using a certain frequency band can use this band continuously.
- Guard bands are needed to avoid frequency band overlapping ("adjacent channel interference").
- Simple multiplexing scheme, does not need complex coordination between sender and receiver: the receiver only has to tune in to the specific sender.
 - works good for FM radios, but not for mobile communication (imagine having one channel for each mobile device).
- Does not require MIMO.



Time Division Multiplexing (TDM)


 Each channel is given the whole bandwidth for a certain amount of time.

- All senders use the same frequency but at different points in time.
- Guard spaces (i.e., time gaps) have to separate the time slots when the senders use the medium.
- Does not require MIMO.
- Can be combined with FDM.




Code Division Multiplexing (1)

- Code Division Multiplexing allows different channels to use the same frequency and the same time for transmission.
- Separation is now achieved by assigning each channel its own 'code'.
- Every day life example: people in the same room talking simultaneously at the same voice level in different languages.
- To achieve this, CDM uses spread spectrum techniques.





Spread Spectrum


- Spread spectrum techniques involve spreading the bandwidth to transmit data.
- Narrowband signals are transformed into spread-spectrum signals.
 - The power of the signal remains the same
 - The resulting signal is barely distinguishable from noise (higher security).





- The receiver has a way to distinguish the original signal.
- Two main techniques: Frequency Hopping SS (FHSS) and Direct Sequence SS (DSSS).















 Uses a combination of Frequency Division Multiplexing and Time Division Multiplexing, with guard bands.



The pattern of channel usage is called **hopping sequence**.


$$f_2$$
 f_4 f_3 f_1 f_2 f_1

The time spent on a channel with a certain frequency is called **dwell time,** t_d .

The time required for sending one bit is t_h .

• If $t_b < t_d$ -> SLOW HOPPING


• If $t_b > t_d$ -> FAST HOPPING





The receiver of an FHSS system has to know the hopping sequence and must stay synchronized.

105

- Direct sequence spread spectrum (DSSS) systems take a user bit stream and perform an (XOR) with a so-called **chipping sequence**.
- It consists of a sequence of smaller pulses, called **chips**, with a duration t_c .
- t_b : duration of a bit (inverse of the bit rate). $t_b > t_c$.
- If the chipping sequence is generated properly it appears as random noise.







- The receiver generates the same pseudo random chipping sequence as the transmitter.
- Sequences at the sender and receiver have to be precisely synchronized: the receiver calculates the product of the chipping sequence with the incoming signal.

- The receiver generates the same pseudo random chipping sequence as the transmitter.
- Sequences at the sender and receiver have to be precisely synchronized: the receiver calculates the product of the chipping sequence with the incoming signal.

During propagation, errors might occur here

- The receiver generates the same pseudo random chipping sequence as the transmitter.
- Sequences at the sender and receiver have to be precisely synchronized: the receiver calculates the product of the chipping sequence with the incoming signal.

Received signal 0 1 1 0 1 0 1 1 0 0 1 0 1 0 1 0 XOR

Chipping sequence 0 1 1 0 1 0 1 0 1 1 0 1 0 1 (repeated)

During propagation, errors might occur here

Resulting in ambiguous information here

- The receiver generates the same pseudo random chipping sequence as the transmitter.
- Sequences at the sender and receiver have to be precisely synchronized: the receiver calculates the product of the chipping sequence with the incoming signal.

During propagation, errors might occur here


The receiver has correlator and decision modules

Resulting in ambiguous information here

000000111111

Code Division Multiplexing (2)

- Each channel is assigned with a different code, which can be either a different hopping sequence or a different chipping sequence, depending on the spread spectrum technique used.
- In DSSS, to minimize overlaps between channels, chip codes must distant enough, in particular, they should be orthogonal (their dot product should be equal to 0).



Bibliography

- More about antennas components: https://www.industrialnetworking.com/pdf/Antenna-Patterns.pdf (Cisco)
- Jochen H. Schiller. "Mobile Communications" ADDISON-WESLEY
- IoT Communication, Illinois Urbana-Champaign