

Network and internet	166
Connect to Wi-Fi networks	166
Connect with Wi-Fi Direct	168
Use Airplane mode	169
Control data usage	170
Share your internet connection	172
Connect to VPNs	176
Add a Private DNS service	177
Connected devices	178
Connect with Bluetooth	178
Make contactless payments	181
Share or receive with NFC	182
Share files and links with nearby devices	183
Transfer files between phone and computer (USB)	185
Change USB preferences	187
Cast screen or media to TV	189
Print from your phone	191
About wireless sharing	192
Display	195
Adjust screen brightness	195
Use Dark theme	196
Choose color mode	197
Change text and icon size	198
Adjust refresh rate	199
Show apps full screen	200
Stop automatic rotation	201
Stop screen flicker in dark environments	202
Adjust colors at night	203
Change screen timeout	204
Set screen recording options	205
Home & lock screen	206
Change lock screen features	206
Sound & vibration	209
Adjust volumes	209
Set ringtones	211
Change vibration settings	213
Enhance sound	215
Silence calls & notifications	217
Stop phone from speaking	220
Turn off charging sounds	221
Turn touch sounds on/off	222
Hear other notification sounds	223