

Set or change default apps	279
Adjust special app access	280
Passwords & accounts	281
Add or remove accounts	281
Change name & info in your Google account	283
Sync apps with your Google account	284
Control what info Google collects	286
Security & privacy	287
About security	287
Protect against harmful apps	288
Make sure your phone can be found	289
Lock and unlock phone	290
Set a screen lock	290
Quickly tighten lock screen security	292
Set advanced lock options	293
Use fingerprint security	295
Auto lock when you leave or disconnect	298
Prevent repetitive unlocking	299
Unlock with your face	300
More security & privacy	302
Pin an app screen	302
Protect apps in a secure folder	303
Lock SIM card	307
Privacy	308
Review or change permissions	308
Control access to your mic and camera	309
Hide passwords	310
Keep Wi-Fi and mobile networks secure	311
Safety & emergency	312
Prepare for emergencies	312
System	314
Use multiple languages	314
Keyboard	315
Customize the keyboard	315
Change keyboard apps	317
Open apps faster, multitask better	318
Back up phone	319
Users and guests	320
Share your phone	320
Add, modify, remove users	322