

Add or delete guest	324
About phone	325
Record your IMEI number	325
Find legal and product information	326
Fix issues	327
Hardware issues	327
Phone is slow or unstable	327
Phone feels warm or hot	328
Phone won't turn on	329
Phone restarts or crashes	330
Screen is frozen or won't respond	331
Screen displays wrong colors	332
Screen brightness automatically too dim or bright	333
Call and SIM issues	334
Troubleshoot issues with calls	334
Can't make calls	335
Can't answer or phone doesn't ring	337
Issues during calls	339
Battery issues	342
Charging issues	342
Battery drains too fast	343
Bluetooth, Wi-Fi, USB issues	344
Bluetooth issues	344
Wi-Fi issues	347
Can't transfer files or connect USB to computer	349
Account and sign-in issues	350
Forgot unlock code	350
Can't sign in to Google	351
Account sync issues	352
App issues	354
App or widget issues	354
Camera issues	356
Messaging issues	358
Gmail issues	360
Play Store issues	361
Maintenance procedures	362
Update Android software	362
Reset connections, settings, or apps	363
Reset phone	366
Get more help	368