


3. Push the tray back into the phone.



Note: If you need to activate or resize a SIM, contact your carrier.

Erase eSIM

You may need to erase your eSIM:

- When you transfer the eSIM number to another phone
- If you're giving the phone to someone else or trading it in

Note: Only erase your eSIM when instructed to do so by a support technician.

When you erase an eSIM, you remove the following capabilities from the phone:

- Calling
- Mobile data usage
- Messaging

Erasing the eSIM does not cancel your mobile data services. To cancel your services, contact your carrier.

To erase an eSIM:

1. Go to **Settings** > **System** > **Reset options**.
2. Tap **Erase eSIMs** > **Erase**.

To restore an eSIM you erased, contact your carrier.

Fix an issue

If you're having problems, [try these troubleshooting steps](#).