


About your lock screen

The lock screen appears when you power on your phone or while [the screen is locked](#). The lock screen has a sleep mode and an awake mode.

Sleep mode



When your phone has been inactive, [the screen times out](#) (goes black). If you lift, tap, or move the phone sideways on a surface, or when a notification comes in, the screen goes into sleep mode and shows essential information:

- Time
- Date
- Notification icons that let you peek at messages
- Battery level

If you're [playing media](#), the media player also appears in sleep mode, so you can control what's playing without fully waking the screen.