

- returns you to the home screen from any app.
- lets you [switch between recent apps](#).

Tip: For visual assistance, you can add  to open the [Accessibility Menu](#).