

3. Select options to rename, delete, or share the recording, or view file details.

Control whether other apps can play and share your recordings

1. In the  **Recorder** app, tap  > .
2. Tap **Storage**, then set access to your recordings:
 - To restrict playing and sharing to only the Recorder app, select **Audio Recorder only**.
 - To permit playing and sharing of recordings with other apps, select **Audio Recorder + other apps**.

Change recording settings

To adjust settings for future recordings you make:

1. In the  **Recorder** app, tap  > .
2. Adjust settings as described below.

Adjust sound quality/file size

Tap **Quality** and select an option:

- **High** (better sound)
- **Low** (smaller file size)
- **Default** (balance between sound quality and file size)

Change file format

1. Tap **Recording format**.
2. Select the file type for new recordings (m4a, wav, aac).

Allow/prevent notification sounds while recording

1. Tap **Notification sounds**.
2. Choose to allow or silence notifications.

Allow/prevent screen from turning off while recording

Turn **Keep screen on while recording** on  or off .