

Arrange apps and control icon's look

Choose where to find apps: app tray or home screen

The app tray holds all of your installed apps. Swipe up from the bottom of the [home screen](#) to open the tray. This simplifies your home screen, showing only [apps you choose to add as shortcuts](#).

To see **all** apps on your home screen instead, you can remove the app tray.

You can switch at any time.

1. Touch & hold a blank space on your home screen.
2. Tap  **Home settings** > **Home screen style** and then:
 - To see all apps on your home screen, tap **Open**.
 - To see all apps in the app tray, tap **App tray**.
3. Tap  to see more customizations, described below.

If you're using the app tray

You can  make these customizations in Home settings:

- Turn on/off suggested apps at the top of the list and bottom of the home screen.
- If you don't want the app's icon added to your home screen when you install a new app, turn **Add app icons to Home screen** off . The icon is only added to the app tray.

If you're using Open to put all apps on the home screen

You can  customize how app icons are arranged:

- To be able to position icons anywhere on the home screen, tap **Free arrangements**.
- To have icons move automatically to fill empty spaces, tap **Auto fill**.

Adjust icon size and names

You can make the app icons on your home screen and in the app tray larger or smaller. You can also remove or expand the names below the icon.

1. Touch & hold a blank space on your home screen.
2. Tap  **Home settings**.
3. Adjust settings:
 - To make the icons smaller or larger, tap **Icon size** and move the slider to choose a size.
 - To remove the names below the icons, tap **App label** > **Don't show**.
 - To restore the names below the icons, tap **App label** > **2 rows** (full names) or **1 row** (short names).