

To customize the sidebar, tap . [You can add or remove apps and reorder them.](#)

Switch between open apps

To switch between recently used apps, swipe left or right at the bottom of the screen.

To see your list of recent apps, drag up from the bottom of the screen, hold, then let go:

- To see more apps, swipe left or right.
- To switch to an app, tap it in the list.
- To choose between opening the app in freeform or full screen, touch & hold its icon.

Tip:

[Use two apps at once with split screen.](#)

Clear recent apps

You can clear all apps from your list of recent apps. Or, you can prevent an app from being cleared from your recent apps when you tap **Clear all** to [close all apps](#).

To remove all apps from the list:

1. Drag up from the bottom of the screen, hold, then let go to see your list of recent apps.
2. Tap **Clear all**.

To lock an app in the list:

1. Drag up from the bottom of the screen, hold, then let go.
2. On the app you want to keep in the list, tap .

To unlock the app so it's removed when you tap **Clear all**:

1. Drag up from the bottom of the screen, hold, then let go.
2. On the app, tap .