
Delete or disable apps

Disable apps provided with phone

You can't remove [preloaded apps](#) from your phone, but you can disable and hide apps that you don't need.

To disable an app:

1. Go to [Settings](#) > **Apps**.
2. Tap **All apps** > app you want to disable.
3. Tap **Disable**.

To re-enable a disabled app:

1. Go to **Settings** > **Apps** > **All apps**.
2. Tap the app.
3. Tap **Enable**.

You can [remove any app from your homescreen](#).

Delete apps you installed

You can delete (uninstall) apps that you downloaded. For many [preloaded apps](#), you can disable but not delete them.

1. Touch & hold the app's icon.
2. Do one of the following:
 - Drag the icon up and drop it on . This deletes the app and frees storage space.
 - If you don't see a delete option, touch & hold the app icon, then tap  > **Disable**.

Delete apps installed by others

If you are the [owner](#) of the phone and [shared it](#) with users or guests, you can uninstall apps they installed. Although their apps don't appear in your app tray or on your home screen, they do reduce available storage space.

1. Go to [Settings](#) > **Apps** > **All apps**.

Apps installed by others show the message **Not installed for this user**.

2. Tap the app name.
3. Tap  > **Uninstall for all users**.