

Tip: To call frequent numbers with one touch from your home screen, [add a Direct dial widget](#).

Dial by voice

[Get your assistant's attention](#), then say “Call” or “Dial” and one of the following:

- Phone number
- Contact's name
- Name and town of local business

Change default calling app

You can [download](#) additional calling apps from Play Store. After you've installed one, you can make it your default calling app.

1. Go to [Settings](#) > **Apps**.
2. Touch **Default apps** > **Phone app**.
3. Touch the app to use.

Fix an issue

If you can't make calls, [try these troubleshooting steps](#).