

Turn call waiting on and off

When you're on a call and a new call comes in, the new call is sent to [voicemail](#). If you want to be notified of new calls instead, turn on call waiting.

Note: Some carriers automatically control call waiting. If you do not see this option on your phone, contact your carrier for more information.

To turn call waiting on:

1. Open the  **Phone** app.
2. Touch  > **Settings**.
3. Do one of the following:
 - If your phone has one SIM, touch **Calls**.
 - If your phone has two SIMs, touch **Calling accounts** and select the SIM.
4. Touch **Additional settings**, then turn **Call waiting** on .

When call waiting is on, if you're on a call and a new call comes in, you can answer it. The first call is put on hold. Touch  to merge the two calls.

To turn call waiting off, go to **Additional settings**, then turn **Call waiting** off .