

Listen to radio

Listen to FM stations

Your phone automatically tunes to radio stations with the best signal. Listening to the radio doesn't use your mobile data.

1. Plug headphones (any brand) into your phone. They serve as a radio antenna and allow you to scan for stations. Even when you listen through your phone's speaker, [Bluetooth](#) wireless speakers, or wireless headphones, you still need the wired headphones as your antenna.
2. [Open](#) the **FM Radio** app.
3. Do any of the following:
 - To view all stations and listen to any, use the  tab.
 - To listen to your favorite stations, use the  tab.
 - To seek stations throughout the radio dial, touch the  tab, then touch  or . Tune to specific frequencies by dragging the tuner to the appropriate number.
 - To change between headphones or loudspeaker, touch  or .
 - If you're listening to the radio while using another app, use the mini player in [notifications](#) to seek stations or turn the radio off.
 - To turn the radio off, touch .

Tip: If you're having reception issues, try moving your phone as far from the headphones as possible to increase the size of the antenna. Or, try moving a short distance, towards a window if you are inside or away from buildings if you are outside.

Manage your favorites

Add a station to your favorites

On the  or  tabs, tap  by the station.

Listen to your favorite stations

Use the  tab.

Remove a favorite

On any tab, tap  by the station.

Save and reload your favorites

If you change regions or manually rescan stations, your favorites will be cleared, too, so save them first. Then after you rescan, reload your favorites.

To save your favorites, on the  tab, tap  > **Save favorites**.

To reload your saved favorites, on the  tab, touch  > **Load favorites**.