

Connect to Wi-Fi networks

Turn on and connect

Open [quick settings](#) and tap  to turn Wi-Fi on.

Your phone will automatically connect to Wi-Fi networks you've used before. If there aren't any, you can [search for nearby networks](#) and connect with one.

When you're connected, you'll see  in the [status bar](#).

Change, share, remove networks

After connecting to a Wi-Fi network, your phone saves its details to automatically connect to previously used networks. You can manually connect to a different nearby network, share a network, or remove a saved network you no longer want to connect automatically.

Search for new networks

To scan for nearby available networks that you haven't connected to before:

1. [Open quick settings](#), then touch & hold .
2. Turn **Wi-Fi** on .

You'll see a list of available networks. If a network needs a password, you'll see .

3. Do one of the following:
 - If the network is open (no ) , tap its name to connect.
 - To type a password from the network owner, tap the network to connect to, then enter the password. For your home network, get the password from the label on the Wi-Fi router. For a public network, get the password from the business or organization.
 - To connect using a QR code, swipe to **Add network**, then tap  and scan the code.
 - If the network is hidden, you'll need to [set it up](#) before it'll show up in the list of available networks.

Change networks

To switch to a network you've used before:

1. [Open quick settings](#), then touch & hold .
2. In the list of nearby networks:
 - To connect to a different network, tap its name.
 - To change settings for the currently connected network, tap  > .
 - To change settings for a saved, disconnected network, touch & hold its name, then tap **Modify**.

Share a network

You can share connection information with a friend so they can connect to the same network.