

Cast screen or media to TV

Mirror with Chromecast

To mirror your screen on a TV, showing all apps and screens you use on your phone, you must:

- Use a TV with [Chromecast built-in](#).
- Or, plug a Chromecast into your TV's HDMI port. ([Learn how.](#))

To start casting:

1. Make sure your phone and Chromecast or TV with Chromecast are connected to the same [Wi-Fi](#) network.
2. Go to [Settings](#) > **Connected devices** > **Connection preferences** > **Cast**.

Or, from [quick settings](#), tap .

3. Tap the name of the Chromecast or TV to connect.

To stop:

- On the casting notification, tap  > **Disconnect**.
- Or, from quick settings, tap  > **Disconnect**.

Cast an app

You can cast an app if you:

- Have a smart TV that supports mobile apps for viewing or playing media from your phone. See your TV user guide for instructions to connect your phone.
- Have Chromecast or a TV with [Chromecast built-in](#).

Miracast is not supported.

To cast an app:

1. Make sure your phone and smart TV or Chromecast are connected to the same [Wi-Fi](#) network.
2. In a cast-compatible app (like YouTube), tap .

If you don't see  or don't see your TV listed in the casting options, [try these troubleshooting steps](#).

While casting:

- You'll see  in the [status bar](#).
- You can still make and receive calls and use your phone's other features.

To stop casting:

- In the app that's casting, tap  and tap the option to disconnect.
- From the notification, tap .