

Print from your phone

Set up printing

To connect your printer and phone:

1. Before you begin:
 - If your printer is connected to a Wi-Fi network, be sure the phone and your printer are connected to the same network.
 - If your printer supports Wi-Fi Direct, [set up a direct connection](#) between the phone and printer.
2. Go to **Settings** > **Connected devices** > **Connection preferences** > **Printing**.
3. Touch **Default Print Service** to automatically find your printer.

Once your printer is found, it is ready to print.

If your printer isn't found in Default Print Service:

1. Touch **Add service**.
2. In Play Store, search for “[printer brand] print service” and install the app for the printer's service plugin.
3. Once installed, return to **Settings** > **Connected devices** > **Connection preferences** > **Printing** and touch the print service plugin name to automatically find your printer.
4. If your printer isn't found automatically, touch  > **Add printer** > .
5. Enter the printer's name and IP address (found in your printer settings on connected computer).

Print

1. Open the item to print, such as:
 - A photo in Photos
 - An email
 - A document in Drive
 - A web page in Chrome
2. Tap  or  > **Print**. (If you're using Chrome,  > **Share** > **Print**.)
3. Select printer options if needed.
4. Tap .