
Change lock screen features

Use these options to control what content and features appear on your [lock screen](#).

You can also [control when your screen locks](#).

Change how notifications look and work

Turn off or limit notifications

To turn off notifications for your lock screen (sleep mode and awake mode), or to choose between showing some or all content:

1. Go to **Settings > Home & lock screen**.
2. Tap **Lock screen > Privacy**.
3. Select whether or not to show notifications.

If you show notifications but hide sensitive content, then you'll receive notifications for incoming emails or chats, but they won't include message details.

To turn off notifications in [sleep mode](#) but see them in awake mode:

1. Go to **Settings > Home & lock screen > Lock screen**.
2. Tap **Sleep display**, then turn **Always On Display** off .
3. Tap **Privacy** and choose **Show all notifications on lock screen**.

To have the screen stay black when notifications arrive:

1. Go to **Settings > Home & lock screen > Lock screen**.
2. Turn **Wake screen for notification** off .

Change notification style

These are your choices for displaying notifications on your lock screen: