




1. **Bubbles:** See notifications bundled by app. Tap a bubble to preview an app's notifications.
2. **Chip:** See which apps have notifications. Tap the chip to see all notifications.
3. **List:** See notifications as a list with details.

To change styles:

1. On the lock screen, touch & hold a blank space, then tap **Customize lock screen**.
Or, go to **Settings > Home & lock screen > Lock screen > Customize lock screen**.
2. Tap the image representing your current notification style.



3. Choose a new style.

Hide or show notification actions

If you don't want to see and use actions on notifications (like Reply, Archive):

1. Go to **Settings > Home & lock screen > Lock screen**.
2. Turn **Sleep mode interactions** off .

Set whether unlocking is needed for replies

To prevent others from using your phone, when you use an action (like Reply) from a notification, you need to unlock the phone before replying.

To allow replies or other actions from notifications without unlocking:

1. Go to **Settings > Home & lock screen > Lock screen**.
2. Turn **Safe reply** off .