

Choose how notifications look and open

Turn notification dots off/on

App icons show dots to alert you about unread notifications. You can turn off dots for one or all apps.



Turn dots off for all apps

1. Go to [Settings](#) > **Notifications**.
2. Turn **Notification dot on app icon** off ☐ or on ☒.

Turn dots off for one app

1. Touch & hold the app icon.
2. Tap ⓘ > **Notifications**.
3. Turn **Allow notification dot** off ☐ or on ☒.

Turn bubbles off/on for messaging

Bubbles keep your conversations accessible by floating on top of other apps. Read and send messages from the bubble without opening the app. You can turn bubbles off if you want to always see conversations in their full app.

1. Go to [Settings](#) > **Notifications** > **Bubbles**.
2. Turn **Allow apps to show bubbles** off ☐ or on ☒.

Turn off/on for specific app or conversation

1. Go to **Settings** > **Apps** > **All apps**.
2. Tap the app to change.
3. Tap **Notifications** > **Additional settings in the app** > **Bubbles**.
If you don't see Bubbles, then the app doesn't support this feature.
4. Adjust settings to specify whether some or all conversations can bubble, or nothing should bubble (all conversations open in the full messaging app).

Turn on snoozing

If you want to be able to [snooze your notifications](#), turn on snoozing:

1. Go to [Settings](#) > **Notifications**.
2. Turn **Allow notification snoozing** on ☒.