
Adjust screenshot settings

You can adjust settings for [capturing screenshots](#) at any time.

1. Go to **Settings** > **Gestures**.

Or, open the **Moto** app and tap  > **Gestures**.

2. Do any of the following:

- Turn **Use Three finger screenshot** on  or off .
- To prevent the three finger gesture from working in certain apps, tap **Settings** >  and select the apps.