

2. Tap a service to open its settings:

- **Earthquake alerts:** Sends you an alert about nearby earthquakes of magnitude 4.5 or more. (Not available in all countries.)
- **Emergency Location Service:** [Sends your location to emergency responders](#) when you call or text an emergency number.
- **Google Location Accuracy:** Improves location accuracy for [Maps](#) and [Find My Device](#).
- **Google Location History:** Clear saved location details and turn location history on or off.
- **Google Location Sharing:** View who's sharing your location, change sharing duration, and stop sharing.
- **Carrier Location Access:** Improves carrier services and analytics.
- **Wi-Fi scanning:** Allow or prevent apps and services from scanning for Wi-Fi networks at any time, even when Wi-Fi is off.
- **Bluetooth scanning:** Allow or prevent apps and services from scanning for nearby Bluetooth devices at any time, even when Bluetooth is off.

Fix an issue

Issue: Location isn't working

After each step, check to see if the issue is fixed.

1. [Turn location off](#) and then on again.
2. [Turn airplane mode on](#), wait 15-20 seconds, then turn it off again.
3. If you're using a case, remove it and check if GPS is working. The case might be obstructing the sensor.
4. [Check if Battery saver is on](#). To save power, when Battery saver is on, your phone disables location services.
5. Turn your phone off and then on again.
6. [Check for updates](#) to the Maps app. After updating the app, restart your phone.
7. Clear the cache and data for the Maps app.
8. [Use safe mode](#) to see if apps you installed are causing the issue and uninstall as needed.

If location works correctly in safe mode, a 3rd party app is probably causing the issue. A lot of apps use your phone's location. If these apps end up with corrupted files, it can affect your phone's location too.

Issue: Location isn't accurate

Turn accuracy on:

1. Go to [Settings](#) > **Location**.
2. Touch **Location services** > **Google Location Accuracy**.
3. Turn **Improve location accuracy** on .

When this setting is on, your phone uses GPS, Wi-Fi, mobile networks, and sensors to get the most accurate location.

When it's off, your phone uses only GPS to find location, which can be slower and less accurate.