

Use accessibility shortcuts

About accessibility shortcuts

Shortcut: Essential controls for your phone

The  [accessibility menu](#) gives quick access to essential features on your phone.

Shortcut: Accessibility features

Easily turn accessibility features on/off from any screen. For each feature you're using, you can:

- [Add a button to the screen](#). The button fades when not in use.
If you set up multiple buttons, they display as a group; drag to reposition the group around the sides of the screen.
If you're using gesture navigation, you can set up a gesture instead of buttons.
- [Set your phone so that you press both Volume buttons to turn the feature on/off](#).
If you set this up for multiple accessibility features, you'll see a list of those features when you press both Volume buttons.

Use accessibility menu of essential controls

Open a large menu where you can:

- Call [your assistant](#)
- Open accessibility settings
- Lock or turn off the phone
- Adjust volume
- Adjust brightness
- See recent apps to return to one
- Take a screenshot
- Open quick settings

Turn it on

1. Go to [Settings](#) > **Accessibility**.
2. Tap **Accessibility Menu**.
3. Turn **Accessibility Menu shortcut** on .
4. To increase the size of the buttons on this menu, tap **Settings**, then turn **Large buttons** on .

Use it

If you're using [gesture navigation](#):

1. Use two fingers to swipe up from the bottom of the screen.