

Sync apps with your Google account

When your phone syncs, your Google apps refresh their data, and you get notifications about updates.

See which apps auto-sync

By default, [apps made by Google](#) sync automatically. You can turn auto-sync off and back on for individual apps.

Whether other apps (not made by Google) can sync varies by app.

See which Google apps auto-sync

1. Go to [Settings](#) > **Passwords & accounts**.
2. Tap the account name.
3. Tap **Account sync**.
4. Review the list of your Google apps and when they last synced.

Check other apps

To see if your other apps can auto-sync:

1. Go to [Settings](#) > **Passwords & accounts**.
2. Review the list of accounts:
 - If the app isn't listed, then it can't auto-sync.
 - If it is listed, tap its name to see any sync options you can adjust.

Turn off auto-sync

Turning off auto-sync doesn't remove the app or your data. It only stops the app from automatically refreshing your data.

Turn off for certain Google apps

1. Go to [Settings](#) > **Passwords & accounts**.
2. If you have multiple accounts on your phone, tap the one you want.
3. Tap **Account sync**.
4. Turn off the apps you don't want to auto-sync.

For example, sync your Calendar and Gmail but don't sync Drive.

Turn off for your Google account

1. Go to [Settings](#) > **Passwords & accounts**.
2. Turn **Automatically sync app data** off .

To receive emails, calendar reminders, or other notifications from Google apps, you'll need to sync manually.