

Use fingerprint security

Set up fingerprint security

The [fingerprint sensor](#) is part of your screen and appears only when you need it. Use it to unlock your phone, make fast and secure online and in-store purchases, and sign into bank and finance apps.

1. Go to [Settings](#) > **Security & privacy**.
2. Tap **Device unlock**.
3. Tap **Fingerprint**, then unlock your phone.
4. Follow the onscreen instructions to scan your fingerprint.

Fingerprints are [stored securely](#) on the phone.

Add more fingerprints

Keep in mind that:

- If multiple users [share the phone](#), users should add their fingerprints from within their [user profile](#), instead of adding multiple fingerprints to your owner profile.
- Anyone whose fingerprints are added to a user profile can unlock the phone and authorize purchases with the associated [Google account](#) or apps.

Add a fingerprint for each finger you want to use with the sensor:

1. Go to [Settings](#) > **Security & privacy**.
2. Tap **Device unlock**.
3. Tap **Fingerprint** and enter your pattern, PIN, or password to verify your identity.
4. Tap **Add fingerprint**.
5. Use the fingerprint sensor to scan another fingerprint.
6. Rename each fingerprint. Tap the current name, type a name, and tap **OK**.

Remove a fingerprint

1. Go to [Settings](#) > **Security & privacy**.
2. Tap **Device unlock**.
3. Tap **Fingerprint** and enter your pattern, PIN, or password to verify your identity.
4. Tap  next to the fingerprint.

Change fingerprint animation

You can adjust how the fingerprint icon animates in response to your touching the sensor:

1. Go to [Settings](#) > **Security & privacy**.
2. Tap **Device unlock**.
3. Tap **Fingerprint** and enter your pattern, PIN, or password to verify your identity.
4. Tap **Animation styles** and make a selection.