
Hide passwords

To control whether characters briefly display when you enter a password to unlock your phone or log into websites and apps:

1. [Open](#) the  **Moto Secure** app and touch **Privacy controls**.
Or, go to **Settings > Security & privacy > Privacy**.
2. Turn **Show passwords** off .