

Keep Wi-Fi and mobile networks secure

Control warnings about and your connections to open networks (that require no password) and weakly secured Wi-Fi and mobile networks.

1. [Open](#) the  **Moto Secure** app.

Or, go to **Settings > Security & privacy**.

2. Tap **More security & privacy**.
3. Tap **Network protection**.
4. Turn options on  or off :
 - To prevent network spoofing by blocking 2G cellular connections, turn **Mobile data security** on .
 - To get warnings when your phone is connected to unsecured networks, turn **Wi-Fi security** on .
 - To get warnings when your hotspot is using a weak protocol, turn **Hotspot** on . ([Learn how to change security protocols.](#))
 - To ensure that you don't use sensitive apps when your phone is connected to an open network, touch **Wi-Fi blocklist** and select the apps, then turn **Wi-Fi blocklist** on .