

Customize the keyboard

To customize Gboard, just tap  in top row of the keyboard.

Or, go to **Settings** > **System** > **Keyboard** > **On-screen keyboard** > **Gboard**.

Add language to keyboard

If you want a keyboard for a language that isn't a display language:

1. On the top row of the keyboard, tap .
2. Tap **Languages**.
3. Tap .
4. Select the language.
5. Tap **Done**.

Then, [switch between languages](#) on the keyboard by tapping .

Resize keyboard to type more accurately

Give yourself more space to type and reduce typos by adjusting the height of the keyboard. You can also reposition it for your best fit.

1. On the top row of the keyboard, tap .
2. Tap .
3. Adjust sizing:
 - Drag the handles on the frame to increase or decrease the keyboard height.
 - Touch & hold  to drag the keyboard up or down.
4. Tap  to save changes or  to reset to the original size and position.

Tip: [Voice typing](#) can also improve typing speed and accuracy.

Change background appearance

1. On the top row of the keyboard, tap .
2. Tap **Theme**.
3. Select a color or landscape to use as the background.
4. Tap **Apply**.

Adjust keyboard sounds or vibration

The [onscreen keyboard](#) vibrates when you tap a key. Turn off vibration feedback if you prefer not to use it or want to improve battery life.