

Can't answer or phone doesn't ring

After each troubleshooting step, check to see if your issue is fixed.

Phone doesn't ring or ring loud enough

1. [Check your volume setting](#).
2. Look for  in your [status bar](#). If you see it:
 - [Open quick settings](#) and touch  to turn Do Not Disturb off. Your phone will ring for incoming calls.
 - Make sure your phone is set to [screen calls](#) at the appropriate times.
3. Check that your [ringtone](#) is not set to **None**.
4. Is your phone connected with a [Bluetooth device](#)? If so, all audio is routed to the Bluetooth device.
5. If you're using a ringtone that you installed, try using a ringtone that came with the phone.
6. [Use safe mode](#) to see if apps you installed are causing the issue and uninstall as needed. Begin with application types like launchers, task killers, or anti-virus apps.

Can't answer ringing phone

1. Clear the data for the Phone app.
Touch & hold , then touch  > **Storage & cache** > **Clear storage**.

Consistent busy signal

Outbound calls

1. If you hear a fast busy signal when you call a number, all cellular circuits may be in use, preventing the call from going through. Try calling again later.
2. If you hear a fast busy signal every time you call the same number, your number may be blocked by an app. Try calling from a different number.

Incoming calls

If you have a signal and can make calls, but callers tell you they consistently get a busy signal when calling you, check that you haven't [blocked their numbers](#).

Don't get calls/texts

1. If [airplane mode](#) is on, turn it off.
2. Turn your phone off and then on again.
3. [Check for updates to your phone and messaging app](#).
4. [Check if a software update is available](#) for your phone.