

Calls go to voicemail

Check your **Do Not Disturb** settings:

1. Look for  in your [status bar](#). If you see it, then your phone is sending calls to voicemail so you're not interrupted. To have your phone ring for incoming calls, open quick settings and touch  to [turn off Do Not Disturb](#).
2. [Check your schedules for Do Not Disturb and delete any you don't want.](#)
3. If you're using [Bedtime mode](#) but don't want to send calls to voicemail when you're sleeping, touch **Settings > Digital Wellbeing & parental controls > Bedtime mode > Customize** and turn **Do not Disturb for Bedtime mode** off .
4. You can start Do Not Disturb by placing your phone face down on a surface. If you don't want to send calls to voicemail when your phone is face down, go to **Settings > Sound & vibration > Flip for DND** and turn it off .