

2. Check which apps have [permission](#) to access the camera.

[Settings](#) > **Apps** > **Camera**

Review the list of the apps on your phone that request camera access and remove access for apps that look suspicious or that you don't use.

3. Clear the cache and data for the Camera app.

Error: Trash is full

If you're getting messages about the trash being full:

1. [Open](#) the **Photos** app.
2. Touch **Collections** > **Trash**.
3. Touch  > **Empty trash**.
4. Touch **Delete permanently** to confirm the deletion.