

Messaging issues

If you're having issues [sending or receiving messages](#), try the following:

1. Check for [updates to your messaging app](#).
2. Check if a [software update](#) is available for your phone.
3. Turn your phone off and then on again.
4. If the issue persists, follow the steps below for specific issues. After each troubleshooting step, check to see if your issue is fixed.

Red ! on text message

If you see , your text message was not sent.

1. Check your signal strength.

Weak signal from your cellular provider is a common cause of unsent messages. In the [status bar](#), see how many bars your network connection has. If you see only one or two bars, change locations to improve your signal strength, particularly if you are indoors.

2. Open the conversation and [resend the message](#).

Can't hear notifications

1. Check that [message notifications are turned on](#).
2. Look for  in your [status bar](#). If you see it:
 - [Open quick settings](#) and touch  to turn Do Not Disturb off.
 - Make sure your phone is set to [screen calls at the appropriate times](#).
3. If you're using a 3rd party launcher, [switch back to the Moto launcher](#). If this fixes the issue, then find an alternative launcher to use.

Can't send or receive messages

1. Change your preferred network to **Global**. (Not all carriers support this feature.)
2. If you recently switched from iPhone and are having trouble sending messages to or receiving them from an iPhone, your phone number may still be associated with iMessage. You need to [deregister your account](#).
3. Contact your carrier.

Can't send or receive pictures or videos

Check that:

- [Cellular data is turned on](#).
- Your data plan supports MMS (multimedia messages).