
LTM 1090/3


HOIST GEAR I



CIRCUIT DIAGRAM SUPERSTRUCTURE

1 2		3		4 1	5 6 7 8	
REGISTER OF SHEETS	•	Ţ	·	SHEET	REGISTER OF SHEETS SH	HEET
						
ACCELERATOR SUPERSTRUCTURE, SPEED, ACKNOWLEDGEMENT SAFETY CHAIN,				55 100	FOLDING JIB , HOISTING LIMIT SWITCH FOLDING JIB , FOOT THROTTLE , ACCELERATOR VEHICLE ,	78 115 Д
ACKNOWLEDGEMENT SAFETY CHAIN, ACUSTICAL WARNING,				99	FUEL PREHEATING,	58 A
ADAPTOR 18CHANNEL WITH				140	FUSE GROUPING	5
AIR CONDITIONING				131	FUSE GROUPING	6
EQUIPMENT (OPTION),				108	FUSES	45 47
ANGLE TRANSMITTER , BALLASTING ,				76 106	FUSES FUSES	47
BATTERY OK				65	FUSES	49
CAB INSTALLATION ,				124	FUSES,	46
CAB INSTALLATION, WORKING PROJECTOR,				123	GENERAL OUTLAY	19
CENTRAL GREASING CENTRAL UNIT 0				110 8	GENERAL OUTLAY BOOM GENERAL OUTLAY HOISTING LIMIT SWITCH ,	22 81
CENTRAL UNIT 0				33	GENERAL OUTLAY HYDRAULICS:	24 R
CENTRAL UNIT 0 (VOLTAGE SUPPLY),				62	GENERAL OUTLAY HYDRAULICS :	25
CENTRAL UNIT 1				9	GENERAL OUTLAY HYDRAULICS:	26
CENTRAL UNIT 1 CENTRAL UNIT 2				34 10	GENERAL OUTLAY HYDRAULICS : GENERAL OUTLAY HYDRAULICS : BALLASTING /	28 27
CENTRAL UNIT 2 CENTRAL UNIT 2				35	GENERAL OUTLAY HYDRAULICS: BALLASTING / GENERAL OUTLAY LSB1 / CAN BUS	12
CENTRAL UNIT 2 (VOLTAGE SUPPLY) ,				63	GENERAL OUTLAY LSB2	13
CHARGING SET, READING LAMP, SOCKETS 24V,				66	GENERAL OUTLAY LSB3 / CAN BUS	14
CIRCUIT DIAGRAM SUPERSTRUCTURE				1	GENERAL OUTLAY LSB / CAN BUS GENERAL OUTLAY SUPERSTRUCTURE	11
CONNECTION PLAN CONTROLS AND FITTING , MONITOR ,				156 15	GENERAL OUTLAY SUPERSTRUCTURE GENERAL OUTLAY SUPERSTRUCTURE / EXCESS PRESSURE	21 18
CONTROLS AND FITTING CONTROL STAND,				16	GENERAL OUTLAY SWITCH CABINET +S20 ,	20
CONTROLS AND FITTING ROOF,				17	HEADLIGHT 42W BOOM HEAD ,	136
COOLER DRIVE DIESEL ENGINE,				29	HEADLIGHT FOR WINCH , REAR MIRROR HEATING ,	133 C
CUT OFF DIAGRAM CUT OFF DIAGRAM				39 40	HEATING , HEATING , GENERAL OUTLAY HEATING	129 130
CUT OFF DIAGRAM				41	HEATING, GENERAL COTLAT HEATING HEATING THERMO 90 ST (OPTION),	127
CUT OFF DIAGRAM				42	HEATING THERMO 90 ST , COMPLEMENTARY HEATING ,	128
CYLINDER INTERLOCKED / UNLOCKED ,				74	HOIST GEAR 1,	87
DATA LOGGER LICCON ,				69 70	HOIST GEAR 1, PRESSURE SWITCH "HOIST GEAR 1 FREE ",	86
DATA LOGGER LICCON , DESCRIPTION OF SYMBOLS				70 148	HOIST GEAR 2 (PREPARATION) , I/O-MODULE 6	30
DESCRIPTION OF SYMBOLS				149	I/O-MODULE 6	60
DESCRIPTION OF SYMBOLS				150	I/O-MODULE 6 DISPOSITION	7
DESCRIPTION OF SYMBOLS				151	INCLINING CAB,	107
DESCRIPTION OF SYMBOLS DESCRIPTION OF SYMBOLS				152 153	INDICATOR INPUT BOARD EP 0	118 71 E
DESCRIPTION OF SYMBOLS				154	INPUT BOARD EP 0 (-A0)	36
DIFFERENTIAL LOCK , TRANSVERSAL DIFFERENTIA	L PAWL ,			114	INPUT BOARD EP0 / EP1 / EP2	64
DISPOSITION MASTER SWITCH ,				23	INPUT BOARD EP 1 (-A1)	37
DOLLY OPERATION (OPTION) , EMERGENCY OFF CABIN , BATTERY BOX ,				95 43	INPUT BOARD EP 1 / LSB 2 INPUT BOARD EP 2	72 73
EMERGENCY OPERATION WITHOUT LICCON				102	INPUT BOARD EP 2 (-A2)	38
EMERGENCY OPERATION WITHOUT LICCON				103	KEY OF SYMBOLS	155
EMERGENCY OPERATION WITHOUT LICCON				104	LEVELLING	111
ENGINE - ELECTRONICS ECU ENGINE , ENGINE STOP , TANK SENSOR , RADIATOR	₹			31 57	LIGHTING LIGHTING , WARNING PLATE , CONTEUR LIGHT ,	121 122
ENGINE EXCESS PRESSURE, CHARGE CONTROL	`,			51	LUFFING, LOWERING BRAKE LOWERING BOOM,	90
ENGINE SUPERSTRUCTURE,				53	LUFFING AT OVERLOAD,	89
ENGINE SUPERSTRUCTURE,				56	MASS DISTRIBUTION	50 F
ENGINE SUPERSTRUCTURE , COOLING WATER , EXTERNAL FEEDING 110V ,				54 139	MASTER SWITCH , DEAD MAN , MASTER SWITCH LEFT ,	82 85
EXTERNAL FEEDING 230V, VENTILATOR 230V CABI	Ν,			138	MASTER SWITCH LEFT / RIGHT ,	83
FAN CABIN, HEAT EXCHANGER, HEATING,	•			126	MASTER SWITCH RIGHT,	84
FLAMME STARTING DEVICE , PREHEAT ENGINE ,				52	MODIFICATIONS, VERSION	165
FLASHING LIGHT (OPTION) , FLASHING LIGHT , WIND WARNING ,				137 80	MONITOR OPERATING EQUIPMENT	67 157
				T	I	
3 Gez.	26.01.0	05 dpl	LIEBHERR WERK		DL CICILID AL CULL I C	S20 S20
Ausga	be 02.02.0	06 lwerof0	EHINGEN		Zeich-Nr. Blatt	2
Änderung Datum Name	Datum	Name	Copyright (c)		3372-932.04.00.001-001	165

1		2			3		4	5	6	7	8	
REGISTER OF SHEETS							SHEET	REGISTER OF SHEETS			SHEE	
OPERATING EQUIPMEN OUTLINE OF DEVICE;	IT IT IT IT						158 159 160 161 162 163 164					A
OUTRIGGERS PLUG GROUPING PLUG GROUPING PLUG GROUPING PLUG GROUPING PLUG GROUPING PLUG GROUPING POWER PACK POWER PACK PRESSURE SENSOR LU PUMP CONTROL, RADIATOR RADIO, SOCKET 12V (C	OPTION),	·					113 143 144 145 146 147 32 61 93 94 109 125					В
REAR AXLE STEERING, REGISTER OF SHEETS REGISTER OF SHEETS REGISTER OF SHEETS RESERVE SEAT SPRINGING, SLEWING GEAR, INCRE SLEWING GEAR, SLEW SLEWING PLATFORM A SLI, CUTOFF SLI, OVER STAR POINT CAN BUS STEERING STEERING CHANGE-OV	EMENTAL /ING GEAF \DJUSTME RLOAD ,	R FREELY TUF		EAR ,			120 2 3 4 141 132 96 97 105 98 59 119					С
SUPPORTING PRESSUR TELEDIAGNOSIS GSM TELESC. SECT. INTERLO TELESC. SECT. INTERLO TELESC. SECT. INTERLO TELESCOPING, PRESS TOP OF LIFT, HOISTING TRAVEL CONTROL FRO VOLTAGE SUPPLY EXC WIND WARNING, FLASI WORKING PROJECTOR	CE INDICA OCK (MAN OCK , OCK , SURE STAC G LIMIT SV DM ABOVE ESS PRES HING LIGH 8 42W BOC	NUAL OPERAT SE TELESC. SI VITCH TELESC SSURE , ST ,	ECTION C. SECTI				112 68 101 75 92 91 77 117 44 79 135 134					E
												F
3			Gez.	26.01.05	dpl	LIEBHERR WERK		סרטופדרם טר פו ודרדפ		ldent-Nr. 984061308	= S20	
2			Ausgabe	02.02.06	lwerof0	EHINGEN		REGISTER OF SHEETS		304001300	+ S20	
1 Änderung	Datum	Name	nusyaut	Datum	Name	Copyright (c)				Zeich-Nr. 3372-932.04.00.001-001	Blatt 3 von 165	



		2		3			4		5	6		7	. 8	
										 			 	\neg
FUSE	SHEET			FUNCTION	N					BMK				
-F1 / 7,5A 45.1 P	ARKING LIGHT LE	FT								-XF1				
· ·	ARKING LIGHT RI									-XF1				
-F3 / 30A 45.2 L										-XF1				
	OW BEAM LEFT	EXCESS PRES	SURE							-XF1 -XF1				
· ·	OW BEAM RIGHT									-XF1 -XF1				
														7
-F7 / 5A 45.5 PC	DWER PACK , MOI	NITOR TANKS	SENSOR FL	UFI PREHEAT	TING WORKIN	IG HOUR ME	TFR			-XF2				
	O-MODULE 6 : OU	· ·		022111211211	, work and					-XF2				В
	PPORTING FOR		•		S PRESSURE					-XF2				
	VORKING PROJEC				1					-XF2				
-F11 / 10A 45.7 V -F12 / 10A 45.8 V			•		1					-XF2 -XF2				
1127107	VOTATALITO I TROUER	71011 BOOM , 7	1010/11110	DINVE						7.1.2				\parallel
-F13 / 5A 46.4 IN	│ I\$TRUMENT LIGH	TING MASTER	SWITCH I	PRESELECTO	R CLOCK CON	NTROI EME	FRGENCY OPER	ATION		-XF3				
	VINDSCREEN WIF					, , , , , , , , , , , , , , , , , , , ,				-XF3				
	HOOTER , CIRCUI	ATING PUMP I	HEATING							-XF3				
-F16 / 15A 46.5 F										-XF3				
-F17 / 2A 46.6 L -F18 / 2A 46.7 L	SB 3									-XF3 -XF3				
										7 0				
														1
-F19 / 10A 47.1 V	VORKING PROJEC	TOR SUPERS	TRUCTURE	REAR						-XF4				
-F20 / 20A 47.2 F										-XF4				
-F21 / 10A 47.2 F				M HEAD , RAD	DIO PREPARATI	TON				-XF4				_
-F22 / 15A 47.3 F -F23 / 15A 47.3 F										-XF4 -XF4				
-F24 / 30A 47.4 I										-XF4				
														1
-F25 / 10A 47.5 S	OCKET SWITCH	ABINET , SOC	KET CABIN	, READING LA	AMP					-XF5				
-F26 / 15A 47.5 F	AN CABIN									-XF5				
	LATFORM CABIN					VINCH , GAS	HEATING			-XF5				
-F28 / 10A 47.7 II -F29 / 15A 47.7 E			CABIN , SE	EAT HEATING						-XF5 -XF5				
-F30 / 47.8 - F		DINIOU								-XF5 -XF5				
3	<u> </u>	Gez.	27.04.04	Jugaihū	LIEDUEDE	D WEDV					ldent-Nr.	1	= S20	
2				lweeih0	LIEBHERF EHING				FUSE GROUPING			984061308	 + S20	
Ändorung	Datum Ma	Ausgabe	02.02.06	lwerof0			1				Zeich-Nr.	3372-932.04.00.001-001	 Blatt 5 von 165	
Änderung	Datum Na	me	Datum	Name	Copyrigh	Jiii (C)	1						von 165	


1		2	3		4	5	6		7	8		\neg
FUSE	SHEET		FUNCTION	I			ВМК					
-F32 / 7,5A 48.2 Cl -F33 / 7,5A 48.2 Cl -F34 / 7,5A 48.3 Cl	ENTRAL UNIT 1 OUT ENTRAL UNIT 2 OUT ERMOSTAT RADIAT	TLETS TLETS TLETS TOR , EMERGENCY	OPERATION WITH	LICCON , FLASHIN	IG LIGHT CABIN		-XF6 -XF6 -XF6 -XF6 -XF6				A	Α
-F38 / 20A 48.5 R -F39 / 7,5A 48.6 A -F40 / 5A 48.7 LS	R DRIER SB 2 , VALVE INTERL IR CONDITIONING EG	LOCKING					-XF7 -XF7 -XF7 -XF7 -XF7				В	3
-F44 / 7,5A 49.2 I/0 -F45 / 20A 49.2 H -F46 / 5A 49.3 PR -F47 / 20A 49.3 C	OWER PACK, MONI O-MODULE 6 POWER IEATING HEATER PL RESELECTOR CLOCK CHARGING SET ADIO, RADIO, SOCK	R PACK LUG K HEATING , CHAR	GING SET SENSOF	R			-XF8 -XF8 -XF8 -XF8 -XF8				C	С
-F50 / 10A 49.5 S	REE -	RUCTURE					-XF9 -XF9 -XF9 -XF9 -XF9				E	E
											F	F
3 2		Gez. 27.04.	04 lweeih0	LIEBHERR WER	RK	FUSE GROUPING		ldent-Nr.	984061308	=	\$20 \$20	
2 1 Änderung	Datum Name	Ausgabe 02.02.		EHINGEN Copyright (c)		-	 	Zeich-Nr.	3372-932.04.00.001-001	+ Blatt von	S20 6 165	\exists


1		2			3		4	5	6			7	8		
E/I/A	SHEET				FUNCTION	N		TYPE		PLUG					
E.E6.0 E.E6.1 57.1 EN E.E6.2 E.E6.3	GINE STOP							E=010V,420mA E=010V,420mA E=010V,420mA E=010V,420mA		-X662:17 -X662:15 -X662:13 -X662:11					A
E.E6.5 51.4 CH E.E6.6 52.7 CH	MPERATURE ARGE CONT ARGE CONT NK SENSOR	ROL EXCES	SS PRESS					E=010V E=010V E=010V E=010V		-X662:9 -X662:7 -X662:5 -X662:3					
E.S6.4 E.S6.5 E.S6.6 E.S6.7 57.3 TA	NK SENSOR	SUPPLY						A=10mA A=10mA A=10mA A=10mA		-X662:10 -X662:8 -X662:6 -X662:4					В
E.DE6.1 51.4 P E.DE6.2 44.7 C	R CONDITIO REHEAT ENG HANGE OVE AMME STAF	SINE EXCES R 150W	SS PRESS	URE	OW			E=HIGH>4V/LOW<2V E=HIGH>4V/LOW<2V E=HIGH>4V/LOW<2V E=HIGH>4V/LOW<2V		-X662:18 -X662:16 -X662:14 -X662:12					
E.VCCEA6.1 E.VCCEA6.2 60.3	OPERATING	S VOLTAGE								-X661:11 -X661:9					C
E.DEA6.1 52.7 C	HARGE CON HARGE CON LAMME STA LAMME STA	ITROL SUPI RTING DEVI	ERSTRUC ICE TELLI	TURE (OV TALE LIGT	V) UW			E=HIGH>4V/LOW<2V(A=24) E=HIGH>4V/LOW<2V(A=24) E=HIGH>4V/LOW<2V(A=24) E=HIGH>4V/LOW<2V(A=24) E=HIGH>4V/LOW<2V(A=24) E=HIGH>4V/LOW<2V(A=24) E=HIGH>4V/LOW<2V(A=24) E=HIGH>4V/LOW<2V(A=24)	4V/2A) 4V/2A) 4V/2A) 4V/2A) 4V/2A) 4V/2A)	-X663:17 -X663:15 -X663:13 -X663:11 -X663:9 -X663:7 -X663:5 -X663:3					E
E.VCCA6.1 E.VCCA6.2	OPERATING OPERATING							- - -		-X661:1 -X661:3 -X661:5 -X661:7					
E.A6.0 E.A6.1 E.A6.2 57.6 VE	NTILATION I							A=24V/8A A=24V/8A A=24V/8A A=24V/8A		-X663:18 -X663:16 -X663:14 -X663:12					
E.GNDMESS6.1								E=010A		-X661:18					F
3 2				27.04.04	lweeih0	LIEBHERR		I/O-MODULE 6 DISPOSITION		ldent-Nr.	9840613	08	= +	\$20 \$20	\Box
1 Änderung	Datum	Name	Ausgabe	02.02.06 Datum	lwerof0 Name	EHING Copyright				Zeich-Nr.	3372-932	2.04.00.001-001	Blatt von	7 165	


1	1		2			3			4	5	6			7	8	
E/I/A		SHEE	- _T			FUNCTION	d			TYPE		PLUG				$\neg \mid \mid$
		JULE	- '			- ONCTION	v			IIFL		FLUG				_
E0.0										A/D		-X635:d2				_A
E0.1										A/D		-X635:d4				
E0.2	115.2	ACCELERATO	OR POSITIO	ON VEHICL	.E					A/D		-X635:d6				
E0.3										A/D		-X635:d8				
E0.4										A/D		-X635:d1	0			
E0.5	119.2	STEERING DI	кестіри і	LEFT						A/D		-X635:d1	2			\Box
E0.6	119.3	STEERING DI	кестіри і	RIGHT						A/D		-X635:d1	4			
E0.7	65.2 I	BATTERY OK								A/D		-X635:d1	6			
E0.8	118.2	INDICATOR L	EFT							A/D		-X635:d1	8			
E0.9	118.3	INDICATOR R	IGHT							A/D		-X635:d2	0			
E0.10	117.1	PUSH-BUTTO	ON SWITCH	H DRIVING	PROGRAM					A/D		-X635:d2	2			B
E0.11	117.2	TRAVELLING	DIRECTIC	N FORWA	RD					A/D		-X635:d2	4			
E0.12	51.3	ENGINE RUNI	NING EXCE	ESS PRES	SURE					A/D		-X635:d2	6			
E0.13	117.3	TRAVELLING	DIREÇTIC	ON BACKWA	ARDS					A/D		-X635:d2	8			
E0.14	120.2	REAR AXLE S	STEERING	STEERING	DIRECTION	I LEFT				A/D		-X635:d3	0			
E0.15	120.3	REAR AXLES	STEERING	STEERING	DIRECTION	I RIGHT				A/D		-X635:d3	2			$ \mid \vdash \mid$
E1.0		PARKING BRA								A/D		-X635:b2				
E1.1	100.3	EMERGENCY	OPERATION	ON WITH L	ICCON					A/D		-X635:b4				
E1.2	116.4	STEERING CH	HANGE-OV	/ER						A/D		-X635:b6				
E1.3	86.5	SETTING SWI	TCH WINC	H 1						A/D		-X635:b8				
E1.4		SETTING SWIT			ON)					A/D		-X635:b1	0			
E1.5	100.3	BR DGING SL	I / TOP OF	LIFT						A/D		-X635:b1	2			
E1.6	100.2	ERECTION								A/D		-X635:b1	4			
E1.7	102.1	EMERGENCY	OPERATION	ON WITHO	UT LICCON					A/D		-X635:b1	6			
E1.8		SUPERSTRUC			D AFTER RE	AR				A/D		-X635:b1				H
E1.9	89.5 L	LUFIFING AT O	VERLÞAD)						A/D		-X635:b2				
E1.10										A/D		-X635:b2				
E1.11		Adknowled								A/D		-X635:b2				
E1.12		SUPERSTRU	l l		:D					A/D		-X635:b2				
E1.13		SUPERSTRU		NLOCKED						A/D		-X635:b2				E
E1.14		SEAT CONTA		_						A/D		-X635:b3				
E1.15	97.7	PARKING BRA	AKE SWIN	G						A/D		-X635:b3	2			
			- -													7
INK0.A												-X635:z2				
INK0.B												-X635:z4				$ \mid \mid \mid \mid$
INK1.A												-X635:z6				
INK1.B												-X635:z8				
100	00.0	0110117077								A/D		\/70.40				7
A0.0		SLICUTOFF	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	TION! \						A/D		-X70:16				
A0.1		SLI PRE-WARI	ſ	•	ואוסבס סבדי	DACT				A/D		-X70:17				
A0.2		NITIAL TENSI		•		KAUI)				A/D		-X70:18				
A0.3		FREE / SLEWII		rkeely II	JKNING					A/D		-X70:19				
A0.4		FOLDING JIB L	l l							A/D		-X70:20				
A0.5		SWING BRAKE		IG BKAKE						A/D		-X70:21				
A0.6		SWING RIGHT								A/D		-X70:22				
A0.7	97.1	SW NG LEFT								A/D		-X70:23			 	_
3			•	Gez.	27.04.04	lweeih0	LIEBHERR WE	IEDK				Ident-Nr.	00.00.00		= S20	
2				G62.	21.04.04	IWEEIIIU				CENTRAL UNIT 0		iucht-Ni.	9840613	UX	+ S20	
1				Ausgabe	02.02.06	lwerof0	EHINGEN	N				Zeich-Nr.	00=0.00	0.04.00.004.004	Blatt 8	$\overline{}$
Ände	erung	Datum	Name		Datum	Name	Copyright (c)						3372-932	2.04.00.001-001	von 165	,


1		2		3		4	5	6		7	8		\Box
E/I/A	SHEET			FUNCTION	I		TYPE		PLUG				
F2.0							A /D		Vesenido				
E2.0 E2.1							A/D A/D		-X635A:d2 -X635A:d4				A
E2.2							A/D		-X635A:d6				
E2.3							A/D		-X635A:d8				
E2.4							A/D		-X635A:d10				
E2.5							A/D		-X635A:d12				Ш
E2.6							A/D		-X635A:d14				
E2.7							A/D		-X635A:d16				
E2.8							A/D		-X635A:d18				
E2.9							A/D		-X635A:d20				
E2.10							A/D		-X635A:d22				B
E2.11							A/D		-X635A:d24				
E2.12							A/D		-X635A:d26				
E2.13							A/D		-X635A:d28				
E2.14							A/D		-X635A:d30				
E2.15							A/D		-X635A:d32				H
									\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\				
E3.0							A/D		-X635A:b2				
E3.1							A/D		-X635A:b4				
E3.2							A/D		-X635A:b6				
E3.3 E3.4							A/D A/D		-X635A:b8 -X635A:b10				C
E3.5							A/D		-X635A:b10 -X635A:b12				
E3.6							A/D		-X635A:b14				
E3.7							A/D		-X635A:b16				
E3.8							A/D		-X635A:b18				Ш
E3.9							A/D		-X635A:b20				
E3.10							A/D		-X635A:b22				
E3.11							A/D		-X635A:b24				
E3.12							A/D		-X635A:b26				
E3.13							A/D		-X635A:b28				E
E3.14							A/D		-X635A:b30				
E3.15							A/D		-X635A:b32				
	EWING GEAR								-X635A:z2				
	EWING GEAR								-X635A:z4				H
INK3.A									-X635A:z6				
INK3.B									-X635A:z8				
A2.0 02.2 TEL	ESC SECTION Y	LINIDOL TIMO					A/D		V71-16				
	ESC. SECTION X INDER UNBOLTI						A/D		-X71:16 -X71:17				
	SSURE STAGE						A/D A/D		-X71:17 -X71:18				
	SSURE STAGE	l .					A/D		-X71:16 -X71:19				
l I	ST GEAR 1 BRA	l .					A/D		-X71:19				
	ST GEAR 2 BRA	1					A/D		-X71:21				
	ESCOPING OUT						A/D		-X71:22				
	ESCOPING IN						A/D		-X71:23				
		<u> </u>	i										Щ
3		Gez.	27.04.04	lweeih0	LIEBHERR WERK		CENTRAL UNIT 1		ldent-Nr. 9840613	308	=	S20	
2		Ausgabe	02.02.06	lwerof0	EHINGEN		<u> </u>		Zeich-Nr.		+ Blatt	S20	-
Änderung	Datum Na	me	Datum	Name	Copyright (c)	1			3372-93	2.04.00.001-001	von	165	\dashv


1		2		3			4	5	6			7	8	
E/I/A	CUEET			TUNOTIO!	.1			TVDE		DILIO				$\neg \mid \mid$
E/I/A	SHEET			FUNCTION	N 			TYPE		PLUG				_
E4.0								A/D		-X635B:d2				
E4.1								A/D		-X635B:d4				
E4.2								A/D		-X635B:d6				
E4.3								A/D		-X635B:d8				
E4.4								A/D		-X635B:d10				
E4.5								A/D		-X635B:d12				H
E4.6								A/D		-X635B:d14				
	LLAST DOWN (P		•					A/D		-X635B:d16				
	LLAST UP (PUSH		TCH)					A/D		-X635B:d18				
	LLASTING RAM N							A/D		-X635B:d20				$ _{B} $
	LLASTING RAM	OP / BOTTOM						A/D		-X635B:d22				
E4.11 E4.12 89.4 PR	RESELECTION FOL	DING HELLIE	INC					A/D A/D		-X635B:d24 -X635B:d26				
	CUSTICAL WARNIN			N SWITCH V				A/D		-X635B:d26				
E4.14	OSTICAL WARNIN	OFF (PU)	יוס-ווטן ו	N OVVII ()				A/D		-X635B:d28				
	RESELECTION LUI	FING						A/D		-X635B:d32				
L4.13 09.3 FIN	L'SELECTION EOI	TING						A/D		-X033B.032	-			
E5.0								A/D		-X635B:b2				
E5.1								A/D		-X635B:b4				
E5.2								A/D		-X635B:b6				
E5.3								A/D		-X635B:b8				
E5.4								A/D		-X635B:b10				
	LINDER AT POSI	TION						A/D		-X635B:b12				
E5.6								A/D		-X635B:b14				
	LINDER UNBOLT	NG (SWITCH)						A/D		-X635B:b16				
	ELESC. SECTION							A/D		-X635B:b18				\perp
	SSURE SWITCH							A/D		-X635B:b20				
E5.10 88.1 PR	ESSURE SWITCH	HOIST GEAR 2	FREE (OF	PTION)				A/D		-X635B:b22	2			
E5.11								A/D		-X635B:b24	4			
E5.12								A/D		-X635B:b26	3			
E5.13 86.4 WI	NCH 1 NOT UNW	DUND						A/D		-X635B:b28	3			E
E5.14								A/D		-X635B:b30)			
E5.15 88.3 WI	NCH 2 NOT UNW	OUND (OPTION	1)					A/D		-X635B:b32	2			
INK4.A 86.3 W	/INCH 1									-X635B:z2				
	/INCH 1									-X635B:z4				
	INCH 2 (OPTION)						·		-X635B:z6				
	INCH 2 (OPTION							1		-X635B:z8				
A40 070 U0	UCT OF A D 4 LIQUO	TINIC						A /D		V70 40				$\dashv \mid \mid$
	DIST GEAR 1 HOIS							A/D		-X72:16				
	DIST GEAR 1 LOW		\					A/D		-X72:17				
	IST GEAR 2 HOIS IST GEAR 2 LOW							A/D A/D		-X72:18 -X72:19				
	FING	INING (OF HO	v)					A/D A/D		-X72.19 -X72:20				
	WERING BOOM							A/D		-X72.20 -X72:21				
	MP 1							A/D		-X72:21				
	MP 2							A/D		-X72:23				
	<u> </u>												1 2	
3		Gez.	27.04.04	lweeih0	LIEBHERR V			CENTRAL UNIT 2		ldent-Nr.	98406130	08	= S20 + S20	
1	+ + -	Ausgabe	02.02.06	lwerof0	EHINGE	EN				Zeich-Nr.	0070 000	2.04.00.004.004	Blatt 10	
Änderung	Datum Nar	ne	Datum	Name	Copyright (c)	(c)					331Z- 9 32	2.04.00.001-001	von 165	














































































27.04.04 LIEBHERR WERK lweeih0 Ident-Nr. INPUT BOARD EP 1 (-A1) 984061308 **EHINGEN** 02.02.06 lwerof0 Zeich-Nr. Blatt WITH LSB2 3372-932.04.00.001-001 Änderung Datum Datum Name Copyright (c)

S20


S20

37

165





	1			2			3				4		5 6							7			8												
	777	ZZZ 1		FUNC	CTION					zd 1																						zz 1]		
	ZE	2		OPER	RATING N	MODE			T.	/TF																				EM	/IERGENC	CY OPERAT	LON		
CROSS-REF	ERENCE OPER	RANT	SYMBOL	DESI	GNATION				MA										MA I																
	Q		Stop	SLI FRE	EE				X 2																										
	Q		1 FREE	WINC	CH 1 FRE	E (C-KEY)		Х	Х																									
B3.28 /	14.5 Q		<u>\$ 1 ¥</u>	HOISTI	ING LIMIT SV	NITCH BOOM F	REE		X 2																							<u> </u>]		
B3.27 /	14.7 Q		<u>\$</u> 2 ∓	HOISTI	ING LIMIT SV	WITCH FOLDING	G JIB FREE		X 2																										
B3.26 /	14.8 Q		<u>₹</u> 3 ∓	HOISTI	ING LIMIT SV	WITCH DOUBLE	FOLDING JIB FR	REE	X 2																						lacksquare				
				MS 1	NOT OK	(LSB)			Х	Х																									
			MS1Y<>0	MS 1	Y0-NOT	(AT STAR	TING)		X	X																						<u> </u>]		
E1.14 /	32.6		~ \	SEAT (CONTACT / C	CONTROL FREE			X 6	χ 6																									
]		
E5.9 /	36.1		1 FREE	PRESS	SURE SWITC	H HOIST GEAR	1 FREE		X 4	X 4																						Х			
E5.13 /	36.4		1 1	WINCH	H 1 NOT UNW	VOUND				Х																									
	DATUM / GEPRÜFT																																		
						X 2	= (⊣'	MONITOR E1.5 /100.3 E1.6 /100.2							•		X ⁴	X ⁴ = ⊢		NITHOUT	TROL ON OUT MOTOR NITOR)		X ⁶ =		-\'	DEAD MA	AN 12							
3 Gez. 27.04.04					27.04.04	lweeih0	LIE	HERR WER	K		L1.0	1100.2		<u> </u>	UT OFF I	DIAGRAN	Л					Ident-Nr.	(9840613	08					= \$20					
2	Datum	Ausgabe 02.02.06 Iwerof0 EHING Name Datum Name Copyright											O	WINC		"					Zeich-Nr.			2.04.00.0	01-001		+ \$20 Blatt 39 von 165								





	1		2	3 4 5 6					7									8		— ¬													
	八		FUNC	TION					吊 ‡	,					Į	‡															5	π ‡	
	ZE 1		OPER	ATING MOI	DE				T/TF						T/	ΓF														EM	IERGENC'	Y OPERAT O	ON A
CROSS-REFEREN	OPERANT	SYMBOL	DESIG	SNATION				7	ζt _l	引	η [†] Π	<u></u> ∏†	州	吊	ηt	引	ηt	<mark> Ц†</mark>	况t	<u> </u>	况t _l	<u></u> 肾1	Th	 	况t	<mark>, 引,</mark>	Π̈́t	<u> </u>	<mark>界t</mark>	<u> </u>	况t	<u></u>	
	Q	Stop	SLI FRE	E					(2																								
	Q		OPERA ⁻	TING MODE OK	(SLI))	(Х																							
			LENGTH	H SENSOR OK)	(Х																							
	Q	FREE FREE	TELE	SCOPING (OUT FRE	EE (SLI))	(В
	Q	TT LABB	WORKIN	NG AREA LIMIT	ATION TEL	ESCOPING OUT	FREE)	(1																								
	Q		NO TIPE	PING DANGER	TOWARDS	REAR (SLI)				X 2																							
B3.28 /14.5	Q	<u>\$</u> 1 T	HOISTIN	NG LIMIT SWITC	CH BOOM F	REE)	(2																								
B3.27 /14.7	Q	<u>₹</u> 2 ∓	HOISTIN	NG LIMIT SWIT	CH FOLDIN	G JIB FREE)	(2																								
B3.26 /14.8	Q	5 ₃ ∓	HOISTIN	NG LIMIT SWITC	CH DOUBLE	FOLDING JIB FF	REE)	(2																								C
			MS 2	NOT OK (LSB))	(Χ																							
		MS2Y<>0	MS 21	Y0-NOT (A	T STAR	TING)		7	(X																							
E1.14 /82.6		~ \	SEAT	CONTACT	/ CONT	ROL FREE)	(6	X 6																							
E4.15 /89.3		工	PRESEL	ECTION LUFFI	NG / NOT T	ELESCOPING		7	(X																							E
	DATUM / GEPRÜFT							!									ı				.		ı				<u> </u>			F			
	X 1 = - WORKING AREA LIMITATION "OFF" (MONITOR))	(² =	()-	7,	MONITOR E1.5 E1.6	7100.3 /100.2														X 6	= T 	-\'	DEAD MA	N 2					
					LIEBHERR W		CUT OFF DIAGRAM ldent-Nr. 984061308									= \$20 + \$20																	
1 Änd	erung	Name	Ausgabe 02.02.06 Iwerof0 EHING ame Datum Name Copyright						_						TELESC	COPING						Zeich-Nr.		3372-93	2.04.00.00	01-001			Blai				


	1		2		3				4					5					6					7					8		
			FUNCTIO)N			6	7																						4	
	ZE 0		OPERAT	ING MODE			T/	TF																				EM	ERGENCY	OPERAT O	N A
CROSS-REFERE	OPERANT	SYMBOL	DESIGNA	ATION			\cap		\cap	\cap	\bigcap	\cap		\cap	\cap	\supset		\cap	\cap	\cap	\cap	\cap	\cap		\cap	\cap	\cap	\cap			
	Q	FREE	SWING LEF	T FREE (SLI)			X 2																								
	Q	FREE	SWING F	RIGHT FREE (S	LI)			χ 2																							
		_					, 1																								B
	Q	LABB		AREA LIMITATION SWII			X 1	1					\rightarrow																		
	Q	C LABB	WORKING A	AREA LIMITATION SWII	NG RIGHT FREE			X 1																							\mathbb{H}
	Q		RELEASE LE	EFT FREE (SLI)			χ 2																								
	Q	← FREE		E RIGHT FREE((SLI)			χ 2																							
			OPERAT	TING MODE SWII	NG OK		Х	χ																							
			MS 2 NO	OT OK (LSB)			Х	χ																							
		MS2X<>0	MS 2X0-l	NOT (AT STAR	ΓING)		X	X																							
E1.14 /82.6		44	SEAT CO	ONTACT / CONT	ROL FREE		X 6	χ 6																							
																															E
																														<u> </u>	
																															F
	DDID OF C		DATUM / GEPRÜFT																												
	BRIDGING WITH :		X 1 =					= ()	MONITOR E1.5 /100.3 E1.6 /100.2																X ⁶ =	<u> </u>	-\'	DEAD MA MS 1 /	N 2		
3			Gez. 27.04.04 Iweeih0 LIEBHERR WERK						CUT OFF DIAGRAM									Ident-Nr. 984061308							= \$20						
1 Än	derung	Datum N	Ausga	Dyright (c)	SWING Zeich-Nr. 3372-932.04.00.001-001											+ S20 Blatt 42 von 165															


























































































































































































































































1		2		3			4		5			6		7			8		\neg
ı	HEATING SWITCH =P2+P6-S626 OR PRESELECTOR CLOCK		3 V	SWITCH AT - 3 WAY VALVE -S90 CABIN		TEMPERATURE - SWITCH -S83		DIESEL ENGINE					ASTO- ATING	WATER CI	CIRCULATING PUMP WATER CIRCULATION -M9				A
	ON	OFF	CABIN WARM		CABIN COLD	<70°C±3	>=70°C±3	ON	OFF	ON	OFF	ON	OFF	ON	OFF				
	Х		Х			Х			Х	Х		Х		Х					
	Х		Х				Х		Х		Х	Х		Х					
	Х		Х			Х		Х			Х	Х		Х					
	Х		Х				Х	Х			Х	Х		Х					В
	Х				Х	Х			Х	Х		Х			Х				
	Х				Х		X		Х		Х	Х			Х				
	Х				Х	Х		X			Х		Х		Х				
	Х				Х		X	X			Х		Х		Х				
		Х	Х			Х			Х		Х		Х	X					C
		Х	Х				X		Х		Х		Х	Х					
		Х			Х	Х			Х		Х		Х		Х				
		Х			Х		X		Х		Х		Х		Х				
		Х	Х			Х		Х			Х		Х	Х					
		Х	Х				X	X			Х		Х	Х					E
		Х			Х	Х		Х			Х		Х		Х				
		Х			Х		Х	Х			Х		Х		Х				
			WARM WARM		2 3 3 COLD SECOND					ENGINE	CURRENTLESS WIET OUTLET								F
3 2		Gez. 27.04.04 weeih0 LIEBHERR WERK			HEATING ,				ldent-Nr.	984061308	•	•	= +	S20 S20	\dashv				
1	Datum N	Ausgabe ame	02.02.06 Datum	lwerof0	EHIN Copyri		FUNCTIONAL DIAGRAMM HEATING					Zeich-Nr.	3372-932.04.00.0	01-001		Blatt von	129 165	=	












































HOISTING , EXTEND , UP HOISTING , EXTEND , UP LOWERING , RETRACT , DOWN MAIN JIB LUFFING	SWING , SLEWING GEAR SWING LEFT
LOWEDING DETRACT DOWN	SWING LEFT
LOWERING , RETRACT , DOWN MAIN JIB LUFFING	
FREE , MOVING MAIN JIB LOWERING BOOM	SWING RIGHT
FORWARD, RIGHT MAIN JIB LUFFING	SLEWING GEAR CIRCULATION
BACKWARDS , LEFT BACKWARDS , LEFT LMB LUFFING AT OVERLOAD	HOIST GEAR , WINCH
T LIMITER AFTER TOP FOLDING JIB , LATTICE FLY JIB	ноок
± LIMITER AFTER BOTTOM FOLDING JIB LUFFING	HOIST GEAR HOISTING , WINCH WINDING ON
ANALOG FOLDING JIB LUFFING / LOWERING BOOM	HOIST GEAR LOWERING , WINCH UNWIND
DIGITAL TELESC. SECTION	₩INCH WOUND ON
ANGLE TELESCOPING	₩INCH UNWOUND
OPERATING LOGIC The transfer out	
PUMP TELESCOPING IN	
Sez. 27.04.04 Iweeih0 LIEBHERR WERK DESCRIPTION OF SYN	MBOLS Ident-Nr. 984061308

	1	2			3		4 5	6	7 8	
		BALLAST				LMB	LOAD MOMENT LIMITER	= <u>†</u> = = <u>‡</u> =	GRIPPER UNBOLTING	A
	1 -	INCLINING CAB AFTER TOP				NT	POWER PACK	====	GRIPPER UNLOCKED	
	√ □	INCLINING CAB AFTER BOTTOM	I			ZE	CENTRAL UNIT	====	GRIPPER INTERLOCKED	
	0 ⊕0	WIND WARNING				EP	INPUT BOARD	⊼ ≛	TELESC. SECTION UNBOLTING	
	s g	ERECTION				Ţ	TELESCOPIC BOOM	吊墨	TELESC. SECTION UNLOCKED	
		HOOTER				М	BOOM NOSE	Π 📥	TELESC. SECTION INTERLOCK	
	يحكي	OVERDRIVE				F	FIXED LATTICE JIB , AUXILIARY JIB	ΠΦ-	TELESC. SECTION INTERLOCKED	
	₽	SUPERSTRUCTURE , SUPERSTR	RUCTURE			KS DKS	FOLDING JIB DOUBLE FOLDING JIB	- Rt⊒ -	GRIPPER EXTEND	
_	-	VEHICLE, EXCESS PRESSURE				Д	CYLINDER	Π.⊒ =	GRIPPER RETRACT	
		PROXIMITY SWITCH				Ī	GRIPPER	∏t⊒ I	TELESC. SECTION EXTEND	
		MASTER SWITCH					INTERLOCKED , INTERLOCKED	∏	TELESC. SECTION RETRACT	
	MS MS<>0	MASTER SWITCH ZEROLAGE MASTER SWITCH (N	NOT)				UNLOCKED , UNLOCKED	Ī → ∏	GRIPPER AT POSITION	
	-							•		
3			Gez.	27.04.04	lweeih0	LIEBHERR WERK	DESCRIPTION OF SYMBOLS		Ident-Nr. 984061308	
1	Änderung	Datum Name	Ausgabe	02.02.06 Datum	lwerof0 Name	EHINGEN Copyright (c)			Zeich-Nr. 3372-932.04.00.001-001 Blatt 149 von 165	
	Additionally	Dutum Hame	1	Dataili	numi	Copyright (c)			100	_

	1	2			3		4	5	6	7		8	
		A				LMB	232 LUFFING AT OVERLOAD			D			A
	¥ T	OUTRIGGERS DOWN								DOLLY OPERATION			
		OUTRIGGERS UP							C+	SLEWING PLATFORM ADJUSTMENT , SUPERSTRUCTURE INTERLOCKED			
	▼▼	OUTRIGGERS - PROGRAM END					В		<u> </u>	SLEWING PLATFORM ADJUSTMENT , SUPERSTRUCTURE UNLOCKED			В
		OUTRIGGERS , SELECTION OUTRIGGER				26.5 V	BATTERY - VOLTAGE , CHARGE CONTROL						
	"	OUTRIGGERS , OUTRIGGER EXTEND					BALLAST UP / DOWN						C
		OUTRIGGERS , OUTRIGGER RETRACT					215 LIGHTING WINCH						
		156 * WORKING PROJECTOR AT BOOM	М			0. K.	IMAGE CHANGE , CHANGE OVER						
	Mil	75 WORKING PROJECTOR AFTER F	FRONT				379 FLASHING LIGHT , FLIGHT WARNING LAMP						E
		170 WORKING PROJECTOR AFTER R	REAR										-
	1	212 WORKING PROJECTOR WITH AC	CTUATING DR	IVE									F
		76 INSTRUMENT LIGHTING											
,	REMARK : FOR INSTANCE N	MAKRO SWF_156											
3			Gez.	27.04.04	lweeih0	LIEBHERR WERK		DESCRIPTION OF SYMBOLS		ldent-Nr. 984061308	=	S20 S20	
1	Änderung	Datum Name	Ausgabe	02.02.06 Datum	lwerof0 Name	Copyright (c)	_			Zeich-Nr. 3372-932.04.00.001-001	Blatt	150	

	1		2			3		4	5	6		7	8		
		F						G			Н				Α
		379 * FLIGHT WARN FLASHING LIG						TRANSMISSION - FAILURE		TS	HOOK TOP ,	TOP OF LIFT			
	(P)	104 RADIO , RADIO)								86 HEATING : C	COMPLEMENTARY HEATING			
											207 HOOTER			- E	В
										→ → → → → → → → → → → → → → → → → → →	218 PRE-HEATIN	IG HYDRAULIC OIL			_
															С
															Е
															F
	* REMARK : FOR INSTANCE	MAKRO SWF_104									1				
3				Gez.	27.04.04	lweeih0	LIEBHERR WERK		DESCRIPTION OF SYMBOLS		ldent-Nr.	984061308	= +	\$20 \$20	\dashv
1	<u>.</u>			Ausgabe	02.02.06	lwerof0	EHINGEN	_			Zeich-Nr.	3372-932.04.00.001-001	Blatt	151	コ
	Änderung	Datum	Name		Datum	Name	Copyright (c)					33.2 332.3 1.00.00 1 00 1	von	165	_'


	1		2			3		Δ	5	6	7	8		_
	· · · · · · · · · · · · · · · · · · ·	·			·	<u> </u>	1	Т	U	•	1			
								L			M			Α
	深	3 * INDOOR LIGHT	ΓING				= + 26.5 v	CHARGE CONTROL , BATTERY - VOLTAGE			MANUAL-PRESSURE INCREASE			
							= +	25 CHARGE CONTROL		25	211 ERECTION			
								LOAD MOMENT LIMITER - BUZZER OFF			ENGINE : COOLING WATER - TEMPERATURE			В
								120 AIR PRESSURE < 5BAR			ENGINE : OIL PRESSURE			
		K						AIR FILTER , AIR FILTER CONTAMINATION		6.5	ENGINE : OIL PRESSURE			С
		244 Inclining Cai	В					AIR FILTER , AIR FILTER CONTAMINATION			ENGINE - FAILURE			
	***	7 AIR CONDITIO EQUIPMENT	NING							8	ENGINE STOP			
		COOLING WA								(<u>)</u>	PREHEATING ENGINE			Ε
		COOLING WA	TER - TEMPERATU	JRE										
	**** 85	COOLING WA	TER - TEMPERATU	JRE							N			
										0.2° 0.0 0.0	LEVELLING , LEVEL			F
	* REMARK : FOR INSTANCE N	IAKRO SWF 3									<u>I</u>		_	
ار				Ι.	0=0.00	1 "-		1			T., .,,	1 _	000	
2				Gez.	27.04.04	lweeih0	LIEBHERR WERK EHINGEN		DESCRIPTION OF SYMBOLS		Ident-Nr. 984061308		S20 S20	_
1	Änderung	Datum	Name	Ausgabe	02.02.06 Datum	lwerof0 Name	Copyright (c)				Zeich-Nr. 3372-932.04.00.001-001	Blatt	152 165	_

		11		2		<u> </u>	3			4		5		6			7	8		٦
			0							S					BUZZER (DFF				A
										100 WINDSCREEN WIPER ROOF	=									
								F	7	99 WINDSCREEN WIPER FRON	IT									
			Р					T T		180 WINDSCREEN WIPER / WIP ROOF	E-WASH									В
			361 * PLATFORM EX	XTEND / RETRACT						179 WINDSCREEN WIPER / WIP FRONT	E-WASH									
								Ĩ.	_	103 OUTRIGGER - MONITORING					Т					C
			R							16 GREASING				40	TANK CO	NTENTS EXCESS F	PRESSURE			
			RADIO , RADIO)						73 OVERDRIVE				100	TANK CO	NTENTS SUPERST	RUCTURE			
			5 WARNING BEA	ACON					Λ	174 SEAT HEATING				m 3.0	TELESCO	PIC BOOM :	RADIUS , ANGLE			E
									1 1	83 REAR MIRROR HEATING				m 9.2		PIC BOOM - LENG	гн			
								G		80 SOCKET				<u>/</u>	TELESCO (SELECT	PING / LUFFING ION)				
										FAILURE TRANSMISSION				H &	214 TELE DIS	MANTLING				
	* R	EMARK : FOR INSTANCE	MAKRO SWF_361					!					l							
3 2					Gez.	27.04.04	lweeih0	LIEBHERR			DESCRIF	PTION OF SYMBOLS	}		ldent-Nr.	984061308		= +	S20 S20	<u></u>
1			1	1	Ausgabe	02.02.06	lwerof0	Links	L11						Zeich-Nr.	2272 022 04	00 004 004	Blatt	153	

3372-932.04.00.001-001 Änderung Datum Datum Name Name Copyright (c)

	1		2			3		4	5	6		7		8	— 1
		Т						U			Z				A
		233 * TELESC. SECTION	ON UNLOCKED					OVERLOAD - BUZZER OFF		6	17 CENTRAL GREA	SING			
		245 TELESC. SECTIO	ON INTERLOCKED)			0. K.	CHANGE OVER , IMAGE CHANGE			86 COMPLEMENTA	RY HEATING			
		TELESC. SECTION	ON 1 SELECTED								236 CYLINDER UNLC	OCKED			В
	2	TELESC. SECTION	ON 2 SELECTED					V			235 CYLINDER INTER	RLOCKED			_
	3	TELESC. SECTION	ON 3 SELECTED				000	296 PREHEAT			161 CYLINDER AT PO	OSITION			C
	4	TELESC. SECTION	ON 4 SELECTED				()	PREHEATING ENGINE							
	5	741 TELESC. SECTION	ON 5 SELECTED												
	85	TEMPERATURE	COOLING WATER	R											E
								W							_
								WATER LEVEL , LEVEL , COOLING WATER - LEVEL							
							<u>/</u>	249 LUFFING / TELESCOPING (SELECTION)							F
*	* REMARK : FOR INSTANCE N	MAKRO SWF_233													
3 2				Gez.	27.04.04	lweeih0	LIEBHERR WERK EHINGEN	DESC	CRIPTION OF SYMBOLS			34061308	= +	S20 S20	<u>-</u>
1	Änderung	Datum	Name	Ausgabe	02.02.06 Datum	lwerof0 Name	Copyright (c)				Zeich-Nr.	372-932.04.00.001-001	Blatt		_

ISTINGUISHING \$	IGN S'	YSTEM			DISTINGUISHING SIGN	TYPE OF MATERIAL	EXAMPLES	DISTINGUISHING	IGN LOCATIONS OF-ELECTRIC COMPONENTS
						•			+
	ELECTRICS CARRIER				Α	COMPONENTS, SUBASSEMBLIES	AMPLIFIERS, MAGNETIC AMPLIFIERS, LASER-EQUIPMENT COMBINATIONS	F1-9	ELECTRICS CARRIER
no	ELECTRICS DRIVER'S- EDITROLS AND FITTING		IDE		ь		DIGUARIES AND WIGHTINGS TRANSPORTED THERMS OF FOUR SERVICES OF THE DAY OF THE	H1-9	ELECTRICS DRIVER'S- 66ATROLS AND FITTING EXCESS PRESSURE
2			JKE		В	CONVERTERS FROM NON-ELECTRIC VALUES-TO ELECT	RIC VALUES-MIEXISEUTERSS TRANSDUCER , THERMO-ELECTRIC SENSORS , THERMO-CELLES , THERMO-ELECTRIC CELLS , DYNAMOMETER , QUARTZ CRISTALS ,	P20-29	
61-10	SWITCH CABINET EXCES: OUTRIGGERS	S PRESSURE					THERMO-ELECTRIC CELLS , DYNAMOMETER , QUARTZ CRISTALS , MICROPHONE , PICK-UPS , SYNCHRO-GENERATOR , ANGLE SENSOR,(ANGLE TRANSI	MTTER) 1 - 9 P30-39	SWITCH CABINET EXCESS PRESSURE
23	LIGHTING EXCESS PRESS	NIDE				CAPACITORS		P30-39	OUTRIGGERS LIGHTING EXCESS PRESSURE
1-33	EXTRA EQUIPEMENT EXC				r l	TIME-LAG DEVICES-MEMORY DEVICES-BINARY CELLS	DELAY LINES , LOGIC ELEMENTS ,	1 *4	EXTRA EQUIPEMENT EXCESS PRESSURE
.1-33	EXTRA EQUIPEINIENT EXC	ESS FRESSURE			U	TIME-LAG DEVICES-WEMONT DEVICES-DINANT CELES	CORE MEMORIES , REGISTER , DISK MEMORIES , MAGNETIC TAPE RECORDING EQUIPMENT , MONOSTABLE ELEMENTS		EXTRA EQUIPEMENT EXCESS PRESSURE
					E	MISCELLANEOUS	LIGHTING EQUIPMENT, HEATING DEVICES		
	ELECTRIES SUPERSTRUC	TURE			F	PROTECTIVE RELAYS	FUSES , SWITCHING RELAY , SWITCH FUSES	D1-9	ELECTRIES SUPERSTRUCTURE
	ELECTRIES CABIN				G	GENERATORS,	GENERATORS, BATTERIES, OSCILLATORS,	K1-9	ELECTRIES CABIN
1	CONTROLS AND FITTING		IRE			POWER SUPPLIES	PHASE ADVANCERS , POWER SUPPLY DEVICES	P1-9	CONTROLS AND FITTING SUPERSTRUCTURE
20-30	SWITCH CABINET SUPER				H	SIGNALLING DEVICES	VISUAL AND AUDIBLE INDICATORS	S20"1"-"9"	SWITCH CABINET SUPERSTRUCTURE
1	LIGHTING SUPERSTRUCT	URE			K	RELAY, CONTACTORS	POWER RELAYS, CONTACTOR RELAYS, BLINKER RELAYS	*1	LIGHTING SUPERSTRUCTURE
	LMB				L	INDUCTANCES	CHOKING COILS	*1	LMB
34-66	EXTRA EQUIPEMENT SUP	ERSTRUCTURE			M	ENGINE		*1	EXTRA EQUIPEMENT SUPERSTRUCTURE
					N	SLIP RIING TRANSMISSION			
					۲	MEASURING EQUIPMENT , TESTING DEVICES	DISPLAYING, WRITING AND COUNTING MEASURING DEVICES , PULSE GENERATOR , CLOCKS		
	ELECTRIES BOOM				Q	POWER CURRENT - JUMPER WIRES	POWER SWITCH , ISOLATING SWITCH , PROTECTIVE SWITCH , ENGINE PROTECTION SWITCH , AUTOMATIC SAFETY SWITCHES	A1-9	ELECTRIES BOOM
.	AUXILIARY JIB				$_{R}$	RESISTORS	ADJUSTABLE RESISTORS, POTENTIOMETER	Q1-9	AUXILIARY JIB
v	LUFFING JIB				Ŝ	SWITCH, SELECTOR	PUSH-BUTTON SWITCH, LIMIT SWITCH, CONTROL SWITCH, SELECTOR,	W1-9	LUFFING JIB
'	FOLDING JIB				_		REVOLUTION SELECTOR , COUPLING STEP , SIGNAL TRANSMITTER , SELECTOR	V1-9	FOLDING JIB
30-40	SWITCH CABINET / TERM				Ĭ	TRANSFORMERS	VOLTAGE CONVERTER, CURRENT TRANSFORMER, TRANSMITTER	S30"1"-"9"	SWITCH CABINET / TERMINAL BOX
67-99	EXTRA EQUIPEMENT BOC	DM			Ų	MODULATORS, CONVERTERS	DISCRIMINATOR, FREQUENCY CONVERTER, TRANSFORMER	*1	EXTRA EQUIPEMENT BOOM
					V	TUBES - SEMICONDUCTOR	ELECTRON TUBES , GAS-FILLED TUBES , DIODES		
					W	COMMUNICATION CIRCUITS , WAVE GUIDE , CIRCUITS	JUMPERS, WIRING, BUS BARS, WAVE GUIDE, DIRECTIONAL WAVEGUIDE COUPLERS		
					Х	CRAMP , PLUG , SOCKET	CONNECTING PLUG , ISOLATING SOCKETS , TEST PLUG , CONNECTOR BLOCKS , TAG BLOCKS		
					Υ	ELECTRIC OPERATED-MECHANICAL DEVICES	BRAKES, COUPLINGS, VALVES		
					Z	TERMINATION, EQUALIZERS, FILTERS,-DELIMITERS, CABLE CONNECTIONS	CABLE BALANCES , DYNAMIC REGULATOR , CRYSTAL FILTER		
				<u>'</u>			EXAMPLE OF A MATERIAL	IDENTIFICATION	
							= SYSTEM + LOCATION	1 . Γ	TYPE OF MATERIAL COUNTING NUMBER 'COU
*1 LOCATI	ONS ON THE EXISTING COMP	ONENTS] . [
							= A + \$1	-	X :
			Gez.	27.04.04	lweeih0	LIEBHERR WERK	KEY OF SYMBOLS	dent-Nr. 984(061308
				ļ		4	NET UF STRIDULS	5510	+
			Ausgabe	02.02.06	lwerof0	EHINGEN		Zeich-Nr.	Blatt



1		2			3			4		5		6			7		8	
ВМК	SYSTI	EM	PLA	CE	SHEET	BM	1K	S	YSTEM	PLACE	SHEET	ВМ	K	S	YSTEM	PLACE	SHEET	
-A1 =K	+K3	127.3				-B4	=A	+A	76.1			-B62	=D	+D2	57.7			
-A2 =K	+K3	127.7				-B6	=A	+A5	76.3			-B86	=Z59	+K1	126.7			
-A11 =D	+D2	58.5				-B7	=A	+A	76.2			-E1	=A	+A5	122.6			
-A14 =S20	+S20	43.2				-B11	=D	+D2	93.4			-E1A	=A	+A5	122.6			
-A15 =S20	+S20	88.6				-B12	=D	+D2	93.6			-E2	=A	+A5	122.7			
-A20 =S20	+S20	52.1				-B17	=F	+F1	96.1			-E2A	=A	+A5	122.7			В
-A50 =S20	+S22	144.3				-B19	=K	+K2	115.1			-E4	=D	+D2	133.5			
-A320 =D	+D2	139.1				-B25	=Z36	+K1	125.1			-E5	=D	+D2	133.5			
-A320.F1 =D	+D2	139.1				-B26	=Z30	+D2	95.3			-E6	=D	+D2	122.3			
-A320.F2 =D	+D2	139.3				-B26	=Z36	+K1	125.3			-E7	=D	+D2	122.5			
-A330 =D	+D2	139.3				-B27	=Z30	+D2	95.4			-E8	=Z38	+K1	133.7			C
-A330 =D	+D2	138.1				-B28	=Z30	+D2	95.2			-E9	=Z38	+A	134.4			
-A330.F1 =D	+D2	139.4				-B29	=K	+K2	55.1			-E10	=Z56	+A5	137.3			
-A330.F1 =D	+D2	138.1				-B30	=K	+K2	97.6			-E11	=D	+D2	122.4			
-A330.F2 =D	+D2	139.5				-B31	=D	+D2	55.6			-E12	=D	+D2	122.5			
-A330.F2 =D	+D2	138.3				-B32	=D	+D2	55.7			-E14	=D	+D2	133.3			E
-A340 =D	+D2	139.6				-B33	=D	+D2	53.3			-E15	=Z38	+A	134.5			
-A340 =D	+D2	138.6				-B34	=D	+D2	53.4			-E15.	=Z38	+A	134.7			
-A340.F1 =D	+D2	139.6				-B35	=D	+D2	54.5			-E16	=Z66	+A5	136.5			
-A340.F1 =D	+D2	138.6				-B36	=D	+D2	54.6			-E17	=A	+A	135.3			
-A340.F2 =D	+D2	138.8				-B37	=D	+D2	54.3			-E18	=A	+A	135.7			
-A340.F2 =D	+D2	139.8				-B38	=D	+D2	53.1			-E19	=Z67	+K1	133.7			
-B1 =Z84	+A5	77.4				-B39	=D	+D2	54.7			-E20	=P1	+P1	66.5			
-B2 =D	+D2	93.2				-B55	= A	+A8	78.3			-E23	=Z56	+A5	136.6			
3 2			Gez.	27.04.04	lweeih0	LIEBHER				OPERATING EQUIPM	1ENT		Ident-N	984	061308		= S20 + S20	
1 Änderung	Datum	Name	Ausgabe	02.02.06 Datum	lwerof0	EHIN							Zeich-N	ir. 337	/2-932.04.00.001-0)01 —	157 ron 165	

1		2	I		3			4		5		6			7		8	
ВМК	SYSTEM		PLACE	SH	IEET	BMŁ	<	SY	STEM	PLACE	SHEET	ВМК		SYS	STEM	PLACE	SHEET	
-E49 =S20	+S20 66	5.8				-F62	=D	+D3	43.6			-K14	=S20	+S20	100.3			A
-E60 =D	+D 123.4	4				-G1	=D	+D2	43.4			-K15	= S20	+S20	43.2			
-E63 =D	+D2 122.	.1				-G2	=D	+D3	43.7			-K16	= S20	+S20	126.6			
-E65 =D	+D2 122.	.1				-G3	=D	+D3	43.7			-K17	= S20	+S20	126.3			
-E66 =A	+A5 122.	.2				-G6	=Z25	+H0	66.1			-K18	= S20	+S20	83.7			
-E67 =A	+A5 122.	.1				-GSM.S	1 =S20	+\$2	20 68.3			-K19	= S20	+S20	126.7			В
-E68 =A	+A5 122.	.1				-H21	=K	+K1	98.4			-K20	= S20	+S20	92.3			
-E69 =A	+A5 122.	.3				-H46	= S20	+S20	106.7			-K21	= S20	+S20	126.4			
-E70 =A	+A5 122.	.4				-H80	=D	+D2	98.3			-K22	= S20	+S20	100.4			
-E71 =A	+A5 122.	.4				-H94	=K	+K1	123.8			-K23	= S20	+S20	102.2			
-E73 =D	+D2 122	.2				-H95	=Z36	+K1	125.2			-K24	= S20	+S20	109.4			
-E74 =D	+D2 122	.2				-H101	=P1	+P1	51.4			-K25	= S20	+S20	102.3			
-E75 =D	+D2 122	.3				-H102	=P1	+P1	51.4			-K26	= S20	+S20	58.3			
-E96 =K	+K1 123.	.3				-H105	=P1	+P1	52.7			-K27	= S20	+\$20	132.1			
-E330 =D	+D2 139	9.4				-H106	=P1	+P1	52.7			-K28	= S20	+S20	133.4			
-E330 =D	+D2 138	3.3				-H423	=P5	+P4	97.8			-K29	= S20	+S20	108.2			E
-E331 =D	+D2 138	3.2				-H612	=P2	+P6	110.3			-K30	= S20	+\$20	110.1			
-E331 =D	+D2 139	9.3				-H613	=P2	+P6	101.5			-K31	= S20	+S20	135.2			
-E333 =D	+D2 139	9.2				-H627	=Z39	+P6	131.5			-K32	= S20	+\$20	135.1			
-E333 =D	+D2 138	3.1				-H628	=P2	+P6	126.7			-K33	= S20	+S20	135.2			
-E600 =P2	+P6 123	3.5				-K1	= S20	+S20	61.4			-K34	= S20	+S20	136.2			
-F49 =Z47	+K1 137	7.8				-K11	= S20	+S20	86.5			-K35	= S20	+S20	131.7			
-F60 =D	+D3 43.4	1				-K12	= S20	+S20	88.5			-K36	= S20	+S20	57.7			
-F61 =D	+D3 43.5	5				-K13	= S20	+S20	102.2			-K37	= S20	+S20	95.1			
3 2			Gez. 27.0	4.04 lwee	eih0	LIEBHERR				OPERATING EQUIPM	MENT		Ident-N	984061	1308		= \$20 + \$20	
1 Änderung	Datum	Name	Ausgabe 02.0		rof0	EHING							Zeich-N	r. 3372-9	32.04.00.001-00)1 ⊢	S20 Blatt 158 von 165	

	1		2			3			4		5		6			7		8	
ВМИ	(SYSTE	EM	PLA	CE	SHEET	BMł	<	SY	STEM	PLACE	SHEET	ВМИ	(SY	STEM	PLACE	SHEET	-
-K38	= S20	+S20	101.7				-M10	=K	+K1	132.5			-R53	=S2	+\$20	102.7			A
-K39	= S20	+S20	134.2				-M11	= S20	+S20	63.6			-R59	=S2	+\$20	102.4			
-K51	= S20	+S22	84.5				-M13	=Z30	+D2	95.7			-S1	=D	+D3	43.5			
-K52	= S20	+S22	85.4				-M14	=K	+K1	123.6			-S26	=D	+D2	106.3			
-K53	= S20	+S22	84.3				-M23	=A	+A	135.3			-S27	=D	+D2	106.4			
-K54	= S20	+S22	85.4				-M168	=D	+D2	142.4			-S28	=D	+D2	106.5			В
-K55	= S20	+S22	89.2				-N1	=A	+A	142.1			-S29	=D	+D2	106.6			
-K56	= S20	+S22	84.4				-N1	=F	+F1	142.1			-S30	=D	+D2	105.3			
-K57	= S20	+S22	85.3				-N2	=A	+A	142.1			-S31	=D	+D2	109.4			
-K58	= S20	+S22	92.4				-N2AS	= A	+A	137.5			-S32	=D	+D2	105.3			
-K59	= S20	+S22	92.5				-N3	=A	+A	142.2			-S34	=D	+D2	96.3			
-K60	= S20	+S22	97.5				-P2	=D	+D5	86.2			-S35	=D	+D2	96.4			
-K61	= S20	+S22	90.8				-P12	=D	+D2	107.5			-S49	=D	+D2	86.1			
-K62	= S20	+S22	84.3				-P654	=P2	+P6	126.3			-S69	=D	+D2	110.3			
-K651	=P2	+P6	124.3				-P655	=P2	+P6	52.8			-S72	=D	+D2	107.7			
-K652	=P2	+P6	124.7				-R1	=D	+D2	133.3			-S73	=D	+D2	107.6			E
-M1	=D	+D2	43.5				-R2	=Z55	+K1	132.3			-S77	=Z39) +D2	131.7			
-M2	=D	+D2	109.5				-R3	=Z55	+K1	132.4			-S78	=Z39	+K1	131.7			
-M3	=K	+K1	124.1				-R4	=D	+D2	57.4			-S81	=S2	+\$20	100.3			
-M4	=K	+K1	124.5				-R9	=D	+D2	52.2			-S83	=Z3	' +K3	126.4			
-M5	=K	+K3	126.2				-R21	=D	+D3	43.8			-S84	=Z48	3 +K1	43.2			
-M6	=K	+K1	124.3				-R50	= S20	+S20	102.3			-S89	=K	+K3	126.1			
-M7	=K	+K1	124.7				-R51	= S20	+S20	102.4			-S90	=K	+K3	126.3			
-M9	=K	+K3	126.3				-R52	= S20	+S20	102.4			-S99	=K	+K1	82.6			
3				Gez.	27.04.04	lweeih0	LIEBHERR				OPERATING EQUIPM	IENT		Ide	nt-Nr. 9840	061308	-	= S20 + S20	
1 Ä	nderung	Datum	Name	Ausgabe	02.02.06 Datum	lwerof0 Name	EHING							Ze	ch-Nr. 3372	2-932.04.00.001-0	\n1 ⊢	Blatt 159 von 165	

1			2			3			4		5		6			7		8	
BMK		SYSTE	M	PLA	CE	SHEET	BMK	(SY	STEM	PLACE	SHEET	BMK	(SY	STEM	PLACE	SHEET	
-S103 =F	P1	+P1	44.3				-S428	=P5	+P4	120.2			-S902	=A	+A	75.3			
-S104 =F	P1	+P1	46.2				-S602	=P2	+P6	124.5			-S903	=A	+A	75.4			
-S301 =F	P5	+P3	83.5				-S604	=P2	+P6	124.7			-S904	=A	+A	75.5			
-S301 =F	P5	+P3	82.4				-S606	=P2	+P6	124.1			-S905	=A	+A	75.6			
-S301 =F	P5	+P3	84.2				-S608	=P2	+P6	124.3			-S908	=A	+A	101.6			
-S320 =F	P5	+P3	115.3				-S610	=P2	+P6	121.4			-S912	=A	+A	74.4			В
-S321 =F	P5	+P3	118.2				-S618	=P2	+P6	101.4			-S913	=A	+A	74.7			
-S322 =F	P5	+P3	89.3				-S620	=P2	+P6	102.6			-S914	=A	+A	74.5			
-S323 =F	P5	+P3	98.1				-S622	=P2	+P6	102.5			-S915	=A	+A	74.6			
-S324 =F	P5	+P3	57.1				-S626	=Z37	+P6	126.5			-S918	=A	+A	74.2			
-S325 =F	P5	+P3	117.1				-S630	=Z39	+P6	131.4			-S919	=A	+A	74.3			
-S326 =F	P5	+P3	117.2				-S632	=P2	+P6	123.3			-S930	=A	+A5	77.1			
-S327 =F	P5	+P3	119.2				-S634	=Z71	+P6	133.3			-S940	=A	+A8	78.5			
-S328 =F	P5	+P3	119.2				-S636	=Z67	+P6	133.7			-S945	=A	+A9	78.6			
-S390 =[:D	+D2	139.5				-S638	=Z65	+P6	134.2			-T50	= S20	+S20	125.2			
-S390 =[:D	+D2	138.4				-S640	=Z66	+P6	135.2			-T51	= S20	+S20	125.5			
-S401 =F	P5	+P4	83.1				-S642	=Z66	+P6	135.5			-X1	=S20	+S20	143.1			
-S401 =F	P5	+P4	82.1				-S644	=Z49	+P6	137.1			-X2	=S20	+S20	143.1			
-S401 =F	P5	+P4	85.2				-S646	=Z55	+P6	132.3			-X3	= S20	+S20	143.1			
-S420 =F	P5	+P4	97.7				-S648	=P2	+P6	108.6			-X4	=S20	+S20	143.1			
-S421 =F	P5	+P4	107.3				-S650	=P2	+P6	123.1			-X5	=S20	+S20	143.1			
-S424 =F	P5	+P4	89.5				-S658	=P2	+P6	106.3			-X6	= S20	+S20	143.1			
-S425 =F	P5	+P4	107.3				-S660	=P2	+P6	105.1			-X7	= S20	+S20	143.1			
-S427 =F	P5	+P4	120.2				-S901	=A	+A	75.2			-X8	= S20	+S20	143.1			
3	I			Gez.	27.04.04	lweeih0	LIEBHERR				OPERATING EQUIPM	IENT	•	ldent-N	9840	61308	<u> </u>	= S20 + S20	
1 Änderung		Datum	Name	Ausgabe	02.02.06 Datum	lwerof0 Name	EHINGE Copyright (Zeich-P	Ir. 3372	-932.04.00.001-0	01 ⊢	320 3latt 160 von 165	

	1		2			3			4		5		6		1	7		8	
ВМ	<	SYSTE	М	PLA	CE	SHEET	ВМ	K	SYS	STEM	PLACE	SHEET	ВМК		SY	STEM	PLACE	SHEET	$\exists $
-X9	=S20	+S20	143.1				-X40	=S20	+S20	143.6			-X124	=P5	+P4	146.1			
-X11	=S20	+S20	143.1				-X45	= S20	+S20	142.5			-X126	=P5	+P4	146.3			
-X12	=S20	+S20	143.1				-X48	=S20	+S20	125.4			-X131	=K	+K1	146.1			
-X14	=S20	+S20	143.4				-X49	= S20	+S20	66.7			-X134	=Z36	+K1	146.1			
-X16	=S20	+S20	143.4				-X50	= S20	+S22	144.2			-X136	=K	+K1	146.3			
-X17	=S20	+S20	143.4				-X51	=S20	+S22	144.2			-X137	=K	+K1	146.1			В
-X20	=S20	+S20	143.4				-X52	= S20	+S22	144.2			-X138	=K	+K1	146.3			
-X21	=S20	+S20	143.4				-X53	= S20	+S22	144.2			-X139	=K	+K1	146.1			
-X22	=S20	+S20	143.4				-X54	=S20	+S22	144.2			-X142	=K	+K1	146.3			
-X24V	= S20	+S20	144.1				-X55	= S20	+S22	144.2			-X143	=K	+K1	146.1			
-X26	=S20	+S20	143.4				-X56	= S20	+S22	144.4			-X144	=P2	+P6	146.3			
-X27	=S20	+S20	143.4				-X57	= S20	+S22	144.4			-X146	=P2	+P6	146.1			
-X28	=S20	+S20	143.6				-X60	= S20	+S20	144.2			-X147	=P2	+P6	146.2			
-X29	=S20	+S20	143.6				-X70	=S20	+S20	33.1			-X148	=P2	+P6	146.3			
-X30	=S20	+S20	143.6				-X71	=S20	+S20	34.1			-X150	=P2	+P6	146.3			
-X31	=S20	+S20	143.6				-X72	=S20	+S20	35.1			-X181	=K	+K3	146.1			E
-X32	=S20	+S20	143.6				-X77	= S20	+S20	32.2			-X182	=K	+K3	146.2			
-X33	=S20	+S20	143.6				-X96	=S20	+S20	144.2			-X183	=K	+K3	146.3			
-X34	=S20	+S20	143.6				-X101	=P1	+P1	146.1			-X184	=K	+K3	146.4			
-X35	=S20	+S20	143.6				-X103	=P1	+P1	146.3			-X185	=K	+K1	146.5			
-X36	=S20	+S20	143.6				-X109	=P1	+P1	146.3			-X190	=K	+K2	146.4			
-X37	=S20	+S20	143.6				-X111	=P5	+P3	146.1			-X191	=K	+K2	146.5			
-X38	=S20	+S20	143.6				-X115	=P5	+P3	146.3			-X192	=K	+K2	146.4			
-X39	=S20	+S20	143.6				-X121	=P5	+P4	146.1			-X201	=Z39	+D2	146.4			
3				Gez.	27.04.04	lweeih0	LIEBHERF				OPERATING EQUIPM	· /ENT	•	Ident-Nr	9840	061308	· -	= S20 + S20	
1 2	inderung	Datum	Name	Ausgabe	02.02.06 Datum	lwerof0	EHING							Zeich-N	r. 3372	2-932.04.00.001-0	ı∩1 ⊢	Blatt 161 von 165	

1			2			3			4		5		6			7		8	
ВМК		SYSTE	EM	PLA	CE	SHEET	BMK		SYS	STEM	PLACE	SHEET	BMK		SYS	TEM	PLACE	SHEET	
-X202	=D	+D2	146.5				-X272	=D	+D2	146.7			-X635A	=S20	+S20	34.1			A
-X203	=D	+D2	146.4				-X298	=D	+D2	139.8			-X635B	=S20	+S20	35.1			
-X204	=D	+D2	146.5				-X298	=D	+D2	138.8			-X650	=S20	+S20	144.2			
-X205	=D	+D2	146.4				-X306	=D	+D6	146.7			-X661	= S20	+S20	30.2			
-X209	=Z39	+D2	146.5				-X335	=D	+D2	138.2			-X662	= S20	+S20	30.3			
-X217	=D	+D2	146.4				-X335	=D	+D2	139.3			-X663	= S20	+S20	30.1			В
-X247	=D	+D2	146.5				-X451	=A	+A5	147.1			-X664	= S20	+S20	30.1			
-X250	=D	+D2	146.4				-X456	=A	+A	147.1			-X665	=S20	+S20	30.1			
-X250A	=D	+D2	146.5				-X456B	=A	+A	147.1			-X700	= S20	+S20	144.4			
-X251	=D	+D2	146.4				-X483	=A	+A5	147.3			-X701	=S20	+S20	31.5			
-X252	=D	+D2	146.5				-X501	=A	+A8	147.1			-X702	=S20	+S20	31.1			
-X253	=D	+D2	146.4				-X502	=A	+A9	147.1			-X703	=S20	+S20	31.1			
-X254	=D	+D2	146.5				-X504	=A	+A8	147.3			-X704	=S20	+S20	31.2			
-X255	=D	+D2	146.4				-X505	=A	+A9	147.3			-X705	= S20	+S20	31.5			
-X256	=D	+D2	146.5				-X519	=K	+K1	66.6			-X706	=S20	+S20	144.7			
-X257	=D	+D2	146.4				-X540	=A	+A	147.1			-X708	= S20	+S20	144.8			E
-X258	=D	+D2	146.5				-X541	=A	+A5	147.1			-X900	= S20	+S20	145.1			
-X259	=D	+D2	146.7				-X556H	=A	+A4	147.1			-X901	= S20	+S20	145.1			
-X260	=D	+D2	146.8				-X556W	=A	+A4	147.3			-X902	= S20	+S20	145.1			
-X262	=D	+D2	146.7				-X574	=Z38	+A	147.1			-X903	= S20	+S20	145.1			
-X268	=D	+D2	146.7				-X630	=A	+A	147.3			-X904	= S20	+S20	145.1			
-X269	=D	+D2	146.8				-X631	=P1	+P2	146.1			-X905	=S20	+S20	145.1			
-X270	=D	+D3	146.7				-X633	=A	+A	147.3			-X906	= S20	+S20	145.1			
-X271	=D	+D2	146.8				-X635	=S20	+S20	33.1			-X907	= S20	+S20	145.1			
3				Gez.	27.04.04	lweeih0	LIEBHERR V				OPERATING EQUIPM	IENT		Ident-Nr.	9840613	308		= S20 + S20	
1 Änder	rung	Datum	Name	Ausgabe	02.02.06 Datum	lwerof0	EHINGE Copyright (c)							Zeich-Nr.	3372-93	2.04.00.001-00)1 ⊢	320 Slatt 162 ron 165	

	1		2			3			4		5		6			7		8	
ВМК	,	SYSTEM	M	PLA	CE	SHEET	BMł	(SYS	STEM	PLACE	SHEET	ВМК		SY	'STEM	PLACE	SHEE	ET
-X908	=S20	+S20	145.1				-XM5	=S20	+S20	50.4			-Y23	=D	+D2	105.2			A
-X909	=S20	+S20	145.1				-XM6	= S20	+S20	50.4			-Y26	=D	+D2	52.5			
-X910	=S20	+S20	145.4				-XM160	=D	+D2	146.7			-Y27	=D	+D2	57.5			
-X913	=S20	+S20	145.4				-XM304	.1 =D	+D2	146.7			-Y28	=Z37	+K3	126.5			
-X914	=S20	+S20	145.4				-XM304	.2 =D	+D2	146.7			-Y31	=D	+D2	94.4			
-X916	= S20	+S20	145.4				-XM304	.3 =D	+D2	146.7			-Y32	=D	+D2	94.5			В
-X917	=S20	+S20	145.4				-XM304	.4 =D	+D2	146.7			-Y38	=D	+D2	92.3			
-X918	=S20	+S20	145.4				-XTest-l	SB =S20	+S2	20 145	.5		-Y40	=A	+A	92.6			
-X919	= S20	+S20	145.4				-Y1a	=D	+D2	87.2			-Y49	=D	+D2	91.1			
-X920	=S20	+S20	145.6				-Y1b	=D	+D2	87.3			-Y56	=D	+D2	57.6			
-X921	=S20	+S20	145.6				-Y3	=D	+D2	87.5			-Y59	=D	+D2	108.3			C
-X922	=S20	+S20	145.6				-Y4a	=D	+D2	90.3			-Y66	=D	+D2	97.1			
-X923	=S20	+S20	145.6				-Y4b	=D	+D2	90.2			-Y67	=D	+D2	97.2			
-X924	=S20	+S20	145.6				-Y5	=D	+D2	90.4			-Y69	=D	+D2	110.2			
-X925	=S20	+S20	145.6				-Y6a	=D	+D2	91.4			-Y80a	=D	+D2	90.6			
-X926	=S20	+S20	145.6				-Y6b	=D	+D2	91.4			-Y80b	=D	+D2	90.6			E
-X927	=S20	+S20	145.6				-Y10	=D	+D2	90.1			-Y82	=D	+D2	90.7			
-X928	=S20	+S20	145.6				-Y11	=D	+D2	91.6			-Y85a	=D	+D2	107.6			
-X929	=S20	+S20	145.6				-Y12	=D	+D2	91.7			-Y85b	=D	+D2	107.7			
-XE49	= S20	+S20	144.1				-Y19a	=D	+D2	106.3			-Y103a	=D	+D2	107.3			
-XM1	=S20	+S20	50.1				-Y19b	=D	+D2	106.3			-Y103b	=D	+D2	107.3			
-XM2	=S20	+S20	50.1				-Y20	=D	+D2	97.4			-Y109	=D	+D2	97.5			
-XM3	=S20	+S20	50.1				-Y21	=D	+D2	97.6			-Y137	=Z39	+D2	131.4			
-XM4	= S20	+S20	50.4				-Y22	=D	+D2	105.1			-Y139	=Z37	+D2	126.7			
3 2				Gez.	27.04.04	lweeih0	LIEBHERR EHING				OPERATING EQUIPM	MENT		ldent-Nr.		061308			20
1 Än	derung	Datum	Name	Ausgabe	02.02.06 Datum	lwerof0 Name	Copyright		_					Zeich-Ni	3372	2-932.04.00.001-0	ı∩1 ⊢		63 65

1			2)		3		4	5		6		7		8	
BMK		SYSTE	ΞM	PLA	CE	SHEET	BMK	SYSTEM	PLACE	SHEET	BMK		SYSTEM	PLACE	SHEET	
-Y141 =)	+D2	108.6													
-Y142 =E)	+D2	108.6													
																B
																F
3				Gez.	27.04.04	lweeih0	LIEBHERR WERK		ODEDATING FOUR	4FNT	<u> </u>	Ident-Nr.	984061308		= \$20	
2				Ausgabe	02.02.06	lwerof0	EHINGEN		OPERATING EQUIPN	/I⊏N I		Zeich-Nr.		14	+ \$20 Blatt 164	
Änderung		Datum	Name		Datum	Name	Copyright (c)						3372-932.04.00.001-00	J I	von 165	

	1			2			3			4		5		6		7			8
	V	ERSION 001		\	/ERSION 002	2	VE	RSION 003	V	ERSION 004	V	ERSION 005	V	ERSION 006	V	/ERSION 007	\ \ \	/ERSION 008	
	SHEET	R	REMARK	SHEET	R	REMARK	SHEET	REMARK	SHEET	REMARK	SHEET	REMARK	SHEET	REMARK	SHEET	REMARK	SHEET	REMARK	
	47	F20 von 30A au geaendert	uf 20A																
	90	K56:31 - K62:11 K56:32 - A50:8 (K56:32 - K62:11	1 getrennt getrennt 1 verbinden																
		Beleuchtung Wi BMK E63 und E	nde2 ergaenzt																
-		Arbeitsscheinwe	erfer Xenon																
	134	pendelnd E15. h K39 zur Abschal	iinzu Itung hinzu																
-																			
				Gez.	27.04.04	lweeih0	LIEBHER	R WFRK						ldent-Nr.	08/06/200	=			
					Ausgabe	02.02.06	lwerof0	EHIN			N	MODIFICATIONS , VERSIC	ON		Zeich-Nr.	984061308		+ Blatt	_
	Änderung		Datum	Name	-	Datum	Name	Соругіс	ıht (c)	1						3372-932.04.00.001-0	01	von	