
Firmware compile & upload

Before proceeding, read the entire guide first.


- Download VS Code: <u>Link</u>
- Install PlatformIO plugin in the VS Code




• Go in PlatformIO




Open Project



- Select Firmwar Folder
- Click Open "Project"





If you want to change the pins or the display timeout time go to */scr/Settings.h

```
C Settings.h X
    V Orbion FW v0.26.4
      ∨ src
                                     #define NUMPIXELS
      C Bitmap.h
      @ main.cpp
                                     #define horzPin
      C Oled.h
                                     #define vertPin
C Settings.h
9
      .gitignore
                                     #define butFun2
      b platformio.ini
```

Once everything is ok, let's proceed with uploading the firmware to Orbion

- Connect the Arduino to the PC (It is recommended to assemble the Orbion first if you don't want to drive your PC crazy)
- In the blue bar at the bottom left, you will find an arrow (->), press it and the upload will start



If you are unable to upload because it is blocked, always click on the arrow (->) in the blue bar and click the Orbion reset button twice quickly