

Global Macro:		Quickflip =Additional action layer. Press multi-key at same time to do named action	
Press 0+15 =mode cycle	==>	Underglow LEDs:	Drum Machine
3+12 =Change underglow brightness			Device Nav Mode
			Clip Nav Mode

Modes:

1

Drum Machine Mode

0	1	2	3
4	5	6	7
8	9	10	11
12	13	14	15

Normal drum pad play mode

Macros: **3+15**=Disable/Enable QuickFlip pages

0+3=Active pads full page UP

0+3+1=Active pads one row UP

0+3+5=Active pads one row DOWN

12+15=Active pads full page DOWN

==>

QuickFlip1 - Quickpress 1+X for all actions

Global Play	1+X	Global Stop	Global record
Clip Left		Clip Right	Global Undo
Toggle Arm	Toggle Overdub	Clip Delete	*State aware (looper)
Play Clip	Stop Clip	Record Clip	New Clip

*State aware will cycle thru Clip Record
Clip play, Clip overdub

Quickflip enable/disable only available on
drum machine mode

==>

QuickFlip2 - Quickpress 5+X for all actions

	5+X		
Launch Scene 1	Launch Scene 2	Launch Scene 3	Launch Scene 4
Launch Scene 5	Launch Scene 6	Launch Scene 7	Launch Scene 8

2

Device Nav Mode

Global Play	Up (track)	Global Stop	Global record
Prev Device	Down (track)	Next Device	Global Undo
Toggle Arm	Toggle Overdub	show/hide expand view device	add device after
Prev RemotePg	expand remote	expand device	Next RemotePg

==>

QuickFlip1 - Quickpress 1+X for all actions

	1+X		
		Delete Device	

3

Clip Nav Mode

Global Play	Up	Global Stop	Global record
Left	Down	Right	Global Undo
Toggle Arm	Toggle Overdub	Clip Delete	state aware
Play Clip	Stop Clip	Record Clip	New Clip

==>

QuickFlip2 - Quickpress 5+X for all actions

	5+X		
Launch Scene 1	Launch Scene 2	Launch Scene 3	Launch Scene 4
Launch Scene 5	Launch Scene 6	Launch Scene 7	Launch Scene 8