

# Temperature & Humidity Sensor Beacon

# **User Manual**

V 1.0



BEC07-7



# **Contents**

Product Introduce	3
2.2 Main technical index	
• •	
	Product Introduce




# 1, Product Introduce

#### 1.1 Brief introduce

Temperature & humidity sensor beacon is a new generation sensor technology that JINOU company developed which based on Beacon. This product can send collected data to phone or gateway via Beacon broadcasting.

# 1.2 System picture



Pic 1 Temperature & humidity sensor beacon system

# 2 Products Features

#### 2.1 Module features

- ◆ Bluetooth version: 5.0 BLE
- Automatic power saving mode
- Compatible with FCC, CE, RoSH certificates
- Precisely show signal strength
- ◆ Having temperature & humidity testing information
- ♦ Able to set sampling frequency



#### 2.2 Main technical index

- ✓ Working frequency: ISM frequency 2.400~2.483GHz
- ✓ Bluetooth specification: V5.0BLE
- ✓ Spread spectrum method: FHSS
- ✓ Voltage: 2.7—3.3V
- ✓ Transmitting power: 0dBm
- ✓ Transmitting distance: 10-30m
- $\checkmark$  Receiving sensitivity: <-96dBm at < 0.1% BER
- ✓ Store temperature: -55 °C ~ 125 °C
- ✓ Standby power: about 30uA
- ✓ Antenna standard: 2.4G, 50ohm
- ✓ Safety standard: AES 128bit
- ✓ Temperature measure range: -40 °C ~ +85 °C
- ✓ Temperature measure accuracy: between -10 °C ~ +85 °C, deviation is ±0.4 °C; between -40 °C ~ -10 °C, deviation is ±0.9 °C.
- ✓ Relative humidity measure range: 0 ~ 100%
- ✓ Humidity measure accuracy: between 0 +80% RH, deviation is ±3%; between 80
   +100% RH, deviation is ±4.5%


# 2.3 Applications

- ◆ Temperature & humidity tag
- ◆ Freezing transportation
- ♦ Smart farm
- Near field positioning

#### 3. Using Method


1. Open Android APP, click "Search" to find beacon.






#### BLE5.0 Temperature & Humidity Sensor Beacon User Manual

2. After searched beacon, click "connect" to connect beacon with app.




#### BLE5.0 Temperature & Humidity Sensor Beacon User Manual

3. When connected, open "Read Weather Information".



BLE5.0 Temperature & Humidity Sensor Beacon User Manual

4. User can edit reading interval. Edit range is 300~2550ms.





# 4. Contact Information

Company: ChongQing JINOU Science and Technology Development CO.,Ltd

Address: 108# Huaxuan Branch, Yuzhou Road, Jiulongpo District, Chongqing, China.

Website: <a href="mailto:www.oemblue.com">www.jinoux.com</a>
Emails: <a href="mailto:info@oemblue.com">info@oemblue.com</a>
<a href="mailto:lauren@oemblue.com">lauren@oemblue.com</a>

dora@oemblue.com ivy@oemblue.com

Tel: 86-23-68903066 Fax: 86-23-68644164