

FILTRATION

Filters and tank strainers

Clean spray liquid protects the pump and stops nozzles blocking. Fit a strainer in the tank opening, a suction filter before the pump and a line filter before the boom.



GLQ60
Suction filter

50 mesh
Inlet/outlet G1½"
Hose 20 or 28 mm
Capacity 60 L/min



GLQ100
Suction filter

50 mesh
Inlet/outlet G1½"
Hose 28 mm
Capacity 100 L/min



GLQ200
Suction filter

30 or 50 mesh
Inlet/outlet G1½"
Hose 28 or 35 mm
Capacity 160 L/min



GLQ220
Suction filter

30, 50 or 80 mesh
Inlet/outlet G2
Hose 50 mm
Capacity 220 L/min



YLQ I
Pressure line filter

50 mesh
Inlet/outlet G1/2"
Working pressure 14 bar



YLQ II
Double-layer line filter

Inner 50 mesh, outer 200 mesh
Inlet/outlet G1/2"
Working pressure 14 bar



GLT50
High-pressure self-cleaning filter

50 mesh
Inlet/outlet G1/2
Working pressure 50 bar
Capacity 70 L/min



Replacement filter elements

Red and blue mesh inserts
For the filters on this page



LW400
Tank strainer

18 mesh
Ø 400 mm, fits a 380 mm opening
Height 275 mm



LW302
Tank strainer

18 mesh
Ø 300 mm, fits a 288 mm opening
Height 235 mm



LW210
Tank strainer

18 mesh
Ø 210 mm, fits a 188 mm opening
Height 120 mm