

CONTROL

Regulators, section valves and ball valves

Pressure regulators set the spray pressure and return the surplus to the tank; section distributors switch boom sections on and off from the tractor.



GI40X / GI40Y Pressure regulator

Working pressure 40 bar
For GMB30 and GMB55 pumps, or remote control
1-4 ball-valve outlets, G1/2 thread
Outlet hose 10 or 13 mm



GR40/30/20 - GR40Y/30Y/20Y Pressure regulator

Working pressure 40, 30 or 20 bar
For the GMB30 pump, or remote control
1-3 ball-valve outlets, G1/2 thread
Outlet hose 10 or 13 mm



RM40YF / RM40Y Pressure regulator

Working pressure 40 bar
For the GMB81 pump
Ball-valve outlets, G1/2 thread
Outlet hose 10 or 13 mm



BMH50 High-pressure regulator

Working pressure 50 bar
For pumps of 90-200 L/min
Inlet G3/4, outlet G1/2, overflow G1



FPF3 3-section distributor

Working pressure 15 bar
Weight 1.6 kg · 285×250×255 mm
Outlets 13, 10 or 8.5 mm



FPF4 4-section distributor

Working pressure 15 bar
Weight 1.625 kg · 285×250×255 mm
Outlets 13, 10 or 8.5 mm



FPF5 5-section distributor

Working pressure 15 bar
Weight 1.725 kg · 285×250×255 mm
Outlets 13, 10 or 8.5 mm



FPF6 6-section distributor

Working pressure 15 bar
Weight 1.825 kg · 306×250×255 mm
Outlets 13, 10 or 8.5 mm



HXF 1 1/2" 3-way ball valve

Thread G1 1/2"
Working pressure 10 bar



HXF2 3-way ball valve

Thread G2
Working pressure 10 bar