





- GPIO pins 34, 35, 36 and 39 are input only.
- TXO and RXO (SerialO) are used for serial programming.
- TX2 and RX2 can be accessed as Serial2.
- Default SPI is VSPI. Both VSPI and HSPI pins can be set to any GPIO pins.
- All GPIO pins support PWM and interrupts.
- . Builtin LED is connected to GPIO2.
- Some GPIO pins are used for interfacing flash memory and thus are not shown.



Rev. 0.1, 17-12-2022 Design: Vishnu Mohanan