# **DBGP Specification (for EE Thread Extension)**

© 2001 Sony Computer Entertainment Inc.

Publication date: October 2001

Sony Computer Entertainment Inc. 1-1, Akasaka 7-chome, Minato-ku Tokyo 107-0052, Japan

Sony Computer Entertainment America 919 E. Hillsdale Blvd. Foster City, CA 94404, U.S.A.

Sony Computer Entertainment Europe 30 Golden Square London W1F 9LD, U.K.

The DBGP Specification (for EE Thread Extension) manual is supplied pursuant to and subject to the terms of the Sony Computer Entertainment PlayStation® license agreements.

The DBGP Specification (for EE Thread Extension) manual is intended for distribution to and use by only Sony Computer Entertainment licensed Developers and Publishers in accordance with the PlayStation® license agreements.

Unauthorized reproduction, distribution, lending, rental or disclosure to any third party, in whole or in part, of this book is expressly prohibited by law and by the terms of the Sony Computer Entertainment PlayStation® license agreements.

Ownership of the physical property of the book is retained by and reserved by Sony Computer Entertainment. Alteration to or deletion, in whole or in part, of the book, its presentation, or its contents is prohibited.

The information in the *DBGP Specification (for EE Thread Extension)* manual is subject to change without notice. The content of this book is Confidential Information of Sony Computer Entertainment.

and PlayStation are registered trademarks of Sony Computer Entertainment Inc. All other trademarks are property of their respective owners and/or their licensors.

# **Table of Contents**

About This Manual	v
Changes Since Last Release	V
Related Documentation	V
Typographic Conventions	V
Developer Support	V
Overview	1
Message Format	1
Messages	2
Thread List(THREADLIST/THREADLISTR)	2
Thread Control Block(TCB/TCBR)	4
Semaphore Block(SEMABLOCK/SEMABLOCKR)	8
Handler List(HANDLERLIST/HANDLERLISTR)	9

# **About This Manual**

This is the Runtime Library Release 2.4 version of the DBGP Specification (for EE Thread Extension) manual.

It describes the EE thread extension of DBGP.

# **Changes Since Last Release**

None

## **Related Documentation**

Note: the Developer Support Web site posts current developments regarding the Libraries and also provides notice of future documentation releases and upgrades.

# **Typographic Conventions**

Certain Typographic Conventions are used throughout this manual to clarify the meaning of the text:

Convention	Meaning
courier	Indicates literal program code.
italic	Indicates names of arguments and structure members (in structure/function definitions only).
medium bold	Indicates data types and structure/function names (in structure/function definitions only).
blue	Indicates a hyperlink.

# **Developer Support**

## **Sony Computer Entertainment America (SCEA)**

SCEA developer support is available to licensees in North America only. You may obtain developer support or additional copies of this documentation by contacting the following addresses:

Order Information	Developer Support
In North America:	In North America:
Attn: Developer Tools Coordinator Sony Computer Entertainment America 919 East Hillsdale Blvd. Foster City, CA 94404, U.S.A. Tel: (650) 655-8000	E-mail: PS2_Support@playstation.sony.com Web: http://www.devnet.scea.com/ Developer Support Hotline: (650) 655-5566 (Call Monday through Friday, 8 a.m. to 5 p.m., PST/PDT)

## **Sony Computer Entertainment Europe (SCEE)**

SCEE developer support is available to licensees in Europe only. You may obtain developer support or additional copies of this documentation by contacting the following addresses:

Order Information	Developer Support
In Europe:	In Europe:
Attn: Production Coordinator Sony Computer Entertainment Europe 30 Golden Square London W1F 9LD, U.K. Tel: +44 (0) 20 7859-5000	E-mail: ps2_support@scee.net Web: https://www.ps2-pro.com/ Developer Support Hotline: +44 (0) 20 7859-5777 (Call Monday through Friday, 9 a.m. to 6 p.m., GMT)

## **Overview**

This document describes the EE thread extension of DBGP. These functions are supported in DBGP Version 3.10 and later. In versions which do not support these functions, DBGP\_RESULT\_INVALREQ will be returned in the DBGP header result field.

# **Message Format**

Values set in each field of a DBGP header are as follows.

id

DBGP\_CPUID\_CPU 0 // CPU (ESDBGP)

group

DBGP\_GROUP\_EE\_THREAD -

## type

DBGP\_EE\_THREAD\_TYPE\_THREADLIST 0x30 //Get Thread List Request DBGP\_EE\_THREAD\_TYPE\_THREADLISTR 0x31 //Get Thread List Reply DBGP\_EE\_THREAD\_TYPE\_TCB 0x32 //Get TCB Request DBGP EE THREAD TYPE TCBR 0x33 //Get TCB Reply DBGP\_EE\_THREAD\_TYPE\_SEMABLOCK 0x34 //Get Semaphore Block Request DBGP\_EE\_THREAD\_TYPE\_ SEMABLOCKR 0x35 //Get Semaphore Block Reply DBGP\_EE\_THREAD\_TYPE\_HANDLERLIST 0x36 //Get Handler List Request DBGP\_EE\_THREAD\_TYPE\_ HANDLERLISTR 0x37 //Get Handler List Reply

code, count are described in the description of type.

#### result

Result codes shown in the following table are entered in messages sent from a target to a host. 0 is always set in messages sent from a host to a target.

Common to all groups

DBGP\_RESULT\_GOOD 0x00 // Good

DBGP\_RESULT\_INVALREQ 0x01 // Invalid Request

DBGP\_RESULT\_UNIMPREQ 0x02 // Unimplemented Request

DBGP\_RESULT\_ERROR 0x03 // Error

If it was determined that an invalid request occurred after the target recognized a type, or if a message of an unimplemented type is received, messages of those response types will be returned for each appropriate type.

In addition, the sender must always set fields to 0 that are unspecified in this document. If the receiver obtains a value that is not 0, it must be handled as an error to the best extent possible.

# Messages

# Thread List(THREADLIST/THREADLISTR)

Messages which request valid thread lists in the EE kernel and their responses.

The messages consist of the following types of headers and data.

DBGP\_EE\_THREAD\_TYPE\_THREADLIST: DECI2 header + DBGP header

DBGP\_EE\_THREAD\_TYPE\_THREADLISTR: DECI2 header + DBGP header +


DBGP\_EE\_THREADLIST\_HDR + DBGP\_EE\_THREADLIST\_DATA X

DBGP\_EE\_THREADLIST\_HDR.count

Set the code field of the DBGP header by combining the codes below.

DBGP_EE_THREAD_CODE_ALLTHREADLIST	0x3f
List of all threads	
DBGP_EE_THREAD_CODE_THREADREADYQUEUELIST	0x0
Thread ready queue thread list	
DBGP_EE_THREAD_CODE_RUN	0x1
RUN state thread list	
DBGP_EE_THREAD_CODE_READY	0x2
READY state thread list	
DBGP_EE_THREAD_CODE_WAIT	0x4
WAIT state thread list	
DBGP_EE_THREAD_CODE_SUSPEND	0x8
SUSPEND state thread list	
DBGP_EE_THREAD_CODE_WAITSUSPEND	0x20
WAITSUSPEND state thread list	
DBGP_EE_THREAD_CODE_DORMANT	0x10
DORMANT state thread list	
DBGP_EE_THREAD_CODE_RESET	0x80
Initialize to 0 the number of times the threads have gone to RUN state.	

Figure 1: Thread List Header(DBGP\_EE\_THREADLIST\_HDR)



## count

Number of threads included in the thread list

0

Figure 2: Thread List Data(DBGP\_EE\_THREADLIST\_DATA)

31

id
priority
status
cause
waitid
wakeupcount
count
pc
sp
func
ra
reserved [0]
reserved [1]

#### id

Thread ID

# priority

Thread priority

#### status

Thread state

THS\_RUN 0x01 RUN state
THS\_READY 0x02 READY state
THS\_WAIT 0x04 WAIT state

THS\_SUSPEND 0x08 SUSPEND state

THS\_WAITSUSPEND 0xc WAIT-SUSPEND state

THS\_DORMANT 0x10 DORMANT state

## cause

WAIT factor (None = 0, Sleep = 1, Sema = 2)

# waitid

Semaphore ID

## wakeupcount

Number of wakeup requests

### count

Number of times the thread has gone to RUN state

#### рс

Program counter

#### 4 Messages

sp

Stack pointer \$29

#### func

Execution start address

ra

Return address \$31

## reserved[2]

Reserved area

A DBGP\_EE\_THREAD\_TYPE\_THREADLISTR response returns a 1 in the count field of a DBGP header. When the thread is in RUN state, the current values are placed in pc,sp,ra.

#### Limitations

When there is a break in the interrupt handler, the register of the thread in RUN state is obtained and the current value is returned.

# Thread Control Block(TCB/TCBR)


Messages which specify valid thread IDs in the EE kernel and their responses. The messages consist of the following types of headers and data.

```
DBGP_EE_THREAD_TYPE_TCB: DECI2 header + DBGP header + DBGP_EE_THREADID_DATA

DBGP_EE_THREAD_TYPE_TCBR: DECI2 header + DBGP header + DBGP_EE_TCB_DATA
```

The format for DBGP\_EE\_THREADID\_DATA is as follows.

#### Figure 3: Thread Id Data(DBGP\_EE\_THREADID\_DATA)



id

Valid thread ID to be specified

Figure 4: TCB Data (DBGP\_EE\_THREADTCB\_DATA)

31 0

31	U
id	
priority	
status	
cause	
waitid	
wakeupcount	
count	
pc	
stackpointer	
func	
args	
argc	
stack	
stacksize	
endofheap	
option option	
gpReg	
initpriority	
sa fcr31	
gpr [0] [0]	
gpr [0] [1]	
gpr [0] [2]	
gpr [0] [3]	
gpr [31] [2]	
gpr [31] [3]	
hi [0]	
hi [1]	
lo [0]	
lo [1]	
hi1 [0]	
hi1 [1]	
lo1 [0]	
lo1 [1]	
fpr [0]	
:	
fpr [31]	
facc	
reserved [0]	
reserved [1]	
reserved [2]	

#### id

Thread ID

## priority

Thread priority

#### status

Thread state

THS_RUN	0x01	RUN state
THS_READY	0x02	READY state
THS_WAIT	0x04	WAIT state

THS\_SUSPEND 0x08 SUSPEND state

THS\_WAITSUSPEND 0xc WAIT-SUSPEND state

THS\_DORMANT 0x10 DORMANT state

#### cause

WAIT factor (None = 0, Sleep = 1, Sema = 2)

#### waitid

Semaphore ID during semaphore WAIT

# wakeupcount

Number of wakeup requests

#### count

Number of times the thread has gone to RUN state

## рс

Program counter

## stackpointer

Top address of user stack (= \$29(sp) + 0x280)

#### func

Execution start address

## args

Arguments of StartThread

#### argc

Number of arguments of StartThread

## stack

Bottom address of stack

#### stacksize

Stack size

## endofheap

End address of heap

## option

Cannot be used

# gpReg

Address of global pointer

## initpriority

Initial value of priority

sa

sa register

#### fcr31

fcr31 register

## gpr[32]

**GPR** 

hi

hi register

lo

lo register

hi1

hi1 register

lo1

lo1 register

## fpr[32]

fpr register

#### facc

facc register

## reserved[3]

Reserved area

A DBGP\_EE\_THREAD\_TYPE\_TCBR response returns a 0 in the count field of a DBGP header when the thread corresponding to the specified thread ID does not exist. 1 is returned when the thread does exist. When the thread is in RUN state, the current register values are placed in gpr, fprt, facc, pc, sa, hi, lo, hi1, lo1.

#### Limitations

When there is a break in the interrupt handler, the register of the thread in RUN state is obtained and the current value is returned.

# Semaphore Block(SEMABLOCK/SEMABLOCKR)

Messages which request valid semaphore information in the EE kernel and response messages which return semaphore information.

The messages consist of the following types of headers and data.

DBGP\_EE\_THREAD\_TYPE\_SEMABLOCK: DECI2 header + DBGP header +

DBPG EE SEMAID DATA

DBGP\_EE\_THREAD\_TYPE\_SEMABLOCK R: DECI2 header + DBGP header +

DBGP\_EE\_SEMABLOCKHDR + (DBGP\_EE\_SEMABLOCK\_DATA +

DBGP\_EE\_THREADID\_DATA X DBGP\_SEMABLOCK\_DATA.numWaitThreads ) X

DBGP EE THREADBLOCK HDR.count


In the code field of the DBGP header of DBGP\_EE\_THREAD\_TYPE\_SEMABLOCK

DBGP\_EE\_THREAD\_CODE\_SEMAID 0 // set the semaphore ID in DBGP\_EE\_SEMAID\_DATA and get semaphore information.

DBGP\_EE\_THREAD\_CODE\_SEMAALL 1 // get all semaphore information.

Set DBGP\_EE\_SEMAID\_DATA to 0.


Figure 5: Semaphore ID data (DBGP\_EE\_SEMAID\_DATA)



#### sema id

Semaphore ID

Figure 6: Semaphore block data (DBGP\_EE\_SEMABLOCK\_HDR)



#### count

Number of semaphores included in response message

Figure 7: Semaphore information (DBGP\_EE\_SEMABLOCK\_DATA + DBGP\_EE\_THREADID\_DATA X DBGP\_EE\_SEMABLOCK\_DATA.numWaitThreads)

sema id
count
maxcount
attr
option
numWaitThreads
thread id
thread id
thread id
:

#### sema id

Semaphore ID

#### count

Number of semaphore resources

#### maxcount

Maximum number of semaphore resources

#### attr

Semaphore attributes

#### option

Additional user defined information

## numWaitThreads

Number of threads waiting for semaphore

#### thread id

Thread ID of thread waiting for semaphore. This ID is returned in order of semaphore waiting.

When the respective semaphore exists, a 1 is returned in the count field of the DBGP header of a DBGP\_EE\_THREAD\_TYPE\_SEMABLOCKR response. Returns a 0 if no semaphore exists.

# Handler List(HANDLERLIST/HANDLERLISTR)

Messages that request interrupt handler lists registered using the EE kernel API and their responses.

The messages consist of the following types of headers and data.

DBGP\_EE\_THREAD\_TYPE\_HANDLERLIST

DBGP\_EE\_THREAD\_TYPE\_HANDLERLISTR: DECI2 header + DBGP header +

DBGP\_EE\_HANDLER\_DATA X DBPG header.count

Figure 8: Interrupt handler data (DBGP\_EE\_HANDLER\_DATA)

31	1 0
	kind
	number
	mask
	func
	arg

### kind

Handler type

DBGP\_EE\_INTC\_HANDLER 0 // INTC interrupt

DBGP\_EE\_DMAC\_HANDLER 1 // DMAC interrupt


## number

Interrupt handler number (0-15)

#### mask

Checks whether the interrupt handler is valid

Figure 9: DBGP\_EE\_HANDLER\_DATA.mask



If the handler is valid, the bits of that number change to 1. If invalid, 0.

#### func

Entry point of interrupt handler function

## arg

Argument to interrupt handler

The DBGP\_EE\_THREAD\_TYPE\_HANDLERLISTR response returns the number of DBGP EE HANDLER DATA that is returned in the count field of the DBGP header.