

MeshCom-Guru

User Manual

v0.3.93 • English

This manual explains the important features of version 0.3.93 in a practical, user-friendly way. No developer setup is required. MeshCom-Guru connects to your MeshCom node and brings messages, rooms, map, Worldwide, monitor, stations, weather and statistics together in one application.

Quick start

1. Start the program and enter the Hotspot IP.
2. Click Connect and wait until ONLINE is shown.
3. Enter your callsign and, if needed, GPS coordinates, then choose Save GPS.
4. Create or select the required rooms under Rooms.
5. Enter a message and use Send.
6. Use Settings Language to switch between all seven supported languages.

1. Connection

Hotspot IP, callsign and GPS are located in the upper part of the application. Connect establishes the connection to the MeshCom web service. After a short interruption, MeshCom-Guru can automatically reconnect. Disconnect intentionally ends the connection.

2. Rooms and "All"

Your rooms are shown on the left. Use Add Room to enter rooms. All combines messages from your saved rooms in one view. The room filter can use up to five rooms.

3. Private chats

Private messages are kept separate from room chats. A callsign can be clicked to open the relevant private chat or QRZ.com. This keeps room traffic and direct conversations clearly separated.

4. Sending messages

Enter a message, check the destination or room, then choose Send. The message field supports up to 149 characters. Quick texts and smileys are available next to the message field.

5. Live monitor

The monitor displays received MSG, POS, TEL and ACK entries. Pause stops the live display and Clear removes the current display. Filter, search and auto-scroll help with monitoring. The counter shows “displayed / saved”.

6. Map

The map shows known stations and their positions. Use + and - to zoom. Depending on received data, distance, RSSI and SNR can be shown for a station.

7. Worldwide

The Worldwide tab displays the integrated MeshCom activity page. The page refreshes itself; MeshCom-Guru does not add a separate 15-second refresh. WebKitGTK is used for this view on Linux/Raspberry Pi.

8. Stations / MH

This area lists recently heard stations. The list can contain up to 250 entries. Typical information includes callsign, distance, RSSI and SNR.

9. Weather

The weather line can show temperature, humidity, QFE and QNH. Refresh Weather reloads the values. Send Weather transmits the current weather data.

10. Statistics

Statistics summarize messages, nodes, positions, telemetry, private messages and monitor entries. Messages per room are also shown.

11. Display and settings

Under Settings Display you can switch between Classic and Dashboard. Both views use the same MeshCom data and functions. Personal settings are saved and restored on the next start.

12. Language

MeshCom-Guru supports Deutsch, English, Italiano, Nederlands, Français, Español and Svenska. The language can be changed while the program is running. The integrated guide and controls follow the selected language.

13. Backup, restore and update check

Personal MeshCom-Guru data can be backed up and restored. The update check informs you about a newer GitHub release. Updates are not downloaded or installed automatically.

14. Help and useful tips

Use Help Guide to open this documentation inside the application. For connection problems, first check the Hotspot IP, node reachability and the ONLINE/OFFLINE status. After a short interruption, give automatic reconnect a moment to restore the connection.

Good to know

Classic view remains available as a familiar alternative to Dashboard.

Worldwide is an integrated HTML page and is not treated as an ordinary chat message.

The monitor “displayed / saved” values are two different counters and are not an error.

Personal settings are stored in the user area under ~/.MeshCom.

73 – and enjoy MeshCom-Guru!

MeshCom-Guru v0.3.93 • English