

Servo ID	Name	Neutral Angle	Min Angle (Safe)	Max Angle (Safe)	Direction Reference (What + / - means)	Notes (Movement Meaning)
0	Head	65°	35	90	+ → Up, - → Down	Nod head up ↔ down
1	Neck	60°	25	110	+ → Left, - → Right	Rotate head left ↔ right
2	R_Shoulder	85°	35	150	+ → Forward, - → Backward	Move whole right arm forward/backward
3	R_ARM1	20°	20	135	+ → Up, - → Down	Move right arm vertically (side raise/lower)
4	R_ARM2	90°	25	150	- → Inward (toward body), + → Outward	Rotate right forearm inward/outward
5	R_Hand	20°	20	125	+ → Bend, - → Straight	Bend/straighten elbow (acts as elbow joint)
6	L_Shoulder	90°	20	135	- → Forward, + → Backward	Move whole left arm forward/backward
7	L_ARM1	140°	25	143	- → Up, + → Down	Move left arm vertically (side raise/lower)
8	L_ARM2	90°	20	150	+ → Inward (toward body), - → Outward	Rotate left forearm inward/outward
9	L_Hand	20°	20	125	+ → Bend, - → Straight	Bend/straighten elbow (acts as elbow joint)
10	R_Leg	90°	25	150	+ → Forward, - → Backward	Move right leg forward/backward
11	R_Knee	90°	20	90	- → Bend, + → Straight	Bend right knee
12	L_Leg	90°	20	150	- → Forward, + → Backward	Move left leg forward/backward
13	L_Knee	90°	90	150	+ → Bend, - → Straight	Bend left knee
14	Servo14	90°		?	TBD	(unused / extra)
15	Servo15	90°		?	TBD	(unused / extra)