
Pre-install two set screws into all 56 inside-corner brackets.

If these screws came bundled with the brackets, check that the set screws are either **cone or cup point** style so that they bite into the frame and form a solid electrical connection for grounding in a later step.

Keep these brackets handy, since they will use these brackets on-demand in later steps.


В



Exploded View



Assembled View



Assembled Side View

Make 56 Asssemblies

В

Α

ITEM NO.	DESCRIPTION	QTY.
1	Interior Inside Corner Bracket	56
2	M4 Set Screw (Cup Point), 4mm long	112

Part Prep				
© ((i) BY	Created by: Joshua Vasquez	last edited: 3/15/2021	
		SCALE: 1:1	SHEET 1 OF 1	