




Parking Post Instructions			
(0)	•	Created by: Joshua Vasquez	last edited: 10/7/2021
	BY	SCALE: 1:1	SHEET 1 OF 7

This part is configurable, and each tool has a particular configuration. (Instructions are the same for all configurations.) Check the embedded Part Number to make sure you're building the one that matches your tool.






Parking Post Base Back View





The four-number code should match on both parts!.


Size Check			
(C) (B)		ted by: nua Vasquez	last edited: 10/7/2021
	SC	CALE: 1:1	SHEET 2 OF 7


Install the following heat-set inserts with the Plate Press Technique













	Heat Set Insert Installation			
		(1)	Created by:	last edited:
		BY	Joshua Vasquez	10/7/2021
			SCALE: 1:1	SHEET 3 OF 7







Press Fit these dowel pins all the way until they are flush with the bottom surface. Use an arbor press, vise, or a clamp.

ITEM NO.	DESCRIPTION	QTY.
2	M5 Dowel Pin, 60mm len	2


Dowel Pin Installation			
<u></u>	(i) BY	Created by: Joshua Vasquez	last edited: 10/7/2021
		SCALE: 1:1	SHEET 4 OF 7






ITEM NO.	DESCRIPTION	QTY.
2	M3 Buttonhead Screw, 10mm long	1
3	M5 Buttonhead Screw, 8mm long	2


Parking Post Base Assembly			
CC BY		Created by: Joshua Vasquez	last edited: 10/7/2021
		SCALE: 1:1	SHEET 5 OF 7



ITEM NO.	DESCRIPTION	QTY.
3	M3 Buttonhead Screw, 10mm long	2

Final Assembly		
© BY	Created by: Joshua Vasquez	last edited: 10/7/2021
	SCALE: 1:1	SHEET 6 OF 7





Adjustments			
© BY	Created by: Joshua Vasquez	last edited: 10/7/2021	
	SCALE: 1:1	SHEET 7 OF 7	