

BOKARO STEEL PLANT — ILLUSTRATIVE SAMPLE

Standard Operating Procedure

SOP No: BSP-SAF-011

Title: Safe Work at Height

Department: Safety and Environment

Revision: 02

Date: 14-May-2024

1. PURPOSE

To prevent falls of persons and objects when working at height.

2. DEFINITION

Work at height means any work at 1.8 metres or more above the ground or floor level, or near an unprotected edge or opening.

3. REQUIREMENTS

- Height Work Permit required for all work at 1.8 metres or more
- Only persons certified medically fit for height work (renewed every year) may work at height
- Full body harness with double lanyard and shock absorber; anchor above shoulder level
- 100% tie-off: at least one lanyard must be attached at all times
- Anchor point capacity minimum 22 kN (approx. 2,250 kg)

4. SCAFFOLDS AND LADDERS

- Scaffolds only erected by trained scaffolders and inspected before use; green tag = safe to use, red tag = do not use
- Toe boards of minimum 150 mm and double guard rails on all working platforms
- Ladders placed at 1:4 angle (1 m out for every 4 m up) and extended 1 metre above the landing

5. WEATHER RESTRICTIONS

- Stop outdoor height work when wind speed exceeds 40 km/h, during lightning, or heavy rain

6. FALLING OBJECTS

- Barricade the area below and post a watchman
- Tools must be tied with tool lanyards

7. RESCUE

A rescue plan must be available before work starts. A suspended worker must be rescued within 10 minutes to avoid suspension trauma. Emergency: Ext. 100.