

```

const int touchSensorPin = 5; // GPIO 5 on ESP8266 (D1 on NodeMCU)
const int ledPin = 4;         // GPIO 4 on ESP8266 (D2 on NodeMCU)

// Fill-in information from Blynk Device Info here
#define BLYNK_TEMPLATE_ID      "TMPL6_4BKx73A"
#define BLYNK_TEMPLATE_NAME    "Quickstart Template"
#define BLYNK_AUTH_TOKEN       "C5WqL44YR4AXwCcKeuuqNFCw-jKxtOBL"

/* Comment this out to disable prints and save space */
#define BLYNK_PRINT Serial

#include <ESP8266WiFi.h>
#include <BlynkSimpleEsp8266.h>

// Your WiFi credentials
char ssid[] = "CPH1609";      // Your WiFi SSID
char pass[] = "1234567R";     // Your WiFi Password

BlynkTimer timer;

void touchSensorControl()
{
    // Read the state of the touch sensor
    int sensorValue = digitalRead(touchSensorPin);
    Serial.println(sensorValue);

    // If the sensor is touched, turn on the LED and send the status to
    Blynk
    if (sensorValue == HIGH) {
        digitalWrite(ledPin, HIGH);      // Turn on LED
        Blynk.virtualWrite(V1, 255);     // Send ON status to Blynk
    }
    // If the sensor is not touched, turn off the LED and update Blynk
    else {
        digitalWrite(ledPin, LOW);       // Turn off LED
        Blynk.virtualWrite(V1, 0);       // Send OFF status to Blynk
    }
}

// This function sends Arduino's uptime every second to Virtual Pin 2
void myTimerEvent()
{
    // Send uptime to Blynk app (V2)
    Blynk.virtualWrite(V2, millis() / 1000);
}

void setup()
{
    // Debug console
    Serial.begin(115200);
}

```

```
// Set pin modes
pinMode(touchSensorPin, INPUT); // Set touch sensor pin as input
pinMode(ledPin, OUTPUT);        // Set LED pin as output

// Connect to Blynk
Blynk.begin(BLYNK_AUTH_TOKEN, ssid, pass);

// Set up a function to be called every second
timer.setInterval(1000L, myTimerEvent);
timer.setInterval(100L, touchSensorControl); // Check touch sensor
every 100 ms
}

void loop()
{
  Blynk.run(); // Run Blynk
  timer.run(); // Run the timer
}
```